



Genuine Spare Parts






Utgåva Issue 2009- 15		Bildnr Picture No 2437		HYDRAULMOTOR KWM- 13L- 166A KWM- 13S- 162A KWM- 13S- 162N		HYDRAULIC MOTOR KWM- 13L- 166A KWM- 13S- 162A KWM- 13S- 162N		Sida Page 172	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	KWM 13L 166A	KWM 13S 162A	KWM 13S 162N						
0	1				1134- 7014- 01	Hydraulmotor	Hydraulic motor		
0		1			1134- 7015- 01	Hydraulmotor	Hydraulic motor		
0			1		1134- 7016- 01	Hydraulmotor	Hydraulic motor		
1	1	1	1		1139- 1543- 01	Pluggsats.....	Plug kit.....		Pos 2 - 5 incl.
2	2	2	2		1139- 1569- 01	• Plugg	• Plug.....		
3	2	2	2		1139- 1579- 01	• Packning.....	• Packing		
4	4	4	4		1139- 1572- 01	• Plugg	• Plug.....		
5	4	4	4		1139- 1115- 01	• O- ring.....	• O- ring		
6	1	1			1139- 1544- 01	Broms kpl.....	Brake kit.....		Pos 7 - 15 incl.
7	1	1			1139- 1541- 01	• Broms.....	• Brake		
8	1	1			1139- 1578- 01	• Kil	• Key		
9	1	1			1139- 1580- 01	• Packning.....	• Packing		
10	1	1			1139- 1542- 01	• Bromshus	• Brake case		
11	1	1			1139- 1582- 01	• Packning.....	• Packing		
12	1	1			1139- 1577- 01	• Bricka	• Washer		
13	1	1			1139- 1589- 01	• Mutter.....	• Nut		
14	2	2			1139- 1584- 01	• Skruv	• Bolt		
15	3	3			1139- 1583- 01	• Skruv	• Bolt		



Utgåva Issue 2009- 15		Bildnr Picture No 2438		HYDRAULPUMP KPL- 23ALP KPS- 23ALP		HYDRAULIC PUMP KPL- 23ALP KPS- 23ALP		Sida Page 174	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	KPL 23 ALP	KPS 23 ALP							
0	1			1134- 7012- 01	Hydraulpump	Hydraulic pump.....			
0		1		1134- 7013- 01	Hydraulpump	Hydraulic pump.....			
1	1			1139- 1557- 01	Ventilsats kpl	Check valve kit		Pos 2 - 6 incl.	
1		1		1139- 1567- 01	Ventilsats kpl	Check valve kit		Pos 2 - 5 incl.	
2	2	2		1139- 1548- 01	• Plugg	• Check plug			
3	3	3		1139- 1115- 01	• O- ring.....	• O- ring			
4	2	2		1139- 1547- 01	• Fjäder.....	• Spring (suction)			
5		2		1139- 1545- 01	• Ventil	• Check valve R.....			
5	1			1139- 1550- 01	• Ventil	• Check valve 1.2			
6	1			1139- 1368- 01	• Ventil	• Check valve F			
7	1	1		1139- 1558- 01	Bypass sats	Bypass kit		Pos 8 - 16 incl.	
8	1	1		1139- 1549- 01	• Axel.....	• Bypass pin			
9	1	1		1139- 1112- 01	• O- ring.....	• O- ring			
10	1	1		1139- 1387- 01	• Ring.....	• Back- up ring			
11	1	1		1139- 1522- 01	• Vågbricka.....	• Wave washer			
12	1	1		1139- 1373- 01	• Plåt	• By- pass plate.....			
13	1	1		1139- 1371- 01	• Adapter	• By- pass adapter.....			
14	1	1		1139- 1372- 01	• By- pass arm.....	• By- pass lever			
15	1	1		1139- 1395- 01	• Stift.....	• Pin.....			
16	1	1		1139- 1562- 01	• Bypass option sats	• Bypass option kit.....		Pos 17 - 18 incl.	
17	1	1		1139- 1585- 01	•• Skruv	•• Bolt.....			
18	2	2		1139- 0247- 01	•• Mutter.....	•• Nut			
19	1	1		1139- 1563- 01	Pump kpl	Gear pump kit		Pos 20 - 24 incl.	
20	1	1		1139- 1539- 01	• Koppling	• Coupling.....			
21	1	1		1139- 1581- 01	• Packning	• Packing			
22	1	1		1139- 1540- 01	• Pump	• Pump			
23	2	2		1139- 1573- 01	• Bricka	• Washer			
24	2	2		1139- 1587- 01	• Skruv	• Bolt			



Utgåva Issue 2009- 15		Bildnr Picture No 2439		HYDRAULPUMP KPL- 23ALP KPS- 23ALP		HYDRAULIC PUMP KPL- 23ALP KPS- 23ALP		Sida Page 176	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	KPL 23 ALP	KPS 23 ALP							
0	1				1134- 7012- 01	Hydraulpump	Hydraulic pump.....		
0		1			1134- 7013- 01	Hydraulpump	Hydraulic pump.....		
1	1	1			1139- 1559- 01	Tätningring kpl.....	Input seal kit		Pos 2 - 3 incl.
2	1	1			1139- 1551- 01	• Tätningring	• Oil seal		
3	1	1			1139- 1576- 01	• Låsring	• Ring		
4	1	1			1139- 1560- 01	Ventilsats	Charge relief kit		Pos 5 - 8 incl.
5	1	1			1139- 1571- 01	• Ventil	• Relief valve		
6	1	1			1139- 1570- 01	• Fjäder.....	• Spring		
7	1	1			1139- 1168- 01	• Packning.....	• Packing		
8	1	1			1139- 1546- 01	• Plugg	• Plug.....		
9	1				1139- 1564- 01	Neutralreglage kpl.....	Neutral kit		Pos 10 - 18 incl.
9		1			1139- 1568- 01	Neutralreglage kpl.....	Neutral kit		Pos 10 - 18 incl.
10	1	1			1139- 1127- 01	• Mutter.....	• Nut		
11	1	1			1139- 1102- 01	• Bricka	• Washer		
12	1				1139- 1553- 01	• Platta	• Plate (return SP)		
13	1	1			1139- 1555- 01	• Vridcentrum.....	• Fulcrum.....		
14	2				1139- 1122- 01	• Bult m.bricka	• Bolt w/washer		
15	1				1139- 1554- 01	• Arm.....	• Lever		
15		1			1139- 1565- 01	• Arm.....	• Lever		
16	1				1139- 1556- 01	• Fjäder.....	• Spring (return)		
16		1			1139- 1566- 01	• Fjäder.....	• Spring (return)		
17	1	1			1139- 1574- 01	• Låsring	• Ring		
18	2				1139- 1586- 01	• Skruv	• Bolt		
18		2			1139- 1588- 01	• Skruv	• Bolt		
19	1				1139- 1561- 01	Tätningring kpl.....	Control seal kit.....		Pos 20 - 21 incl.
20	1				1139- 1552- 01	• Tätningring	• Oil seal		
21	1				1139- 1575- 01	• Låsring	• Ring		