









# Genuine Spare Parts

---




21











12


(x 2)





Utgåva Issue 2009- 11		Bildnr Picture No 2196A		VILLA MONTERINGSDETALJER		VILLA ASSEMBLY PARTS		Sida Page 272	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718 2719 2725	2717	2727						
1	1	1	1		9595-0262-00	Spännstift .....	Locating pin .....		
2A	1	1	1		9699-0103-02	Shims .....	Flat washer .....		0.5 mm
2B	1	1	1		9699-0114-02	Shims .....	Flat washer .....		1.0 mm
3	2	2	2		1134-4185-01	Ansatsbricka .....	Flange washer .....		
5	4	4	4		9699-0056-02	Planbricka .....	Flat washer .....		
6	2	2	2		1134-4481-01	Vingmutter .....	Wing nut .....		
7	1	1	1		1134-4627-01	Dragögla .....	Tow bar .....		
8	2	2	2		9959-0820-16	Skruv .....	Screw .....		
9	4	4	4		9997-0820-16	Skruv .....	Screw .....		
10A	1	1	1		1134-4734-01	Tändningsnyckel .....	Ignition key .....		
10B	1	1	1		1134-6125-01	Tändningsnyckel .....	Ignition key .....		
11	1	1	1		1134-5245-01	Batterirem .....	Battery strap .....		
12	1	1	1		1134-6113-01	Batteriskruvar .....	Battery screws .....		
13	2	2	2		9898-1035-16	Skruv .....	Screw .....		
14	2	2	2		9739-1031-22	Mutter .....	Nut .....		
21	1				8211-0011-90	Bruksanvisning .....	Owner's manual .....		13-2718, 13-2719
21	1				8211-0036-90	Bruksanvisning .....	Owner's manual .....		13-2725
21			1		8211-0038-90	Bruksanvisning .....	Owner's manual .....		13-2727
21		1			8211-0040-90	Bruksanvisning .....	Owner's manual .....		13-2717
21	1				8211-0603-90	Monteringsanvisning .....	Assy instructions .....		
21	1				8211-0701-91	Säkerhetsföreskrifter .....	Safety regulations .....		
21	1	1	1		8211-0960-90	Garantikort .....	Warranty card .....		



Utgåva Issue 2009- 11		Bildnr Picture No 2197		VILLA KAROSS		VILLA BODY WORK		Sida Page 274	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717 2725	2718 2727	2719						
1	1	1	1	1134-5283-02	Motorhuv- gul .....	Engine hood- yellow .....			
2	7	7	7	9838-9530-12	Skruv .....	Screw .....			
3	1	1	1	1134-5284-02	Motorlucka- grå .....	Engine cover- grey .....			
4	1	1	1	1134-5307-01	Stänkskärm- vä, grå .....	Mud guard- LH, grey .....			
5	1	1	1	1134-5307-02	Stänkskärm- hö, grå .....	Mud guard- RH, grey .....			
6	2	2	2	1134-0225-00	Stödplåt .....	Support plate .....			
7	4	4	4	9699-0056-02	Planbricka .....	Flat washer .....			
8	6	6	6	9945-0816-16	Skruv .....	Screw .....			
9	4	4	4	1134-4176-01	Clips .....	Clips .....			
10	4	4	4	9893-0616-16	Skruv .....	Screw .....			
11	1	1	1	1134-5306-01	Stötfångare, front- vä .....	Bumper, front- LH .....			
12	1	1	1	1134-5306-02	Stötfångare, front- hö .....	Bumper, front- RH .....			
13	1	1	1	1134-5305-01	Front- nedre .....	Front plate- lower .....			
14	6	6	6	9893-0616-16	Skruv .....	Screw .....			
15A	1			1134-5304-01	Front- övre .....	Front- upper .....			
15B		1		1134-5320-02	Front- övre .....	Front- upper .....			
15C			1	1134-5320-05	Front- övre .....	Front- upper .....			
16	2	2	2	9946-0525-16	Skruv .....	Screw .....			
17	2	2	2	1134-4790-02	Styrning .....	Hood guide .....			
18	2	2	2	9838-9530-12	Skruv .....	Screw .....			
19	2	2	2	9699-0060-02	Planbricka .....	Flat washer .....			
20			1	1134-6199-01	Deflektor .....	Deflector .....			
99	1			1134-6426-01	Dekalsats .....	Label kit .....		Villa 12	
99		1		1134-6426-02	Dekalsats .....	Label kit .....		Villa 14 HST	
99			1	1134-6426-03	Dekalsats .....	Label kit .....		Villa 16 HST	






Utgåva Issue		Bildnr Picture No		VILLA RAM		VILLA FRAME		Sida Page	
2009- 11		1642B						276	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717 2725	2718 2719 2727							
1	1	1		1134-6635-01	Ram.....	Frame.....			
2	1	1		1134-5293-01	Durk.....	Floor plate.....			
3	2	2		9893-0616-16	Skruv.....	Screw.....			
4	1			1134-5338-03	Durkmatta.....	Floor mat.....			
4		1		1134-5339-03	Durkmatta.....	Floor mat.....			
5	1	1		1134-5453-03	Stötfångare- bak, grå.....	Bumper- rear, grey.....			
6	1	1		1134-6630-01	Stag- vä.....	Attachment- LH.....			
7	1	1		1134-6630-02	Stag- hö.....	Attachment- RH.....			
8	2	2		1134-0240-00	Ansatsskruv.....	Shoulder screw.....			
9	2	2		1134-4242-01	Distansbricka.....	Spacer washer.....			
10	2	2		9694-0001-00	Fjäderbricka.....	Washer.....			
11	2	2		9747-0831-02	Mutter.....	Lock nut.....			
12	2	2		9943-0516-16	Skruv.....	Screw.....			
13	2	2		9959-0820-16	Skruv.....	Screw.....		L = 20 mm	
14	2	2		9959-0825-16	Skruv.....	Screw.....		L = 25 mm	
15	1	1		9739-0831-22	Mutter.....	Nut.....			
16	3	3		9739-0831-22	Mutter.....	Nut.....			








Utgåva Issue 2009- 11		Bildnr Picture No 1151C		VILLA REDSKAPSLYFT		VILLA LIFTING DEVICE		Sida Page 278	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717 2718 2719	2725 2727							
1	1	1		1134-4117-01	Fäste .....	Bracket .....			
2	2	2		9959-1025-16	Skruv .....	Screw .....			
3	2	2		9739-1031-22	Mutter .....	Nut .....			
4	2	2		1134-2684-01	Lager .....	Bearing .....			
5	1	1		1134-4945-01	Lyftspärr kpl .....	Lift catch assy .....			
9	1	1		9404-0027-01	• O-ring .....	• O-ring .....			
10	1	1		9650-0039-04	• Seegersäkring .....	• Lock ring .....			
11	1	1		9595-0276-01	• Spännstift .....	• Locating pin .....			
12	1	1		9997-0640-12	• Skruv .....	• Screw .....			
13	1	1		9747-0631-02	• Låsmutter .....	• Lock nut .....			
15	1	1		9897-0820-16	• Skruv .....	• Screw .....			
16	1	1		9747-0831-02	Mutter .....	Lock nut .....			
17	1	1		1134-4860-01	Lyftgaffel .....	Lift fork .....			
18	2	2		1134-0240-00	Ansätsskruv .....	Shoulder screw .....			
19	1	1		1134-4938-01	Lyftpedal .....	Lift pedal .....			
20	2	2		9997-0625-16	Skruv .....	Screw .....			
21	2	2		9739-0631-22	Mutter .....	Nut .....			
22	1	1		4231-0013-00	Fjäder .....	Spring .....			









51



Utgåva Issue		Bildnr Picture No		VILLA STYRNING	VILLA STEERING	Sida Page		
2009- 11		2199				282		
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717 2725 2727	2718 2719						
1	3	3		1134-0041-01	Linhjulshylsa .....	Bushing.....		
2	3	3		1134-0046-00	Linhållare.....	Wire clamp.....		
3	1	1		1134-9025-01	Linhjul- sats .....	Steering pulley- kit .....		Sats 2 st/kit of 2
4	3	3		9997-1040-16	Skruv.....	Screw.....		
5	2	2		9739-1031-22	Mutter.....	Nut.....		
6	1	1		1134-2032-04	Styrwire.....	Steering cable .....		
7	1	1		1134-1310-01	Tryckfjäder.....	Compression spring.....		
8	1	1		9699-0056-02	Planbricka.....	Flat washer.....		
9	1	1		9747-0831-02	Mutter.....	Lock nut.....		
10	1	1		9959-0820-16	Skruv.....	Screw.....		
11	1	1		1134-5349-03	Styrkonsol- grå .....	Steering console- grey .....		
12	4	4		9897-0820-16	Skruv.....	Screw.....		
13	4	4		9739-0831-22	Mutter.....	Nut.....		
15	1	1		1134-1305-05	Rattrör- nedre .....	Steering column- lower .....		
16	2	2		1134-1901-01	Lager .....	Bearing.....		
17	2	2		9893-0616-16	Skruv.....	Screw.....		
18	2	2		9699-0060-02	Planbricka.....	Flat washer.....		
19	1	1		1134-5495-01	Rattstång .....	Steering rod .....		
20	1	1		1134-1933-01	Styrrulle.....	Steering pulley .....		
21	1	1		9595-0262-00	Spännstift .....	Locating pin .....		
22	1	1		1134-5496-01	Ratt.....	Steering wheel .....		
32	1	1		1134-3047-01	Distans .....	Spacer .....		
33	2	2		9699-0104-02	Bricka .....	Washer.....		
36	2	2		1134-3047-01	Distans .....	Spacer.....		
37	1	1		1134-0041-05	Hylsa .....	Bushing.....		
38	1	1		1134-0046-00	Linhållare.....	Wire clamp.....		
39	1	1		1134-9025-01	Linhjul- sats .....	Steering pulley- kit .....		Sats 2 st/kit of 2
40	1	1		9997-1060-12	Skruv.....	Screw.....		
50		1		1134-6330-02	Ratt.....	Steering wheel .....		
51		1		1134-3769-01	• Styrknopp kpl .....	• Steering wheel button .....		
52		1		1134-3752-01	•• Knoppfäste.....	•• Knob holder.....		
53		1		9997-0870-16	•• Skruv.....	•• Screw.....		
54		1		1134-1565-06	•• Distans.....	•• Spacer .....		
55		3		9699-0090-02	•• Planbricka .....	•• Flat washer .....		
56		1		9747-0831-02	•• Mutter.....	•• Lock nut .....		
57		1		9403-0043-70	•• Plugg .....	•• Plug.....		
58		1		9403-0113-00	•• Mutterhatt.....	•• Nut cap .....		
60		1		1134-5216-02	Rattrör- inre .....	Steering tube- inner.....		
61		1		1134-5177-01	• Slid .....	• Slide .....		
62		1		9710-0631-12	• Fyrkantmutter .....	• Square nut .....		
63		1		1134-4481-02	Vingmutter.....	Wing nut .....		
64		1		9997-0630-12	Skruv.....	Screw.....		




Utgåva Issue 2009- 11		Bildnr Picture No 1654A		VILLA HANDREGLAGE		VILLA HAND CONTROLS		Sida Page 284	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
	2725								
1	1				1134-5286-01	Reglagepanel- vä .....	Control panel- LH .....		
2	2				1134-5531-01	Dämpare .....	Absorber .....		
3	3				9893-0616-16	Skruv .....	Screw .....		
4	1				1134-5357-01	Fäste .....	Bracket .....		
5	2				9838-9516-12	Skruv .....	Screw .....		
6	1				1134-4077-01	Gasreglage .....	Throttle control .....		
7	1				1134-4078-01	Knopp .....	Knob .....		
8	1				1134-0240-00	Ansatssskruv .....	Shoulder screw .....		
9	1				9694-0001-00	Fjäderbricka .....	Washer .....		
10	2				1134-4242-01	Distansbricka .....	Spacer washer .....		
11	1				9747-0831-02	Mutter .....	Lock nut .....		
12	1				1134-1597-13	Gaswire .....	Throttle cable .....		
13	1				9500-9991-00	Wireklämma .....	Cable clamp .....		
14	1				9943-0516-16	Skruv .....	Screw .....		
15	1				9579-0003-00	Buntband .....	Cable holder .....		
20	1				9997-0812-02	Skruv .....	Screw .....		
21	1				1134-5274-02	Distans .....	Spacer .....		
22	3				1134-3047-01	Distans .....	Spacer .....		
23	1				1134-5271-01	Reglagefäste .....	Control bracket .....		
24	1				1134-5275-01	Växelspak .....	Gear shift lever .....		
25	1				1134-5535-01	Fjäder .....	Spring .....		
26	1				9997-0890-12	Skruv .....	Screw .....		
27	1				9747-0831-02	Mutter .....	Lock nut .....		
28	1				1134-5268-01	Stag .....	Shifter rod .....		
29	1				9675-0009-02	Starlock .....	Starlock .....		
30	1				1134-5271-01	Reglagefäste .....	Control bracket .....		
31	1				1134-5276-01	Reglagespak .....	Control lever .....		
32	1				9997-0890-12	Skruv .....	Screw .....		
33	1				9747-0831-02	Mutter .....	Lock nut .....		
34	1				1134-5356-01	Stag .....	Strut .....		
35	1				9747-0831-02	Mutter .....	Lock nut .....		
36	2				9400-0312-01	Mikrobrytare .....	Micro switch .....		
37	4				9840-7716-16	Skruv .....	Screw .....		
38	1				1134-5358-01	Brytarfäste .....	Switch bracket .....		
39	2				9943-0516-16	Skruv .....	Screw .....		
40	1				1134-5285-01	Reglagepanel- hö .....	Control panel- RH .....		
41	2				1134-5531-01	Dämpare .....	Absorber .....		
42	4				9893-0616-16	Skruv .....	Screw .....		
43	2				1134-2551-01	Reglageknopp .....	Knob .....		
44	1				1134-3573-06	Krafttuttagswire .....	PTO cable .....		
45	1				1134-1242-02	Fjäder .....	Spring .....		
50	1				1134-4093-01	Tändningslås .....	Ignition switch .....		
51	1				1134-4749-01	Mutter .....	Nut .....		






Utgåva Issue		Bildnr Picture No		VILLA HST HANDREGLAGE		VILLA HST HAND CONTROLS		Sida Page	
2009- 11		2201						286	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718	2719	2727						
1	1				1134-5286-04	Reglagepanel- vä .....	Control panel- LH .....		
2	2				1134-5531-01	Dämpare .....	Absorber .....		
3	3				9893-0616-16	Skruv .....	Screw .....		
4	1				1134-5464-01	Fäste .....	Bracket .....		
6	1				1134-5465-01	Gasreglage.....	Throttle lever .....		
7	1				1134-4078-01	Knopp .....	Knob .....		
8	1				1134-0240-00	Ansattsskruv .....	Shoulder screw .....		
9	1				9694-0001-00	Fjäderbricka .....	Washer .....		
10	2				1134-4242-01	Distansbricka .....	Spacer washer .....		
11	1				9747-0831-02	Mutter .....	Lock nut .....		
12	1				1134-4197-03	Gaswire .....	Throttle cable .....		
13	1				9500-9991-00	Wireklämma .....	Cable clamp .....		
14	1				9943-0516-16	Skruv .....	Screw .....		
16	1				1134-6370-01	Wirestyrning .....	Wire guide.....		
19	1				1134-5508-01	Reglagehylsa .....	Control sleeve .....		
20	1				9997-0812-02	Skruv .....	Screw .....		
21	1				1134-5274-02	Distans .....	Spacer .....		
22	1				1134-3047-01	Distans .....	Spacer .....		
30	1				1134-5271-01	Reglagefäste .....	Control bracket .....		
31	1				1134-5276-01	Reglagespak .....	Control lever .....		
32	1				9997-0890-12	Skruv .....	Screw .....		
33	1				9747-0831-02	Mutter .....	Lock nut .....		
34	1				1134-5356-01	Stag .....	Strut .....		
35	1				9747-0831-02	Mutter .....	Lock nut .....		
36	1				9400-0312-01	Mikrobrytare.....	Micro switch .....		
37	2				9840-7716-16	Skruv .....	Screw .....		
40	1				1134-5285-02	Reglagepanel- hö .....	Control panel- RH.....		
41	2				1134-5531-01	Dämpare .....	Absorber .....		
42	4				9893-0616-16	Skruv .....	Screw .....		
43	1				1134-2551-01	Reglageknopp.....	Knob .....		
44	1				1134-3573-06	Kraftuttagwire .....	PTO cable.....		
45	1				1134-1242-02	Fjäder.....	Spring .....		




Utgåva Issue 2009- 11		Bildnr Picture No 1644B		VILLA FOTREGLAGE		VILLA FOOT CONTROLS		Sida Page 288	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
	2725								
1	1				1134-4802-01	Pedal .....	Pedal .....		
2	2				1134-4624-01	Lager .....	Bearing .....		
3	4				9897-0640-12	Skruv .....	Screw .....		
4	4				9739-0631-22	Mutter .....	Nut .....		
5	1				1134-4795-01	Kopplingsstång .....	Clutch rod .....		
6	1				1134-2138-01	Skruvögla .....	Eye bolt .....		
7	1				9739-1031-22	Mutter .....	Nut .....		
8	1				9731-1031-22	Mutter .....	Nut .....		
9	1				9739-0831-22	Mutter .....	Nut .....		
10	1				9747-0831-02	Mutter .....	Lock nut .....		
11	1				9595-0208-00	Spännstift .....	Locating pin .....		
14	1				1134-4777-01	Bromsstag .....	Brake rod .....		
15	1				1134-4617-01	Fjäder .....	Spring .....		
16	2				1134-2138-01	Skruvögla .....	Eye bolt .....		
17	2				9699-0035-02	Planbricka .....	Flat washer .....		
18	4				9595-0208-00	Spännstift .....	Locating pin .....		
19	2				9739-0831-22	Mutter .....	Nut .....		
20	1				9747-0831-02	Mutter .....	Lock nut .....		
26	1				1134-5353-01	Bromsstång .....	Brake rod .....		
27	1				1134-2786-01	Plastknopp .....	Plastic knob .....		
28	1				1131-1497-01	Fjäder .....	Spring .....		
29	1				1134-4002-01	Fäste .....	Brake rod attachment .....		
30	3				9838-9516-12	Skruv .....	Screw .....		
31	1				1134-4714-01	Fästvinkel .....	Angle bracket .....		
32	2				9959-0820-16	Skruv .....	Screw .....		
33	2				9739-0831-22	Mutter .....	Nut .....		
34	1				1134-4715-01	Triangel .....	Triangular plate .....		
35	1				1134-0240-00	Ansatsskruv .....	Shoulder screw .....		
36	1				9694-0001-00	Fjäderbricka .....	Washer .....		
37	1				9699-0036-02	Planbricka .....	Flat washer .....		
38	1				9747-0831-02	Mutter .....	Lock nut .....		
39	1				1134-4717-02	Gångstång .....	Threaded rod .....		
40	2				9570-0004-00	Vinkellänk .....	Elbow link .....		
41	2				9747-0631-02	Låsmutter .....	Lock nut .....		
42	2				9739-0631-22	Mutter .....	Nut .....		
43	1				1134-6351-01	Växelarm .....	Shift lever .....		
44	1				9987-5016-16	Skruv .....	Screw .....		
45	1				9699-0060-02	Planbricka .....	Flat washer .....		
46	1				9675-0009-02	Starlock .....	Starlock .....		
51	1				1134-4793-01	Stopplåt .....	Stop plate .....		
52	1				4231-0013-00	Fjäder .....	Spring .....		
53	2				1134-4779-01	Plastbussning .....	Plastic bushing .....		
58	1				9747-0831-02	Mutter .....	Lock nut .....		



Dana 6800-7



Utgåva Issue		Bildnr Picture No		VILLA HST FOTREGLAGE		VILLA HST FOOT CONTROLS		Sida Page	
2009- 11		1645B						290	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718	2719	2727						
1	1				1134-4802-01	Pedal .....	Pedal .....		
2	2				1134-4624-01	Lager .....	Bearing.....		
3	4				9897-0640-12	Skruv .....	Screw.....		
4	4				9739-0631-22	Mutter.....	Nut .....		
5	1				1134-4949-01	Kopplingsstång.....	Clutch rod .....		
6	2				1134-2138-01	Skruvögla .....	Eye bolt .....		
7	2				9739-1031-22	Mutter.....	Nut .....		
9	1				9739-0831-22	Mutter.....	Nut .....		
10	1				9747-0831-02	Mutter.....	Lock nut.....		
11	1				9595-0208-00	Spännstift .....	Locating pin .....		
12	2				9699-0035-02	Planbricka.....	Flat washer.....		
13	1				1134-4617-01	Fjäder.....	Spring .....		
15	1				9739-0831-22	Mutter.....	Nut .....		
16	1				9747-0831-02	Mutter.....	Lock nut.....		
18	1				9598-0002-02	Låsnål .....	Pin lock .....		
20	1				1134-5353-01	Bromstång .....	Brake rod .....		
21	1				1134-2786-01	Plastknopp.....	Plastic knob .....		
22	1				1131-1497-01	Fjäder.....	Spring .....		
23	1				1134-4002-01	Fäste.....	Brake rod attachment.....		
24	3				9838-9516-12	Skruv .....	Screw .....		
25	1				1134-6353-01	Drivpedal .....	Drive pedal.....		
26	2				1134-6313-01	Lager .....	Bearing.....		
27	2				1134-2700-01	Fäste.....	Bracket.....		
28	2				9959-0820-16	Skruv .....	Screw.....		
29	2				9739-0831-22	Mutter.....	Nut .....		
30	1				9997-0870-16	Skruv .....	Screw.....		
31	2				9739-0831-22	Mutter.....	Nut .....		
34	1				1134-4440-01	Axel .....	Shaft .....		
35	1				1134-4793-01	Stopplåt .....	Stop plate.....		
36	1				1134-4441-01	Stag .....	Link .....		
37	2				1134-0240-00	Ansatsskruv.....	Shoulder screw.....		
38	2				9694-0001-00	Fjäderbricka .....	Washer.....		
39	2				9747-0831-02	Mutter.....	Lock nut.....		
40	1				1134-5288-01	Reglagestång.....	Control rod.....		
41	2				9675-0012-02	Starlock .....	Locking washer.....		
51	1				4231-0013-00	Fjäder.....	Spring .....		
52	1				1134-4779-01	Plastbusning.....	Plastic bushing .....		
53	1				1134-4972-01	Bromslänk .....	Brake link .....		
54	1				9747-0831-02	Mutter.....	Lock nut.....		
55	1				9997-0820-16	Skruv .....	Screw.....		






Utgåva Issue 2009- 11		Bildnr Picture No 2202B		VILLA ELUTRUSTNING		VILLA EL. EQUIPMENT		Sida Page 292	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717 2725	2718 2727	2719						
1	1	1	1		1134-4804-01	Batteri.....	Battery .....		
4		1	1		1134-4610-01	Fäste.....	Switch bracket .....		
5		1	1		1134-3399-02	Brytare.....	Switch.....		
6		2	2		9852-8013-16	Skruv.....	Screw.....		
7		3	3		9579-0003-00	Buntband.....	Cable holder.....		
8	1	1	1		1134-2042-02	Kabel- svart.....	Cable- black.....		L = 350 mm
9	1	1	1		9838-9516-12	Skruv.....	Screw .....		
10	1	1	1		9747-0831-02	Mutter.....	Lock nut.....		
11	1	1	1		9795-3531-02	Mutter.....	Nut .....		1/4 UNC
11	1	1	1		9739-0631-22	Mutter.....	Nut .....		M6
12	3	3	3		9579-0003-00	Buntband.....	Cable holder.....		
22	1	1	1		9699-0060-02	Planbricka.....	Flat washer.....		
26	1	1	1		1134-2962-01	Solenoid kpl.....	Solenoid assy.....		
27	2	2	2		9794-5131-02	• Mutter.....	• Nut .....		
28	1	1	1		1134-0234-02	Batterikabel ( + ).....	Battery cable ( + ).....		L = 395 mm
29	1	1	1		1134-2310-01	Batteriskydd.....	Guard cap .....		
30	1	1	1		1134-4702-02	Kabel- röd.....	Cable- red.....		L = 480 mm
32		1	1		1134-6308-01	Kablage.....	Harness.....		
32	1				1134-7218-01	Kablage.....	Harness.....		
32A	1	1	1		1134-3496-06	• Säkring.....	• Fuse .....		20A
39		1			1134-6348-01	Kablage.....	Harness.....		
39			1		1134-6442-01	Kablage.....	Harness.....		
41		1	1		1134-4093-01	Tändningslås.....	Ignition switch .....		
42		1	1		1134-4749-01	Mutter.....	Nut .....		
43			1		1134-7535-01	Honkontakt.....	Female terminal.....		
45			1		1134-4052-01	Stödbricka.....	Support washer.....		
46			2		9840-7716-16	Skruv.....	Screw.....		
48			1		9400-0282-01	Brytare m.diod.....	Switch w.diode.....		
49			1		9400-0280-03	Vippa- höjinställning.....	Cover- height adjust.....		









Utgåva Issue 2009- 11		Bildnr Picture No 2519		VILLA MOTOR (GGP)		VILLA ENGINE (GGP)		Sida Page 294	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2725								
3	4				9955-3725-16 Skruv.....	Screw.....		3/8" x 25	
5	1				1134-6626-01 Bränsletank.....	Fuel tank .....			
6	1				1134-5532-01 Tanklock .....	Fuel tank cap.....			
7	1				1134-3224-01 Bränslekran .....	Fuel shut-off valve.....			
8	1				1134-3225-01 Gummibussning .....	Grommet.....			
9	1				1134-2975-18 Bensinslang .....	Fuel line.....		L = 260 mm	
10	2				9578-0023-02 Slangklämma.....	Hose clamp .....			
12	1				1134-4808-01 Tankbygel .....	Tank clamp.....			
13	1				9699-0060-02 Bricka .....	Washer.....			
14	1				9747-0631-02 Mutter.....	Nut.....			
15	1				1134-4807-02 Tank/batterihylla .....	Tank/battery shelf.....			
16	4				9829-8830-12 Skruv.....	Screw.....			
19	2				1134-0433-00 Ljuddämparpackning.....	Muffler gasket.....			
22	4				1134-4930-01 Skruv.....	Screw.....			
23	1				1134-6623-01 Ljuddämpare .....	Muffler .....			
24	1				1134-6634-01 Grenrör.....	Exhaust pipe .....			
25	2				9893-0616-16 Skruv.....	Screw.....			
26	1				1134-6699-01 Värmskydd.....	Heat guard .....			
27	4				9893-0616-16 Skruv.....	Screw.....			
99	1				1134-9500-01 Motor kpl.....	Engine assy.....		GGP WM 12,5	





Utgåva Issue 2009- 11		Bildnr Picture No 2200A		VILLA MOTOR (B&S)		VILLA ENGINE (B&S)		Sida Page 296	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717 2718	2719							
1	1	1		9997-0840-16	Skruv.....	Screw.....		M8 x 40	
2	1	1		9747-0831-02	Mutter.....	Lock nut.....			
3	3	3		9955-3725-16	Skruv.....	Screw.....		3/8" x 25	
5	1	1		1134-6626-01	Bränsletank.....	Fuel tank.....			
6	1	1		1134-5532-01	Tanklock.....	Fuel tank cap.....			
7	1	1		1134-3224-01	Bensinkran.....	Fuel shut-off valve.....			
8	1	1		1134-3225-01	Gummibussning.....	Grommet.....			
9	1	1		1134-2975-05	Bensinslang.....	Fuel hose.....		L = 460 mm	
10	2	2		9578-0023-02	Slangklämma.....	Hose clamp.....			
12	1	1		1134-4808-01	Tankbygel.....	Tank clamp.....			
13	1	1		9699-0060-02	Planbricka.....	Flat washer.....			
14	1	1		9747-0631-02	Låsmutter.....	Lock nut.....			
15	1	1		1134-4807-02	Tank/batterihylla.....	Tank/battery shelf.....			
16	4	4		9829-8830-12	Skruv.....	Screw.....			
19	1	1		1134-0433-00	Ljuddämparpackning.....	Muffler gasket.....			
22	2	2		1134-4930-01	Skruv.....	Screw.....			
23A	1			1134-7781-01	Ljuddämpare.....	Muffler.....			
23B		1		1134-7744-01	Ljuddämpare.....	Muffler.....			
25	2	2		9893-0616-16	Skruv.....	Screw.....			
26	1	1		1134-6699-01	Värmeskydd.....	Heat guard.....			
27	4	4		9893-0616-16	Skruv.....	Screw.....			



Utgåva Issue		Bildnr Picture No		VILLA TRANSMISSION		VILLA TRANSMISSION		Sida Page	
2009- 11		1643B						298	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2717								
1	1				1134-4611-01	Motorremskiva .....	Engine belt pulley .....		
4	1				1134-6637-01	Remstyrning .....	Belt guide .....		
5	1				9699-0056-02	Planbricka .....	Flat washer .....		
6	1				1134-4519-01	Spännarm .....	Tension arm .....		
7	1				1134-9091-01	Spännrulle .....	Tension roller .....		
8	1				1134-4614-01	Ansats .....	Shoulder spacer .....		
9	1				9997-1040-16	Skruv .....	Screw .....		
10	1				9699-0035-02	Planbricka .....	Flat washer .....		
11	1				9739-1031-22	Mutter .....	Nut .....		
12	1				1134-9027-02	Spännrulle- grå .....	Tension roller- grey .....		
13	1				1134-1795-01	Rembygel .....	Belt stirrup .....		
14	1				9997-1040-16	Skruv .....	Screw .....		
15	2				9699-0035-02	Planbricka .....	Flat washer .....		
16	1				9739-1031-22	Mutter .....	Nut .....		
17	1				1134-9065-01	Drivrem .....	Drive belt .....	= 9585-0124-01	
18	1				1134-1565-08	Distans .....	Spacer .....		
19	1				9997-0870-16	Skruv .....	Screw .....		
20	2				9699-0056-02	Planbricka .....	Flat washer .....		
21	1				9739-0831-22	Mutter .....	Nut .....		
22	1				1134-5214-01	Fjäder .....	Spring .....		
23	1				1134-6338-01	Transaxel kpl. ....	Transaxle assy .....		Dana 6800-7
24	4				9960-0860-12	Skruv .....	Screw .....		
25	4				9747-0831-02	Mutter .....	Lock nut .....		
26	1				1134-4687-01	Momentstag .....	Strut .....		
27	1				9945-0816-16	Skruv .....	Screw .....		
28	1				1134-1849-01	Remskiva .....	Belt pulley .....		
30	1				9650-0016-04	Spårring .....	Lock ring .....		
31	1				1134-4707-01	Remstyrning .....	Belt guide .....		
32	1				9942-0820-16	Skruv .....	Screw .....		
41	1				1134-2138-01	Skruvögla .....	Eye bolt .....		
42	1				1134-4779-01	Plastbussning .....	Plastic bushing .....		
43	1				9739-0831-22	Mutter .....	Nut .....		
44	1				9747-0831-02	Mutter .....	Lock nut .....		



Utgåva Issue		Bildnr Picture No		VILLA HST TRANSMISSION		VILLA HST TRANSMISSION		Sida Page	
2009- 11		1157G						300	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2718	2719	2727						
1	1				1134-4611-01	Motorremskiva .....	Engine belt pulley .....		
4	1				1134-6637-01	Remstyrning .....	Belt guide .....		
5	1				9699-0056-02	Planbricka .....	Flat washer .....		
6	1				1134-4519-01	Spännarm .....	Tension arm .....		
7	1				1134-9091-01	Spännrulle .....	Tension roller .....		
8	1				1134-4614-01	Ansats .....	Shoulder spacer .....		
9	1				9997-1040-16	Skruv .....	Screw .....		
10	1				9699-0035-02	Planbricka .....	Flat washer .....		
11	1				9739-1031-22	Mutter .....	Nut .....		
12	1				1134-9027-02	Spännrulle- grå .....	Tension roller- grey .....		
13	1				1134-1795-01	Rembygel .....	Belt stirrup .....		
14	1				9997-1040-16	Skruv .....	Screw .....		
15	2				9699-0035-02	Planbricka .....	Flat washer .....		
16	1				9739-1031-22	Mutter .....	Nut .....		
17	1				1134-9064-01	Drivrem .....	Drive belt .....		= 9585- 0099- 01
18	1				1134-1565-08	Distans .....	Spacer .....		
19	1				9997-0870-16	Skruv .....	Screw .....		
20	2				9699-0056-02	Planbricka .....	Flat washer .....		
21	1				9739-0831-22	Mutter .....	Nut .....		
22	1				1134-5214-01	Fjäder .....	Spring .....		
23	1				1134-7766-01	Transaxel kpl. ....	Transaxle assy .....		Kanzaki K46CJ
24	4				9960-0860-12	Skruv .....	Screw .....		
25	4				9747-0831-02	Mutter .....	Lock nut .....		
26	1				1134-6290-01	Momentstag .....	Strut .....		
27	1				9945-0816-16	Skruv .....	Screw .....		
28	1				9997-0840-16	Skruv .....	Screw .....		
29	1				9747-0831-02	Mutter .....	Lock nut .....		
42	1				1134-5156-01	Dragstång .....	Pull rod .....		
43	1				1134-4014-01	Plastknopp .....	Plastic button .....		
44	1				9675-0009-02	Starlock .....	Starlock .....		
51	1				1134-2138-01	Skruvögla .....	Eye bolt .....		
52	1				1134-4779-01	Plastbussning .....	Plastic bushing .....		
53	1				9739-0831-22	Mutter .....	Nut .....		
54	1				9747-0831-02	Mutter .....	Lock nut .....		
55	1				1134-5319-01	Remstyrning .....	Belt guide .....		
56	1				9699-0056-02	Planbricka .....	Flat washer .....		





Utgåva Issue		Bildnr Picture No		VILLA HJUL		VILLA WHEELS		Sida Page	
2009- 11		1646B						302	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2717 2718 2719	2725 2727							
1	1	1		1134-6703-01	Bakaxel .....	Rear axle .....			
2	2	2		9501-0500-00	Smörjnippel .....	Grease joint .....			
3	1	1		1134-5009-02	Spindel- vä .....	Spindle- LH .....			
4	1	1		1134-5009-01	Spindel- hö .....	Spindle- RH .....			
5	2	2		9699-0088-02	Planbricka .....	Flat washer .....			
6	2	2		9650-0020-04	Spårring .....	Circlip .....			
7	1	1		1134-5316-01	Styrskiva .....	Steering pulley .....			
8	1	1		1134-5575-01	Distans .....	Spacer .....			
9	1	1		1134-9024-01	Lager .....	Bearing .....	Sats 4 st/kit of 4		
10	1	1		9699-0104-02	Bricka .....	Washer .....			
11	1	1		9997-1680-12	Skruv .....	Screw .....			
12	2	2		1134-3247-05	Styrstag .....	Tie rod .....			
13A	2	2		9997-0825-16	Skruv .....	Screw .....	L = 25 mm		
13B	1	1		9997-0835-12	Skruv .....	Screw .....	L = 35 mm		
14	2	2		9699-0090-02	Planbricka .....	Flat washer .....			
15	3	3		9747-0831-02	Mutter .....	Lock nut .....			
16	2	2		1134-4706-01	Fälg .....	Rim .....			
17	1	1		1134-9026-01	Lagerbussning .....	Bearing bush kit .....	Sats 4 st/kit of 4		
18	2	2		9545-0117-00	Däck .....	Tyre .....	13 x 5.00 - 6		
19	2	2		9545-0500-00	Ventil .....	Valve .....			
20	2	2		1134-0341-01	Bricka .....	Washer .....			
21	2	2		9650-0020-04	Spårring .....	Circlip .....			
22	2	2		1134-4344-01	Navkapsel .....	Hub cap .....			
25	1	1		9501-0500-00	Smörjnippel .....	Grease joint .....			
26	1	1		9699-0088-02	Planbricka .....	Flat washer .....			
27	1	1		9650-0020-04	Spårring .....	Circlip .....			
28	2	2		1134-5255-01	Fälg .....	Rim .....			
29	2	2		9545-0126-01	Däck .....	Tyre .....	16 x 6.00 - 8		
30	2	2		9545-0500-00	Ventil .....	Valve .....			
32	6	6		9731-1031-22	Mutter .....	Nut .....			
33	2	2		1134-2471-03	Kil .....	Key .....			
34	2	2		9653-0001-04	Spårryttare .....	Lock ring .....			
35	2	2		1134-0341-01	Bricka .....	Washer .....			
36	2	2		1134-4844-02	Hjulnav .....	Wheel hub .....			
37	2	2		1134-4845-02	Navhylsa .....	Hub sleeve .....			
38	2	2		1134-4981-01	Bricka .....	Washer .....			
50	2	2		1134-6274-01	Redskapsfäste kpl. ....	Attachment assy .....			
51	1	1		1134-9026-01	• Lagerbussning .....	• Bearing bush kit .....	Sats 4 st/kit of 4		
52	1	1		9501-0502-00	• Smörjnippel .....	• Grease joint .....			
98				9545-0204-00	Innerslang .....	Inner tube .....	Reservdel/spare part		
99				9545-0203-00	Innerslang .....	Inner tube .....	Reservdel/spare part		

