















Genuine Spare Parts






Utgåva Issue 2010- 11		Bildnr Picture No 2309B		PRIMO MONTERINGSDETALJER		PRIMO ASSEMBLY PARTS		Sida Page 210	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				9595-0262-00	Spännstift	Locating pin		
2	1				9699-0103-02	Shims	Flat washer		0.5 mm
3	1				9699-0114-02	Shims	Flat washer		1.0 mm
4	1				1134-4734-01	Tändningsnyckel.....	Ignition key		
5	1				1134-6125-01	Tändningsnyckel.....	Ignition key		
6	1				1134-6113-01	Batteriskruvar	Battery screws		
7	4				9959-0820-16	Skruv.....	Screw.....		
21	1				8211-0027-90	Bruksanvisning	Owner's manual		
21	1				8211-0701-91	Säkerhetsföreskrifter	Safety regulations		


99




Utgåva Issue 2010-11		Bildnr Picture No 2311B		PRIMO KAROSS CHASSI		PRIMO BODY WORK CHASSIS		Sida Page 212	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2411 -13	2411 -33							
1	1			1134-6711-01	Motorhuv- gul	Engine hood- yellow			
1		1		1134-6711-03	Motorhuv- svart	Engine hood- black			
2	1	1		1134-6712-01	Motorlucka	Engine cover			
3	1	1		1134-6583-01	Fäste	Bracket			
5	1	1		1134-6584-01	Fäste	Bracket			
6	6	6		9838-8822-19	Skruv	Screw			
7	2	2		9959-0620-16	Skruv	Screw			
8	2	2		1134-5114-01	Distans	Spacer			
9	2	2		9747-0631-02	Låsmutter	Lock nut			
10	1			1134-6708-01	Frontkåpa- gul	Front cover- yellow			
10		1		1134-6708-03	Frontkåpa- svart	Front cover- black			
11	2	2		9838-8822-19	Skruv	Screw			
12	1	1		1134-6581-04	PTO kåpa- svart	PTO cover- black			
13	4	4		9838-8822-19	Skruv	Screw			
31	1	1		1137-0022-01	Chassi	Chassis			
98	1	1		1137-0076-01	Dekalsats	Label kit			
99	1	1		1134-7498-01	Rep.sats- gängor	Rep.kit- threads			




Utgåva Issue		Bildnr Picture No		PRIMO SITS		PRIMO SEAT		Sida Page	
2010- 11		2310B						214	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				1134-7837-01	Brytarhållare	Switch bracket		
2	2				9838-8822-19	Skruv	Screw		
3	1				1134-3134-01	Gummifjäder.....	Rubber spring		
4	1				9959-0820-16	Skruv.....	Screw.....		
5	1				9699-0056-02	Planbricka.....	Flat washer.....		
6	1				1134-5302-01	Fjäder.....	Spring		
7	1				9747-0831-02	Mutter.....	Lock nut		
10	2				9838-8822-19	Skruv	Screw		
11	2				9699-0056-02	Planbricka.....	Flat washer.....		
20	1				1134-7834-01	Sitsplatta	Seat plate		
22	1				1134-7873-01	Sits	Seat.....		



Utgåva Issue		Bildnr Picture No		PRIMO AGGREGATSLYFT		PRIMO MOWER DECK LIFT		Sida Page	
2010- 11		2316						216	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				1134-7727-01	Lyftpedal.....	Lift pedal.....		Sats 2 st/kit of 2
2	2				1134-6527-01	Överfall.....	Clamp.....		
3	5				9838-8822-19	Skruv.....	Screw.....		
4	1				4231-0013-00	Fjäder.....	Spring.....		
5	1				1134-0041-01	Linhjulshylsa.....	Bushing.....		
6	1				1134-9025-01	Linhjul- sats.....	Steering pulley- kit.....		
7	1				1134-0046-00	Linhållare.....	Wire clamp.....		
8	1				9997-1040-16	Skruv.....	Screw.....		
9	1				9739-1031-22	Mutter.....	Nut.....		
10	1				1134-6565-01	Lyftwire.....	Lift wire.....		
11	1				9675-0012-02	Starlock.....	Locking washer.....		
12	1				1134-6536-01	Fjäder.....	Spring.....		
20	1				1134-6526-01	Pedalspär.....	Pedal catch.....		
21	1				1131-1497-01	Fjäder.....	Spring.....		
22	1				1134-6552-01	Spärrknopp.....	Catch button.....		










Utgåva Issue 2010-11		Bildnr Picture No 2312A		PRIMO STYRNING		PRIMO STEERING		Sida Page 218	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				1134-6562-01	Styrplåt	Steering plate		
2	2				9959-0825-16	Skruv	Screw		
3	2				9739-0831-22	Mutter	Nut		
4	4				9838-8822-19	Skruv	Screw		
5	1				1134-6551-01	Rattstång	Steering column		
6	2				1134-1901-01	Lager	Bearing		
7	1				1134-9138-01	Styrwire	Steering cable		STIGA förp/package
8	1				1134-3817-01	Tryckfjäder	Compression spring		
10	1				9747-0831-02	Mutter	Lock nut		
11	4				1134-0041-01	Linhjulshylsa	Bushing		
12	2				1134-9025-01	Linhjul-sats	Steering pulley-kit		Sats 2 st/kit of 2 M10x40
13	4				9997-1040-16	Skruv	Screw		
14	4				9699-0035-02	Planbricka	Flat washer		
15	4				9739-1031-22	Mutter	Nut		
16	1				1134-6490-01	Linhjulsstag- hö	Bracket- RH		
17	1				1134-6491-01	Linhjulsstag- vä	Bracket- LH		
18	2				9838-8822-19	Skruv	Screw		
19	2				9945-0816-16	Skruv	Screw		
20	1				1134-5496-02	Ratt	Steering wheel		
99	1				1134-7498-01	Rep.sats- gängor	Rep.kit- threads		





Utgåva Issue		Bildnr Picture No		PRIMO REGLAGE		PRIMO CONTROLS		Sida Page	
2010- 11		2317A						220	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				1134-6483-01	Växelspak	Gear shift lever		
2	1				9997-0860-16	Skruv	Screw		
3	1				1134-6554-01	Distans	Spacer		
4	1				9699-0056-02	Planbricka	Flat washer		
5	1				1134-4079-01	Fjäder	Spring		
6	1				9695-0011-00	Bricka	Washer		
7	1				9739-0831-22	Mutter	Nut		
8	1				1134-6486-01	Växelstag	Gear shift rod		
9	2				9675-0012-02	Starlock	Locking washer		
10	1				1134-6482-01	Växelförararm	Gear shift arm		
11	1				9699-0060-02	Planbricka	Flat washer		
12	1				9987-5016-16	Skruv	Screw		
13	1				1134-2551-01	Reglageknopp	Knob		
14	1				1134-6558-01	Aggregatsspak	Deck engagement lever		
15	1				9699-0109-02	Planbricka	Flat washer		
16	1				1134-7713-01	Dragfjäder	Spring		
17	1				1134-2551-01	Reglageknopp	Knob		
18	1				1134-7754-01	Stag	Rod		
19	1				1134-4231-01	Dragfjäder	Spring		
20	1				1134-6526-01	Pedalspär	Pedal catch		
21	1				1131-1497-01	Fjäder	Spring		
22	1				1134-6552-01	Spärrknopp	Catch button		
31	1				1134-6528-01	Kopplingspedal	Clutch pedal		
32	2				1134-6527-01	Överfall	Clamp		
33	5				9838-8822-19	Skruv	Screw		
34	1				4231-0013-00	Fjäder	Spring		
35	1				1134-7729-01	Kopplingsstag	Clutch rod		
36	1				9598-0002-02	Låsnål	Pin lock		
37	1				1134-2138-01	Skruvögla	Eye bolt		
38	1				1134-4779-01	Plastbussning	Plastic bushing		
39	1				9699-0035-02	Planbricka	Flat washer		
40	1				9739-0831-22	Mutter	Nut		
41	1				9747-0831-02	Mutter	Lock nut		
42	1				1134-6666-01	Stag	Rod		
43	1				1134-1242-02	Fjäder	Spring		
44	1				9675-0015-02	Starlock	Lock washer		
45	1				1131-1497-01	Fjäder	Spring		

Ref. bild/drawing 2309B




Ref. bild/drawing 2309B










Utgåva Issue 2010-11		Bildnr Picture No 2318A		PRIMO ELSYSTEM		PRIMO ELECTRIC SYSTEM		Sida Page 222	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				1134-6677-01	Batteri	Battery		16 Ah
3	1				1134-6498-01	Kablage	Cable harness		
3A	1				1134-3496-06	• Säkring	• Fuse		20 A
4	1				9739-0631-22	Mutter	Nut		
5	1				1134-2310-01	Batteriskydd	Guard cap		
6	1				1134-2962-01	Solenoid kpl	Solenoid assy		
7	2				9794-5131-02	• Mutter	• Nut		
8	1				9838-8822-19	Skruv	Screw		
9	1				9699-0056-02	Planbricka	Flat washer		
10	1				9400-0360-01	Mikrobrytare	Micro switch		
11	1				1134-2871-03	Relä	Relay		
12	1				9838-8822-19	Skruv	Screw		
13	1				1134-4702-01	Kabel- röd	Cable- red		
14	1				1134-3156-02	Brytare (grå)	Switch (grey)		
15	6				9579-0003-00	Buntband	Cable holder		
16	1				1134-4093-01	Tändningslås	Ignition switch		
17	1				1134-4749-01	Mutter	Nut		
20	1				1134-7381-01	Brytare- neutralläge	Switch- neutral		


X






Utgåva Issue		Bildnr Picture No		PRIMO MOTOR		PRIMO ENGINE		Sida Page	
2010-11		2315						224	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				118550439/0 Motor kpl.....	Engine assy.....		GGP WM12	
2	4				1134-6582-01 Bussning.....	Bushing.....			
3	4				9699-0105-02 Bricka.....	Washer.....			
4	4				9955-3738-16 Skruv.....	Screw.....			
5	1				1134-6495-01 Remskiva.....	Belt pulley.....			
6	1				9600-0251-01 Kil.....	Key.....			
7	1				1134-5017-01 Bricka.....	Washer.....			
8	1				9987-5332-16 Skruv.....	Screw.....			
11	1				1134-6568-01 Bränsletank.....	Fuel tank.....			
12	1				1134-5532-01 Tanklock.....	Fuel tank cap.....			
X 13	0,46				9505-0001-01 Bensinslang (meter).....	Fuel line (metre).....		Per meter	
14	2				9578-0023-02 Slangklämma.....	Hose clamp.....			
15	1				1134-7048-01 Fäste.....	Bracket.....			
16	1				9838-8822-19 Skruv.....	Screw.....			
21	1				1134-6719-01 Ljuddämpare.....	Muffler.....			
22	1				1134-0433-00 Ljuddämparpackning.....	Muffler gasket.....			
23	2				1134-4930-01 Skruv.....	Screw.....			
31	1				1134-7122-01 Gasreglage.....	Throttle control.....			
32	1				1134-1597-14 Gaswire.....	Throttle cable.....			
33	1				1134-7284-01 Knopp.....	Knob.....			
34	1				1134-0240-00 Ansatsskruv.....	Shoulder screw.....			
35	1				9694-0001-00 Fjäderbricka.....	Washer.....			
37	1				9747-0831-02 Mutter.....	Lock nut.....			
38	1				9500-9991-00 Wireklämma.....	Cable clamp.....			
39	1				9838-9516-12 Skruv.....	Screw.....			
40	1				9579-0003-00 Buntband.....	Cable holder.....			






Utgåva Issue		Bildnr Picture No		PRIMO TRANSMISSION	PRIMO TRANSMISSION	Sida Page			
2010- 11		2319A				226			
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
6	4			9699-0090-02	Planbricka.....	Flat washer.....			
7	4			9997-0814-02	Skruv.....	Screw.....			M8 x 140
8	1			1134-6717-01	Växellåda kpl.....	Gearbox assy.....			
8A	1			9600-0050-00	Woodruffkil.....	Key.....			
9	1			1134-7381-01	• Brytare- neutralläge.....	• Switch- neutral.....			
10	1			1134-7382-01	• Bromsbelägg.....	• Brake pad.....			Sats 2 st/kit of 2
11	1			1134-6652-01	Kedjedrev.....	Chain wheel.....			
12	1			9651-0016-04	Spärring.....	Lock ring.....			
13	1			1134-6494-01	Remskiva.....	Belt pulley.....			
14	1			9650-0016-04	Spärring.....	Lock ring.....			
15	1			1134-6481-01	Växellådsplåt.....	Gearbox plate.....			
16	4			9945-0816-16	Skruv.....	Screw.....			
17	4			9897-0850-12	Skruv.....	Screw.....			
18	4			9739-0831-22	Mutter.....	Nut.....			
19	1			1134-6564-01	Neutralstopp.....	Neutral stop.....			
20	2			9893-0616-16	Skruv.....	Screw.....			
21	1			1134-6487-01	Infästningskonsol.....	Console.....			
22	4			9945-0816-16	Skruv.....	Screw.....			
23	1			9958-0820-16	Skruv.....	Screw.....			
24	1			1134-6505-01	Kopplingsarm.....	Clutch lever.....			
25	1			1134-7829-01	Skruv.....	Screw.....			
27	1			1134-1565-06	Distans.....	Spacer.....			
28	1			1134-9134-01	Kilrem.....	V- belt.....			= 9585-0174-01
29	1			1134-9027-02	Spännrulle- grå.....	Tension roller- grey.....			Sats 1 st/kit of 1
30	1			9924-1035-16	Skruv.....	Screw.....			
31	1			9739-1031-22	Mutter.....	Nut.....			
32	1			1134-6692-01	Fjäder.....	Spring.....			
40	1			1134-7760-01	Bakaxel kpl.....	Rear axle assy.....			Inkl. pos 42 - 55
42	1			1134-6667-01	• Kedjedrev.....	• Chain wheel.....			
43	1			1134-7771-01	• Kedja.....	• Chain.....			
44	1			1134-7843-01	• Kedjestreckare.....	• Chain tensioner assy.....			Inkl. pos 45 - 51
45	1			1134-3820-01	•• Kedjehjul.....	•• Sprocket.....			
46	1			1134-7827-01	•• Distans.....	•• Spacer.....			
47	1			9930-1045-16	•• Skruv.....	•• Screw.....			
48	1			9699-0030-02	•• Planbricka.....	•• Flat washer.....			
49	1			9739-1031-22	•• Mutter.....	•• Nut.....			
50	1			9865-0860-16	•• Skruv.....	•• Screw.....			
51	1			9739-0831-22	•• Mutter.....	•• Nut.....			
52	1			1134-6660-01	• Wirefäste.....	• Wire bracket.....			
53	2			1134-3247-06	• Styrstag.....	• Tie rod.....			
54	1			1134-7826-01	• Stag.....	• Steering stay.....			
55	1			1134-7759-01	• Tvärstag.....	• Cross bar.....			
X 99	1			1134-9142-01	Drivaxeldamask.....	Drive shaft rubber.....			Ej ill/not ill.




Utgåva Issue		Bildnr Picture No		PRIMO HJUL		PRIMO WHEELS		Sida Page	
2010-11		2314B						228	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				1134-7787-01 Framaxel	Vorderachse			
2	1				1134-6527-01 Överfall	Clamp			
3	2				9838-8822-19 Skruv	Screw			
4	1				1134-6569-01 Framaxelfjäder	Wheel axle spring			
5	2				1134-7244-01 Framhjul kpl	Front wheel assy			
5A	1				1134-9140-01 • Hjulbussning	• Wheel bushing			Sats 2 st/Kit of 2 Ej ill/not ill.
5B	1				9545-0500-00 • Ventil	• Valve			
6	2				1134-7243-01 Bakhjul kpl	Rear wheel assy			Ej ill/not ill.
6B	1				9545-0500-00 • Ventil	• Valve			
7	4				9997-1020-16 Skruv	Screw			
8	4				1134-5406-01 Bricka	Washer			
11	4				1134-6510-01 Navkapsel	Hub cap			
20	2				9945-0816-16 Skruv	Screw			



Utgåva Issue		Bildnr Picture No		PRIMO KRAFTUTTAG	PRIMO POWER TAKE-OFF	Sida Page			
2010-11		2313B				230			
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				1134-6496-01 Remskiva.....	Belt pulley			
2	1				1134-7803-01 Remstyrning.....	Belt guide			
3	1				1134-6617-01 Mellanremskiva kpl.....	Intermediate pulley			
4	2				9549-0019-00 • Kullager	• Ball bearing			
6	1				1134-6519-01 Axel	Shaft			
7	1				1134-5548-01 Distans	Spacer.....			
8	1				1134-7745-01 Skruv.....	Screw.....			M8 x 130
10	1				1134-6567-01 Stagplåt	Support plate			
11	4				9838-8822-19 Skruv.....	Screw.....			
12	1				1134-6501-01 Kopplingsarm	Clutch lever			
13	1				1134-1565-17 Distans	Spacer.....			
14	1				9997-0811-02 Skruv	Screw.....			
15	1				9699-0056-02 Planbricka.....	Flat washer.....			
16	1				9747-0831-02 Mutter.....	Lock nut.....			
17	1				1134-9135-01 Kilrem.....	V- belt.....			= 9585-0188-01
18	1				1134-6516-01 Spännrulle	Tension roller			
19	1				1134-6548-01 Ansats	Spacer.....			
20	1				9997-1040-16 Skruv.....	Screw.....			
22	1				9799-1031-02 Mutter.....	Nut.....			
23	1				1134-6497-01 Bromsarm	Brake lever			
24	1				1134-4164-04 Bromsklots.....	Brake pad.....			
25	1				9897-0825-16 Skruv.....	Screw.....			
26	1				9747-0831-02 Mutter.....	Lock nut.....			
27	2				9699-0056-02 Planbricka.....	Flat washer.....			
28	1				9997-0840-16 Skruv.....	Screw.....			
29	1				1134-1565-06 Distans	Spacer.....			
30	1				1134-6500-01 Bromsstång.....	Brake rod			
31	1				1134-4170-01 Nippel	Nipple.....			
32	1				9747-0631-02 Låsmutter	Lock nut.....			
33	1				9675-0008-02 Starlock	Locking washer.....			
34	1				1134-1770-01 Spännrulle	Tension roller			
35	1				1134-1888-04 Distans	Spacer.....			
36	1				9997-0855-12 Skruv.....	Screw.....			
37	1				9699-0056-02 Planbricka.....	Flat washer.....			
38	1				9739-0831-22 Mutter.....	Nut.....			
39	1				1134-6492-01 Spännarm.....	Tension lever.....			
40	1				1134-7867-01 Fjäder.....	Spring			
41	1				1134-5713-03 Fjäder.....	Spring			
42	1				1134-7865-01 Flänshylsa.....	Flange sleeve.....			
43	1				1137-0021-01 Gånginsats.....	Thread insert.....			



Utgåva Issue 2010-11		Bildnr Picture No 2307		PRIMO KLIPPAGGREGAT RAM		PRIMO MOWER DECK FRAME		Sida Page 232	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2411 -13 -33								
1	1				1134-7383-01 Klippaggregat kpl.....	Mower deck assy		Gul/yellow	
2	1				1134-6587-01 Flytfäste- vä	Holder- LH.....			
3	1				1134-6587-02 Flytfäste- hö	Holder- RH			
4	4				9959-0820-16 Skruv.....	Screw.....			
5	4				9739-0831-22 Mutter.....	Nut			
6	1				1134-6591-01 Lyftöra	Lift loop.....			
7	2				9959-0820-16 Skruv.....	Screw.....			
8	2				9739-0831-22 Mutter.....	Nut			
9	1				1134-6598-01 Infästningsram	Mounting frame			
10	2				1134-0240-00 Ansatsskruv.....	Shoulder screw			
11	2				9747-0831-02 Mutter.....	Lock nut			
21	1				1134-6735-01 Frontrör kpl.....	Front tube assy			
22	2				1134-9139-01 • Stödhjulssats	• Support wheel kit		Inkl. pos 22	
23	1				1134-9024-01 •• Lager	•• Bearing		Inkl. pos 23, 24	
24	1				9650-0020-04 •• Spårring.....	•• Circlip		Sats 4 st/kit of 4	
25	1				1134-6594-01 Konsol- vä.....	Bracket- LH			
26	1				1134-6594-02 Konsol- hö	Bracket- RH			
27	4				9959-0820-16 Skruv.....	Screw.....			
28	4				9739-0831-22 Mutter.....	Nut			
29	2				1134-0240-00 Ansatsskruv.....	Shoulder screw			
30	2				9747-0831-02 Mutter.....	Lock nut			
31	1				1134-6599-01 Stag	Strut			
32	1				1134-6600-01 Stag	Strut			
33	4				9675-0015-02 Starlock	Lock washer			
34	1				1134-6755-01 Nivåkonsol.....	Level bracket assy.....			
36	2				9959-0820-16 Skruv.....	Screw.....			
37	2				9739-0831-22 Mutter.....	Nut			
38	1				1111-2816-01 Spak	Height adj.lever			
39	1				1111-2817-01 Handtag	Lever knob			
40	2				9893-0616-16 Skruv.....	Screw.....			



Utgåva Issue 2010-11		Bildnr Picture No 2308B		PRIMO KLIPPAGGREGAT TRANSMISSION KNIVAR		PRIMO MOWER DECK TRANSMISSION BLADES		Sida Page 234	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	2411 -13	2411 -33							
1	2	2		1134-6613-01	Lagerbox kpl.....	Bearing box assy.....			
2	8	8		9945-0825-16	Skruv.....	Screw.....			
3	1	1		1134-9129-01	Knivbalk kpl.....	Blade bar assy.....		Sats 2 st/kit of 2	
4	1	1		1134-9130-01	• Knivsats kpl.....	• Blade kit.....			
5	1	1		1134-9054-01	•• Brytbultsats.....	•• Shear bolt kit.....			
6	2	2		1134-6311-01	•• Bult.....	•• Bolt.....			
7	2	2		1134-6312-01	•• Låsmutter.....	•• Lock nut.....			
8	2	2		1134-6211-01	Knivbricka.....	Blade washer.....			
9	2	2		9997-1050-12	Skruv.....	Screw.....			
10	1	1		1134-6590-01	Combiplugg.....	Mulch plug.....			
11	1	1		9959-0820-16	Skruv.....	Screw.....			
12	4	4		1134-0341-01	Bricka.....	Washer.....			
13	1	1		9739-0831-22	Mutter.....	Nut.....			
21	1			1134-6713-01	Transm.kåpa- gul.....	Transm. cover-yellow.....			
21		1		1134-6713-03	Transm.kåpa- svart.....	Transm. cover-black.....			
22	1	1		1134-0240-00	Ansatssskruv.....	Shoulder screw.....			
23	1	1		9739-0831-22	Mutter.....	Nut.....			
24	3	3		9893-0616-16	Skruv.....	Screw.....			
25	1	1		1134-9137-01	Kuggremskiva kpl.....	Toothed belt pulley.....		Sats 2 st/kit of 2	
26	1	1		1134-6607-01	Remskiva.....	Belt pulley.....			
27	1	1		9600-0168-01	Kil.....	Key.....			
28	1	1		1134-5124-02	Distans.....	Spacer.....			
29	2	2		1134-5406-01	Bricka.....	Washer.....			
30	2	2		9997-0850-16	Skruv.....	Screw.....			
31	1	1		1134-9133-01	Kuggrem.....	Timing belt.....		= 9585-0173-01	
32	1	1		1134-9136-01	Kilrem.....	V- belt.....		= 9585-0176-01	
33	1	1		1134-7017-01	Remstyrning.....	Belt guide.....			
34	2	2		9959-0820-16	Skruv.....	Screw.....			
35	2	2		9739-0831-22	Mutter.....	Nut.....			
37	4	4		9699-0056-02	Planbricka.....	Flat washer.....			