



Reservdelskatalog Parts Catalogue

Park 320 M



2F6120520/S15 - Season 2015

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
 - The contents described in the parts list may change due to improvement.
 - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
 - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


© Copyright 2014 Global Garden Products

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


www.stiga.com




Utgåva Issue 50 - 2014		Pedallyft Pedal lift			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4117-01	Fäste	Bracket	
2	2	1134-2684-01	Lager	Bearing	
3	1	1134-4945-01	Lyftspärr kpl	Lift Catch Assy	Pos 7-13 incl.
7	1	9404-0027-01	O-ring	O-ring	
8	1	9650-0039-04	Sparring Sga 8	Lock Ring	
9	1	9595-0276-01	Spiralspännstift 8*24	Locating Pin	
10	1	112689500/0	Skruv	Screw	
11	1	112154510/0	Mutter	Nut	
13	1	9897-0820-16	Skruv	Screw	
14	1	112155000/0	Mutter	Nut	
15	1	1134-4860-01	Lyftgaffel	Lift Fork	
16	2	1134-0240-00	Skruv	Screw	
17	1	1134-4938-01	Lyftpedal	Lift Pedal	
18	2	112791500/0	Skruv	Screw	
19	2	9739-0631-22	Mutter	Nut	
20	1	4231-0013-00	Fjäder	Spring	




Utgåva Issue 50 - 2014		PTO			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5548-01	Distans	Spacer	
2	1	1137-1124-01	Spännhjulsarm	Tension Wheel Arm	
3	1	1137-0128-01	Spännhjul Kpl	Tension Roller Assy	
4	1	1134-1888-04	Distans	Spacer	
5	1	1134-5111-01	Fjäder	Spring	
6	1	112523060/0	Bricka	Washer	
7	1	112154220/0	Mutter	Nut	
8	1	112691600/0	Skruv	Screw	
10	1	1137-0209-01	Centrumremskiva Smst Remskiva	Centre Belt Pulley Belt Pulley	
11	1	1134-0051-09	Distans	Spacer	
12	2	9549-0019-00	Kullager	Ball Bearing	
13	1	1134-5112-01	Fjäder	Spring	
14	2	9945-0816-16	Skruv	Screw	
15	1	1134-5110-02	Hake	Hook	
16	2	9893-0616-16	Skruv Relä	Screw Relay	
18	1	1134-2018-02	Spännarm Kpl	Tension Arm	
19	1	1134-9027-01	Spännrulle (Svart)	Tension Roller (Black)	
20	1	1134-9071-01	Kilrem Drivrem	V-Belt Belt	contain belt 9585-0129-01
21	1	112794300/0	Skruv	Screw	
22	1	112295200/0	Mutter	Nut	
23	1	387318251/0	Bromsarm Kpl	Brake Arm	
24	1	1134-4164-03	Bromsklots	Brake Pad	
25	1	112818700/0	Skruv	Screw	
26	1	112155000/0	Mutter	Nut	
27	1	137033100/0	Bromsstang	Brake Rod	
28	1	9675-0008-02	Starlockbricka	Starlock	
29	1	1134-4170-01	Nippel	Nippel	
30	1	112521330/0	Bricka	Washer	
31	1	112154510/0	Mutter	Nut	
32	1	4231-0013-00	Fjäder	Spring	
33	1	1135-3307-01	Fjäder	Spring	
34	1	1134-1565-10	Distans	Spacer	
35	1	112691800/0	Skruv	Screw	
36	1	112523060/0	Bricka	Washer	
37	1	112154220/0	Mutter	Nut	
38	1	1134-4163-01	Ansattsskruv	Shoulder Bolt	
39	1	9747-1031-02	Mutter Lasmutter	Nut	
40	1	1134-3958-01	Remstyrning	Belt Guide	
41	2	9893-0616-16	Skruv Relä	Screw Relay	
42	1	1134-0041-03	Bussning	Bushing	
43	1	112794950/0	Skruv	Screw	
44	1	9739-1031-22	Mutter	Nut	
45	1	1134-3654-01	Fingerskydd 5-01 24	Guard	
46	2	9959-0612-16	Skruv	Screw	
47	2	9739-0631-22	Mutter	Nut	
48	1	9699-0090-02	Bricka	Washer	
49	2	112521360/0	Bricka	Washer	
50	1	112521360/0	Bricka	Washer	




Utgåva Issue 50 - 2014		PTO			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
51	2	337546547/0	Plat	Plate	
52	1	112793102/0	Skruv	Screw	
53	1	112293201/0	Mutter	Nut	
54	2	325160039/0	Distans	Spacer	
55	1	122041980/0	Bussning	Bushing	
56	1	337600000/0	Skydd	Protection	
57	1	112523060/0	Bricka	Washer	




Utgåva Issue 50 - 2014		Hjul Wheels			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	1134-0075-01	Framaxeltapp	Front Axle	
2	2	9595-0258-00	Spännstift	Locating Pin	
3	2	1134-4844-05	Hjulnav Kpl	Wheel Hub Assy	
4	1	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
5	1	1134-9026-01	Bussning	Bearing	Sats 4 st/kit of 4
6	2	187000454/0	Fälg	Rim Rimm	
7	2	9545-0116-00	Däck	Tyre	16 x 7.50 - 8
8	2	9545-0500-00	Ventil	Valve Assy.	
9	6	9731-1031-22	Mutter	Nut	
10	8	1134-0341-01	Bricka	Washer	
11	2	9599-0080-02	SaxSprint Sp 4*28	Cotter Pin	
12	2	1134-4844-02	Hjulnav Kpl	Wheel Hub Assy	
13	2	187000454/0	Fälg	Rim Rimm	
14	2	9545-0116-00	Däck	Tyre	16 x 7.50 - 8
15	2	9545-0500-00	Ventil	Valve Assy.	
16	6	9731-1031-22	Mutter	Nut	
18	2	1134-4796-01	Navkapsel	Hub Cap	
19	2	9947-0540-19	Skruv	Screw	
20	2	1134-2471-01	Kil	Key	
21	2	9699-0042-02	Bricka	Washer	
22	2	9653-0001-04	Sparryttare Rs	Lock Ring	
26	2	9699-0042-02	Bricka	Washer	
45	1	13-0992-61	Rac Snabbfäste 2Wd Park	Rac Quick Connection 2Wd	Inkl. pos 11,26,46-51
46	1	1134-7465-01	Sats-Fästen (Vä+Hö Inkl Skruv)	Attachment Kit	Inkl. pos 50-51
47	2	1137-0077-01	Säkerhetssprint Lassprint	Safety Pin Locking Pin	
48	2	9548-0026-01	Glidlager 20E7X26-20	Bearing	
50	2	9898-1035-16	Skruv	Screw	
51	2	9739-1031-22	Mutter	Nut	
99	1	9545-0203-00	Innerslang	Inner Tube	Reservdel/spare part




Utgåva Issue 50 - 2014		Monteringsdetaljer Assembly parts			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
2	1	1134-6113-01	Skruv	Screw	
4	2	9595-0262-00	Spännstift	Locating Pin Elastic Pin	
5	1	9699-0103-02	Bricka	Washer	0.5 mm
11	1	9699-0114-02	Bricka	Washer	1.0 mm
6	2	1134-4185-01	Ansatsbricka	Flange Washer	
7	2	9959-0820-16	Skruv	Screw	
8	2	1134-4481-01	Vingmutter	Wing Nut	
9	4	112523060/0	Bricka	Washer	
10	2	1134-4734-01	Tändningsnyckel	Ignition Key	
12	2	112793102/0	Skruv	Screw	
13	1	1134-5512-01	Dragplat Dragplat5-01	Towing Plate	
14	2	9959-0820-16	Skruv	Screw	
15	2	112154220/0	Mutter	Nut	
18	2	9898-1035-16	Skruv	Screw	
19	2	9739-1031-22	Mutter	Nut	




Utgåva Issue 50 - 2014		Sits	Seat		
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
2	1	1134-6444-01	Sits (Xb 150) Stiga	Seat	
3	1	1134-5301-01	Sitsplatta	Upper Seat Bracket	
4	2	1134-0240-00	Skruv	Screw	
5	2	112155000/0	Mutter	Nut	
6	1	1134-5454-01	Spärr	Catch	
7	1	112604899/0	Starlock	Crown Fastener	
10	4	9893-0616-16	Skruv Relä	Screw Relay	
11	1	1134-5300-01	Bakstycke Gul	Rear Plate, Yellow	
12	1	1134-5296-04	Sitskonsol Kpl (Gul) 1-00	Seat Bracket (Yellow)	
13	1	1134-4256-01	Fjäder	Spring	
14	1	9924-1235-19	Skruv	Screw	
15	1	112156603/0	Mutter	Nut	
16	1	112691115/0	Skruv	Screw	
17	1	1134-1565-06	Distans	Spacer	
18	1	1134-5302-01	Fjäder	Spring	
19	1	1134-5299-01	Tryckplatta	Push Plate	
20	1	9699-0090-02	Bricka	Washer	
21	1	112155000/0	Mutter	Nut	
22	1	1134-3156-02	Brytare (gra)	Switch	
26	2	9897-0880-12	Skruv	Screw	L = 80 mm
27	2	1134-1565-08	Distans	Spacer	
28	4	9897-0820-16	Skruv	Screw	L = 20 mm
29	6	112155000/0	Mutter	Nut	




Utgåva Issue 50 - 2014		Kaross Body work			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5263-02	Motorhuv Gul	Engine Hood Yellow	Yellow
2	7	9838-9530-12	Skruv	Screw	
3	1	1134-9028-01	Gummistropp (3 St)	Rubber Strap (3 Pcs)	Sats 3 st/kit of 3
4	1	9632-0516-00	Popnit 9.5	Pop Rivet	
5	1	9699-0120-02	Bricka	Washer	
6	1	1134-5264-01	Motorlucka (Gra) 7-14	Engine Cover (Grey) 7-14	Grey
7	1	1134-5308-01	Skärm-Vä (Gra) 7-14	Mudguard-Lh (Grey) 7-14	Grey
8	1	1134-5308-02	Skärm-Hö (Gra) 7-14	Mudguard-Rh (Grey) 7-14	Grey
9	4	9893-0616-16	Skruv Relä	Screw Relay	
10	4	1134-4176-01	Clips	Clips	
11	2	1134-0225-00	Stödplat	Support Plate	
12	6	9945-0816-16	Skruv	Screw	
13	4	112523060/0	Bricka	Washer	
14	1	1134-5306-01	Stötfangare Front-Vä Grå	Bumper Front-Lh (Grey)	Grey
15	1	337502505/0	Stötfangare Front-Hö Gra	Bumper Front-Rh (Grey)	
16	2	9893-0616-16	Skruv Relä	Screw Relay	
18	1	1134-5305-01	Front Nedre Gul	Lower Hood Yellow	Grey
19	2	9893-0616-16	Skruv Relä	Screw Relay	
20	1	1134-5320-05	Front-Övre (Gul) 1-00	Front-Upper Part (Yellow)	
21	2	9946-0525-16	Skruv	Screw	
22	1	1134-6241-01	Huvstöd (Svart) 5-01	Hood Support	
23	3	9893-0616-16	Skruv Relä	Screw Relay	
24	1	1134-3970-05	Kantlist-Vä (Gra) 7-14	Moulding-Left (Grey)	
25	1	1134-3970-02	Kantlist-Hö (Gra) 7-14	Moulding Right-Grey	
26	2	9893-0616-16	Skruv Relä	Screw Relay	
27	2	9699-0060-02	Bricka	Washer	
28	2	112154510/0	Mutter	Nut	
29	2	112815200/0	Skruv	Screw	





Utgåva Issue 50 - 2014		Styrning Steering			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6374-06	Kedja	Chain	83 Links
2	1	1134-9084-01	Styrwire	Steering Wire	Sats vö+h÷/kit L+R
4	2	1134-2824-02	Kedjelas Fz	Chain Lock	
5	2	1134-3817-01	Fjäder	Spring	L = 58 mm
6	2	9699-0090-02	Bricka	Washer	
7	2	112155000/0	Mutter	Nut	
8	4	1134-2816-01	Kedjehjul	Sprocket	
9	4	1134-0041-02	Bussning	Bushing	
10	4	112521360/0	Bricka	Washer	
11	2	9997-1050-16	Skruv	Screw	
12	2	9897-1040-12	Skruv	Screw	
13	4	9739-1031-22	Mutter	Nut	
14	2	1134-9025-01	Linhjul	Steering Pulley	Sats 2 st/kit of 2
15	2	1134-0041-01	Bussning	Bushing	
16	2	1134-0046-00	Wireklämma	Wire Clamp	
17	2	9997-1030-16	Skruv	Screw	
18	2	9739-1031-22	Mutter	Nut	
19	1	1134-5349-01	Styrkonsol Kpl (Gul) 1-00	Steering Console (Yellow) 1-00	
20	4	9897-0820-16	Skruv	Screw	
21	4	112154220/0	Mutter	Nut	
22	1	1134-1305-05	Rattrör Nedre	Steering Column, Lower	
23	2	1134-1901-01	Lager	Bearing	
24	2	9893-0616-16	Skruv Relä	Screw Relay	
25	1	1137-0079-02	Rattstang Kpl	Steering Rod Assy	
26	1	1134-2837-01	Distans	Spacer	
52	1	337961200/0	Ratt	Steering wheel	
53	1	337580550/0	Styrplåt Kpl Styrplat Kpl	Steering Plate	
54	1	112793102/0	Skruv	Screw	
55	1	112583500/0	Lasbricka	Grower	
56	1	112620299/0	Spännstift	Elastic Pin	
57	1	1137-0080-01	Styrstag	Steering Stay	








Utgåva Issue 50 - 2014		Transmission		Tranmssion	
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4000-02	Spännarm Kpl 15	Tension Arm	
2	1	1134-3459-01	Remskiva Spännrulle	Belt Pulley Tension Roller	
3	1	9924-1035-16	Skruv	Screw	
4	1	112295200/0	Mutter	Nut	
5	1	1134-9058-01	Drivrem Kilrem	Drive Belt V-Belt	9585-0091-01
6	1	112791500/0	Skruv	Screw	
7	1	9739-0631-22	Mutter	Nut	
37	1	112154510/0	Mutter	Nut	
8	1	1134-3377-02	Reglagestang	Control Rod	
9	1	4231-0013-00	Fjäder	Spring	
10	1	1134-4171-01	Ledtapp	Pivot Pin	
11	1	1134-4183-01	Fjäder	Spring	
12	2	1134-3456-01	Bussning	Bushing	
13	1	112154510/0	Mutter	Nut	
14	1	1134-1565-08	Distans	Spacer	
15	1	112793905/0	Skruv	Screw	
16	1	112523060/0	Bricka	Washer	
17	1	112155000/0	Mutter	Nut	
18	1	1134-6414-01	Fjäder	Spring	
19	1	9699-0060-02	Bricka	Washer	
20	1	1137-0123-01	Transaxel K46Ci	Transaxle K46Ci	Kanzaki K46Ci
21	4	9960-0860-12	Skruv	Screw	
22	4	112155000/0	Mutter	Nut	
23	1	1134-3913-01	Reaktionsstag 5-01 F24	Strut	
24	1	9959-0825-16	Skruv	Screw	
25	1	112691200/0	Skruv	Screw	
26	1	112523060/0	Bricka	Washer	
27	2	112155000/0	Mutter	Nut	
28	1	112154510/0	Mutter	Nut	
29	1	1134-2765-02	Oljetank	Oil Tank	
30	1	1134-2777-02	Tanklock	Filler Cap	
31	1	1134-3734-01	Plugg (Service)	Vent Plug	
32	1	1134-2778-01	Fästband5-01	Band	
33	2	9852-8013-16	Skruv	Screw	
34	2	9699-0099-02	Bricka	Washer	
35	2	9578-0036-01	Slangklämma	Hose Clamp	
36	1	1134-2779-07	Rör	Tube	L = 140 mm
36	1	1134-2779-12	Rör Slang	Tube	L = 205 mm
40	1	1134-4015-01	Dragstang	Pull Rod	
41	1	1134-4014-01	Plastknopp	Knob	
42	1	1134-4713-01	Vinkelfäste	Angle Bracket	
43	1	1134-2790-01	Kabelgenomföring	Cable Protection	
44	1	9959-0820-16	Skruv	Screw	
45	1	112154220/0	Mutter	Nut	
46	1	9675-0009-02	Starlockbricka	Starlock	
51	1	1134-3289-02	Remstyrning	Belt Guide	
52	1	9959-0820-16	Skruv	Screw	
53	1	112523060/0	Bricka	Washer	
54	1	112154220/0	Mutter	Nut	




Utgåva Issue 50 - 2014		Ram	Frame		
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	387800011/0	Ram-Främre Kpl	Frame Front	Inkl. pos 2-5
2	1	1137-1119-02	Midjegaffel Service	Fork	
3	1	1134-0031-00	Ledaxelstopp Ledaxelstopp	Pivot Shaft Stop	
4	1	9595-0262-00	Spännstift	Locating Pin Elastic Pin	
5	1	112379511/0	Smörjnippel	Grease Dispenser	Rak/straight
6	1	9501-0504-01	Smörjnippel	Grease Nipple M6 90	90°
7	1	1134-6466-01	Ram-Bakre Kpl (5-01)	Frame-Rear Assy	
8	1	1134-5705-01	Distans	Spacer	
9	2	9547-0001-00	Ledlager Ge17Es	Bearing	
10	2	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
11	1	1134-5988-01	Centrumaxel	Centre Shaft	
12	1	1134-2171-01	Fjäder	Spring	
13	2	9699-0035-02	Bricka	Washer	
14	2	9959-1025-16	Skruv	Screw	
16	1	1134-6586-01	Durk (5-01)	Floor Plate	
17	1	1134-6372-04	Durkmatta	Floor Mat Hst	
18	2	9893-0616-16	Skruv Relä	Screw Relay	
19	2	9403-0048-70	Täckpropp Ikpt 13-6,5S	Cover Plug	
20	2	9945-0816-16	Skruv	Screw	
21	2	9959-0820-16	Skruv	Screw	
22	2	112154220/0	Mutter	Nut	
28	1	1134-4975-01	Gummibuffert	Rubber Buffer	
29	1	9950-0570-12	Skruv	Screw	
30	2	9739-0531-22	Mutter	Nut	
31	1	1134-5337-02	Stötfangare-bakre, grå	Bumper Assy-Rear Grey	
32	2	1134-0240-00	Skruv	Screw	
33	2	1134-4242-01	Bricka Distansbricka	Washer	
34	2	9665-0002-00	Bricka	Washer	
35	2	112155000/0	Mutter	Nut	
36	2	9943-0516-16	Skruv	Screw	
37	2	1134-5345-01	Batterihallare	Battery Holder	
38	1	1134-5344-01	Batterihylla	Battery Shelf	
39	4	9945-0816-16	Skruv	Screw	
40	1	337600013/0	Bakstycke	Rear Cover	




Utgåva Issue 50 - 2014		Handreglage Hand controls			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6301-01	Aggregatsspak5-01	Engage Lever	
2	1	1134-2551-01	Knopp	Knob	
3	1	1134-3790-02	Lager	Bearing	
4	1	9699-0090-02	Bricka	Washer	
5	1	4231-0013-00	Fjäder	Spring	
6	1	1134-5368-01	Panel	Dashboard	
7	1	9400-0312-01	Mikrobrytare	Microswitch	
8	4	9946-0525-16	Skruv	Screw	
9	1	1134-3573-05	Reglagewire	Control Cable	
20	1	1134-5465-01	Gasreglage	Throttle Control Lever	
21	1	1134-4078-01	Knopp	Knob	
22	1	1134-5464-01	Fäste	Bracket	
23	1	1134-0240-00	Skruv	Screw	
24	2	1134-4242-01	Bricka Distansbricka	Washer	
25	1	9694-0001-00	Bricka	Washer	
26	1	112155000/0	Mutter	Nut	
27	1	1134-4197-03	Gasreglage	Throttle Cable	
28	1	9500-9991-00	Kabelklämma	Wire Clamp	
29	1	9943-0516-16	Skruv	Screw	




Utgåva Issue 50 - 2014		Elsystem Electric system			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4804-01	Batteri	Battery	
2	1	187040308/0	Kablage	Harness	Inkl. Pos 3, 4
3	1	9400-0327-01	Säkringshallare Inkl 20A Säkring	Fuse Holder Incl Fuse	Inkl. pos 4
4	1	1134-3496-06	Säkring 20A Säkring (20A)	Fuse 20 A Fuse (20A)	20A
6	1	1134-3901-01	Solenoid	Solenoid	Inkl. pos 8
7	2	9852-8013-16	Skruv	Screw	
8	2	9743-5121-32	Mutter	Nut	
9	1	1134-4093-01	Tändningslas	Ignition Switch	
10	1	1134-4749-01	Mutter	Nut	
11	1	1134-5245-01	Batterirem	Battery Strap	
12	1	1134-2167-01	Elkabel	Cable	
12	1	1134-2167-02	Kabel (Minus)	Cable (-)	
13	1	1134-0234-02	Batterikabel (+)	Battery Cable (+)	
14	1	1134-2310-01	Batteriskydd	Guard Cap (+)	
15	1	112361005/0	Mutter	Nut	1/4" UNC
16	15	133320027/0	Bunband	Cable	
17	1	1134-5343-01	Batterikonsole	Battery Bracket	
18	3	9852-8013-16	Skruv	Screw	
19	2	9699-0060-02	Bricka	Washer	
25	1	1134-3399-02	Brytare	Switch	
26	2	112789008/0	Skruv	Screw	
27	2	112154330/0	Mutter	Nut	
34	1	9959-0612-16	Skruv	Screw	
35	1	1134-6454-01	Jordplat	Ground Plate	
36	1	9739-0631-22	Mutter	Nut	
40	1	1137-0075-01	Plat Fäste	Plate Attachment 2010	
41	2	112735105/0	Skruv	Screw	
42	1	1134-7535-01	Anslutning Honkontakt	Connector Female Connector	
43	1	9959-0820-16	Skruv	Screw	
44	1	112154220/0	Mutter	Nut	
45	1	9400-0282-01	Brytare (Med Diod)	Switch	
46	1	9400-0280-03	Vippa Höjdinst	Switch Cover-Height Adjust	




Utgåva Issue 50 - 2014		Motor	Engine		
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	4	9955-3725-16	Skruv	Screw	3/8" UNC x 25 mm
3	1	1134-7784-01	Ljuddämpare Kpl	Muffler Assy	
4	1	1134-0433-00	Packning	Gasket	
5	2	1134-4930-01	Skruv	Screw	
6	1	9959-0820-16	Skruv	Screw	
7	1	112154220/0	Mutter	Nut	
8	1	1134-5390-01	Dragkroksbalk	Tow Bar Bracket	
9	4	9945-0816-16	Skruv	Screw	
14	1	1137-0208-01	Motorremskiva Motorremskiva	Engine Pulley	Ø 137 mm
15	1	1137-0206-01	Motorremskiva Remskiva	Engine Belt Pulley Engine Pulley	Ø 85 mm
16	1	9600-0251-01	Kil	Key	L = 2 1/2"
17	1	1134-5017-01	Bricka	Washer	
18	1	9987-5332-16	Skruv	Screw	
19	1	1134-6618-01	Bränsletank	Fuel Tank	
20	1	1134-5532-01	Tanklock	Fuel Tank Cap	
21	1	1134-3224-01	Bensinkran	Fuel Shut-Off Valve	
22	1	1134-3225-01	Gummibussning Gummibussning	Grommet	
23	1	1134-2975-01	Bensinslang	Fuel Tube	L = 520 mm
23	1	1134-2975-07	Bensinslang	Fuel Tube	L = 350 mm
24	1	9578-0023-02	Slangklämma D12*8 (Svart) Rörklammer	Hose Clamp Tube Clamp	
25	1	1134-6627-01	Tankfäste	Fuel Tank Bracket	
26	2	9959-0820-16	Skruv	Screw	
27	2	112154220/0	Mutter	Nut	
28	2	1134-5346-01	Tankbygel	Fuel Tank Loop	
29	2	112154510/0	Mutter	Nut	
30	1	133320027/0	Bunband	Cable	
40	1	9578-0023-02	Slangklämma D12*8 (Svart) Rörklammer	Hose Clamp Tube Clamp	
41	1	1134-5827-01	Oljeavtappning Kpl	Oil Drain Assy	Pos 42-45 incl.
42	1	1134-5825-01	Nippel	Nipple	
43	1	9578-0023-04	Slangklämma 15*8 (Vit) Kabelhal- lare	Hose Clamp Clamp	
44	1	1134-3499-02	Slangklämma	Hose Clamp	
45	1	1134-5826-01	Plugg	Plug	




Utgåva Issue 50 - 2014		Fotreglage		Foot controls	
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5655-01	Kopplingspedal Kpl	Clutch Pedal	
2	1	1134-9024-01	Lager (4 St)	Bearing	Sats 4 st/kit of 4
3	1	1134-5677-02	Distans	Spacer	
4	1	9997-1070-12	Skruv	Screw	
5	1	9699-0030-02	Bricka	Washer	
6	1	9739-1031-22	Mutter	Nut	
7	1	1134-6005-01	Reglagewire	Control Cable	
8	1	4231-0013-00	Fjäder	Spring	
9	1	1134-3906-01	Vajerfäste 24	Cabel Holder	
9	1	1134-6467-01	Wirefäste	Cable Holder	
10	2	9959-0820-16	Skruv	Screw	
11	1	112154220/0	Mutter	Nut	
12	1	112155000/0	Mutter	Nut	
13	1	1134-6353-01	Drivpedal	Drive Pedal	
14	2	1134-6313-01	Lager	Bearing	
15	2	1134-2700-01	Fäste	Bracket	
16	2	9959-0820-16	Skruv	Screw	
17	2	112154220/0	Mutter	Nut	
18	1	9997-0835-16	Skruv	Screw	
19	1	112154220/0	Mutter	Nut	
22	1	1134-2766-05	Reglagevajer	Speed Control Cable	
23	2	9570-0001-00	Vinkellänk As8 Din 71802M5 Länk	Elbow Link Joint	
24	2	9739-0531-22	Mutter	Nut	
25	2	112154330/0	Mutter	Nut	
26	1	1134-6317-01	Wirefäste	Wire Bracket	
28	2	9959-0620-16	Skruv	Screw	
29	2	9739-0631-22	Mutter	Nut	
30	1	1134-3395-01	Fäste 24 (5-01)	Attachment	
31	2	9959-0820-16	Skruv	Screw	
32	2	112154220/0	Mutter	Nut	
33	1	1134-2021-01	Växelwirefäste	Clamp	
34	1	1134-5353-01	Bromsstang	Brake Rod	
35	1	1134-2786-01	Knopp	Knob	
36	1	1131-1497-01	Fjäder	Brake Spring	
37	1	1134-4002-01	Fäste	Brake Rod Attachment	
38	3	112728697/0	Skruv	Screw	



Utgåva Issue 50 - 2014		Remskydd Protection, Belt			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	112154510/0	Mutter	Nut	
2	1	337600010/0	Skydd	Protection	
3	1	337600011/0	Skydd	Protection	
4	1	112792099/0	Skruv	Screw	
5	1	9893-0616-16	Skruv Relä	Screw Relay	
6	1	337600015/0	Remskydd	Belt Cover	
7	2	112735669/0	Skruv	Screw	
8	2	112523050/0	Bricka	Washer	
9	2	1134-1565-14	Distans	Spacer	
10	2	112154510/0	Mutter	Nut	
11	1	337060001/1	Remskydd	Belt Cover	
12	2	112792099/0	Skruv	Screw	
13	2	112524010/0	Bricka	Washer	
14	1	337785100/0	Fäste	Support	
15	2	112521330/0	Bricka	Washer	
16	2	112154510/0	Mutter	Nut	
18	1	112791500/0	Skruv	Screw	
19	1	112154510/0	Mutter	Nut	
20	1	337060000/1	Remskydd	Belt Cover	
21	1	337060002/0	Remskydd Skydd	Belt Cover Protection Cover	
22	1	9893-0616-16	Skruv Relä	Screw Relay	
23	1	9945-0816-16	Skruv	Screw	
24	1	137294100/0	Remstyrning	Belt Guide	
25	2	9893-0616-16	Skruv Relä	Screw Relay	
26	1	112523050/0	Bricka	Washer	
30	1	112791500/0	Skruv	Screw	
31	1	337060003/0	Remskydd	Belt Cover	
33	1	322545159/0	Plat	Plate	
35	1	112154510/0	Mutter	Nut	



Utgåva Issue 50 - 2014		Transmission			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-7766-01	Transaxel K46 Cj	Transaxle K46Cj	Kanzaki K46CJ
2	1	1139-1485-01	Övre Hus	Upper Case Kit	
3	1	1139-1402-01	Hus-Nedre	Case-Lower	
7	1	1139-1595-01	Ventil	Vent Valve	
8	2	1139-1150-01	Magnet	Magnet	
10	1	1139-1499-01	Pumpaxel Kpl	Pump Shaft Kit	
11	1	1139-1347-01	Fjäder	Spring	
12	1	1139-1324-01	Axel Bypass	Shaft Bypass	
13	1	1139-1189-01	Arm	By-Pass Lever	
14	1	1139-1161-01	Lasring	Ring	
15	1	1139-1275-01	Plugg	Bore Plug	
16	1	1139-1104-01	Lasring	Snap Ring	
17	2	1139-1103-01	Bricka	Washer	
18	2	1139-1500-01	Dräneringsbult-Sats	Drain Bolt Kit	
19	2	1139-1117-01	O-Ring	O-Ring	
20	1	1139-1119-01	Tätning	Seal 15*35*7	
21	2	1139-1295-01	Skruv	Screw	
22	14	1139-0244-01	Skruv	Screw	
24	1	1139-1599-01	Centrumhus	Center Case	
25	1	1139-1158-01	Stift	Pin	
26	1	1139-1405-01	Filter	Filter	
27	3	1139-1718-01	Bult	Bolt	
28	2	1139-1468-01	Ventil	Ids Valve	
29	2	1139-1243-01	Fjäder	Spring	
30	2	1139-1307-01	Filter	Filter	
31	1	1139-1601-01	Cylinderblock (Pump)	Cylinder Block Kit (Pump)	
32	1	1139-1245-01	Fjäder	Pump Spring	
33	1	1139-1406-01	Pumpaxel	Pump Shaft	
34	3	1139-1146-01	Lasring	Ring	
35	1	1139-1110-01	Kullager	Ball Bearing	
36	1	1139-1157-01	Hus	Housing	
37	1	1139-1501-01	Lager	Bearing	
38	1	1139-1717-01	Cylinderblock (Motor)	Cylinder Block (Motor)	
39	1	1139-1160-01	Bricka	Washer	
40	1	1139-1353-01	Motoraxel	Motor Shaft	
41	1	1139-1021-01	Lasring	Snap Ring	
42	1	1139-1272-01	Motordrev	Motor Gear	
43	1	1139-1453-01	Lager	Bearing	
44	2	1139-1066-01	Tryckplatta	Use 1139-1141-01	
45	1	1139-1597-01	Stänkplatta	Swash Plate	
46	1	1139-1508-01	Lager	Thrust Bearing Kit	
47	1	1139-1598-01	Magnethallare	Magnet Holder	
49	1	1139-1354-01	Regleraxel	Control Shaft	
50	1	1139-1410-01	Vridcentrum	Fulcrum	
51	1	1139-1312-01	Vridfjäder	Torsion Spring	
52	1	1139-1409-01	Reglerarm	Lever	
53	1	1139-1325-01	Reglerarm	Control Lever	
54	1	1139-1596-01	Ryckplatta	Jerky Plate	
55	1	1139-1102-01	Bricka	Washer	



Utgåva Issue 50 - 2014		Transmission		Transmission	
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
56	1	1139-1355-01	LasSprint	Cotter Pin	
57	1	1139-1329-01	Stift	Pin	
58	1	1139-1285-01	Stift	Pin	
59	2	1139-1115-01	O-Ring	O-Ring	
60	1	1139-1127-01	Mutter	Nut	
61	1	1139-1404-01	Differentialdrev Kpl	Diff.Gear Kit	
62	1	1139-1258-01	Slutdrev	Final Gear	
63	1	1139-1255-01	Hylsa	Collar	
64	1	1139-1256-01	röduktionsaxel	Reduction Shaft	
65	2	1139-1398-01	Bricka	Washer	
66	1	1139-1267-01	Reduktionsdrev	Reduction Gear	
67	1	1139-1361-01	Slutdrev	Final Pinion Gear	
68	1	1139-1342-01	Hjulaxel-Vä	Axle Shaft-L	
69	1	1139-1343-01	Hjulaxel-Hö	Axle Shaft-R	
70	2	1139-1078-01	Bricka	Thrust Washer	
71	2	1139-1163-01	Lasring	Ring	
72	2	1139-1080-01	Tätning	Seal 19*32*8	
73	2	1139-1164-01	Bussning	Bushing	
74	2	1139-1414-01	Bussning	Bushing	
75	1	1139-1260-01	Bromssko	Brake Shoe	
76	1	1139-1261-01	Bromsarm	Brake Arm	
77	1	1139-1320-01	Bromsaxel	Brake Shaft	
78	1	1139-1411-01	Returfjäder	Return Spring	
79	1	1139-1264-01	Tryckplatta	Brake Actuator	
80	1	1139-1282-01	Stift	Pin	
81	2	1139-1114-01	O-Ring	O-Ring	
82	2	1139-1281-01	Stift	Pin	
84	1	1139-1484-01	Remskiva	Belt Pulley	
85	1	1134-4190-01	Fläkt	Fan	
86	1	1139-1266-01	Bricka	Washer	
87	1	1139-1149-01	Lasring	Snap Ring	
90	1	1139-1280-01	Stift	Pin	
91	1	1139-1303-01	Tätningring	Seal Ring	
95	1	1139-1279-01	Stift	Pin	
99	1	1139-1443-01	Tätningmedel	Sealant (Tube)	
200	1	1139-1403-01	Packningssats	Seal Kit	Märkta S/Marked S
201	1	1139-1600-01	Reparationssats	Repair Kit	Märkta R/Marked R

code	pos.	q.ty	page				
112154220/0	7	1	p. 5	112691115/0	16	1	p. 13
112154220/0	7	1	p. 27	112691200/0	25	1	p. 19
112154220/0	11	1	p. 29	112691600/0	8	1	p. 5
112154220/0	15	2	p. 11	112691800/0	35	1	p. 5
112154220/0	17	2	p. 29	112728697/0	38	3	p. 29
112154220/0	19	1	p. 29	112735105/0	41	2	p. 25
112154220/0	21	4	p. 17	112735669/0	7	2	p. 31
112154220/0	22	2	p. 21	112789008/0	26	2	p. 25
112154220/0	27	2	p. 27	112791500/0	6	1	p. 19
112154220/0	32	2	p. 29	112791500/0	18	1	p. 31
112154220/0	37	1	p. 5	112791500/0	18	2	p. 3
112154220/0	44	1	p. 25	112791500/0	30	1	p. 31
112154220/0	45	1	p. 19	112792099/0	4	1	p. 31
112154220/0	54	1	p. 19	112792099/0	12	2	p. 31
112154330/0	25	2	p. 29	112793102/0	12	2	p. 11
112154330/0	27	2	p. 25	112793102/0	52	1	p. 7
112154510/0	1	1	p. 31	112793102/0	54	1	p. 17
112154510/0	10	2	p. 31	112793905/0	15	1	p. 19
112154510/0	11	1	p. 3	112794300/0	21	1	p. 5
112154510/0	13	1	p. 19	112794950/0	43	1	p. 5
112154510/0	16	2	p. 31	112815200/0	29	2	p. 15
112154510/0	19	1	p. 31	112818700/0	25	1	p. 5
112154510/0	28	1	p. 19	122041980/0	55	1	p. 7
112154510/0	28	2	p. 15	133320027/0	16	15	p. 25
112154510/0	29	2	p. 27	133320027/0	30	1	p. 27
112154510/0	31	1	p. 5	137033100/0	27	1	p. 5
112154510/0	35	1	p. 31	137294100/0	24	1	p. 31
112154510/0	37	1	p. 19	187000454/0	6	2	p. 9
112155000/0	5	2	p. 13	187000454/0	13	2	p. 9
112155000/0	7	2	p. 17	187040308/0	2	1	p. 25
112155000/0	12	1	p. 29	322545159/0	33	1	p. 31
112155000/0	14	1	p. 3	325160039/0	54	2	p. 7
112155000/0	17	1	p. 19	337060000/1	20	1	p. 31
112155000/0	21	1	p. 13	337060001/1	11	1	p. 31
112155000/0	22	4	p. 19	337060002/0	21	1	p. 31
112155000/0	26	1	p. 5	337060003/0	31	1	p. 31
112155000/0	26	1	p. 23	337502505/0	15	1	p. 15
112155000/0	27	2	p. 19	337546547/0	51	2	p. 7
112155000/0	29	6	p. 13	337580550/0	53	1	p. 17
112155000/0	35	2	p. 21	337600000/0	56	1	p. 7
112156603/0	15	1	p. 13	337600010/0	2	1	p. 31
112293201/0	53	1	p. 7	337600011/0	3	1	p. 31
112295200/0	4	1	p. 19	337600013/0	40	1	p. 21
112295200/0	22	1	p. 5	337600015/0	6	1	p. 31
112361005/0	15	1	p. 25	337785100/0	14	1	p. 31
112379511/0	5	1	p. 21	337961200/0	52	1	p. 17
112521330/0	15	2	p. 31	387318251/0	23	1	p. 5
112521330/0	30	1	p. 5	387800011/0	1	1	p. 21
112521360/0	10	4	p. 17				
112521360/0	49	2	p. 5				
112521360/0	50	1	p. 5				
112523050/0	8	2	p. 31				
112523050/0	26	1	p. 31				
112523060/0	6	1	p. 5				
112523060/0	9	4	p. 11				
112523060/0	13	4	p. 15				
112523060/0	16	1	p. 19				
112523060/0	26	1	p. 19				
112523060/0	36	1	p. 5				
112523060/0	53	1	p. 19				
112523060/0	57	1	p. 7				
112524010/0	13	2	p. 31				
112583500/0	55	1	p. 17				
112604899/0	7	1	p. 13				
112620299/0	56	1	p. 17				
112689500/0	10	1	p. 3				