



Reservdelskatalog Parts Catalogue

Park 520 L (ISO)


13-6311-32 - Season 2014

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
 - The contents described in the parts list may change due to improvement.
 - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
 - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.





© Copyright 2014 Global Garden Products

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


www.stiga.com




Utgåva Issue 43 - 2014		Monteringsdetaljer Assembly parts			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
4	2	9595-0262-00	Spännstift	Locating Pin	
5	1	9699-0103-02	Bricka	Washer	0.5 mm
5	1	9699-0114-02	Bricka	Washer	1.0 mm
11	2	118210027/0	Kil	Key	
13	1	1134-5512-01	Dragplåt5-01	Towing Plate	
14	2	9959-0820-16	Skruv	Screw	
15	2	9739-0831-22	Mutter	Nut	
17	1	1134-6113-02	Skruv	Screw	
18	2	9898-1035-16	Skruv	Screw	
19	2	9739-1031-22	Mutter	Nut	
31					as PDF






Utgåva Issue 43 - 2014		Kaross Body work			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0048-01	Framskärm-Vä	Mud Guard, Front-Lh	
2	1	1137-0048-02	Framskärm-Hö	Mud Guard, Front-Rh	
3	2	9893-0616-16	Relä Skruv	Relay Screw	
4	2	1134-4176-01	Clips	Clips	
5	2	9699-0060-02	Bricka	Washer	
6	2	9747-0631-02	Mutter Låsmutter	Nut	
7	2	1137-0088-01	Stödplåt	Support Plate	
8	6	9945-0816-16	Skruv	Screw	
9	4	9699-0056-02	Bricka	Washer	
10	1	1137-0049-01	Stötfångare-Fram	Front Bumper	
11	6	9893-0616-16	Relä Skruv	Relay Screw	
12	2	1134-4176-01	Clips	Clips	
17	1	1134-4360-01	Kåpa-Inre (1-00)	Cover-Inner	
18	1	1134-3979-01	Kåpa Yttre1-00	Cover-Outer	
19	3	9946-0525-16	Skruv	Screw	
20	2	9950-0570-12	Skruv	Screw	
21	2	9747-0531-02	Mutter	Nut	
23	4	9893-0616-16	Relä Skruv	Relay Screw	
25	1	1134-3970-05	Kantlist-Vä (Grå) 7-14	Moulding-Left (Grey)	
26	1	1134-3970-02	Kantlist-Hö (Grå) 7-14	Moulding Right-Grey	
27	4	9893-0616-16	Relä Skruv	Relay Screw	
28	2	9840-8013-16	Skruv	Screw	
29	2	9897-0616-16	Skruv	Screw	
31	1	1134-6461-01	Bakstycke 1-00	Rear Plate	
40	1	1137-0050-01	Frontkåpa-Nedre	Front Panel-Lower	
41	2	9838-9516-12	Skruv	Screw	
42	1	1137-0051-01	Frontkåpa-Övre	Front Panel-Upper	
43	2	9946-0525-16	Skruv	Screw	
44	1	1137-0052-01	Lamphållare	Lamp Holder	
45	1	1137-0053-01	Toppkåpa	Top Panel	
46	2	9838-9516-12	Skruv	Screw	
47	1	1137-0054-01	Lampglas	Lamp Glass	




Utgåva Issue 43 - 2014		Kaross Body work			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6025-01	Motorhuv(1-00)	Engine Hood	
2	4	9893-0616-16	Relä Skruv	Relay Screw	
3	1	1134-9028-01	Gummistropp (3 St)	Rubber Strap (3 Pcs)	Sats 3 st/kit of 3
4	1	9632-0513-00	Popnit 3,2X20	Pop Rivet	
5	1	9699-0120-02	Bricka	Washer	
6	1	1134-6026-01	Motorlucka (7-14)	Engine Cover	
7	1	1134-6027-01	Ändavslut Stötfångare-Vä	Bumper End-Lh	
8	1	1134-6027-02	Ändavslut Stötfångare-Hö	Bumper End-Rh	
9	4	1134-6310-01	Clips	Clip	
15	1	1134-4012-03	Stöd-Hö	Support, Right	
16	1	1134-4012-04	Stöd-Vä	Support, Left	
17	1	9959-0820-16	Skruv	Screw	
18	1	9739-0831-22	Mutter	Nut	
19	1	1134-6241-01	Huvstöd (Svart) 5-01	Hood Support	
20	3	9893-0616-16	Relä Skruv	Relay Screw	
21	1	1134-4800-01	Innerskärm-Hö (Park)	Inner Mud Guard-Rh (Park)	
22	4	9699-0060-02	Bricka	Washer	
23	4	9893-0616-16	Relä Skruv	Relay Screw	
24	1	1134-4801-01	Innerskärm-Vä (Park)	Inner Mud Guard-Lh (Park)	
30	3	1137-0020-01	Distans	Spacer	
31	3	9997-0535-16	Skruv	Screw	
32	3	9739-0531-22	Mutter	Nut	
33	3	9699-0099-02	Bricka	Washer	
34	3	9747-0531-02	Mutter	Nut	




Utgåva Issue 43 - 2014		Ram	Frame		
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0388-01	Ram-Främre (2Wd) 5-01	Frame-Front (2Wd)	France
1	1	1137-0182-01	Ram-Främre Kpl	Frame Front	
2	1	1134-3963-02	Midjegaffel Service 5-01 H10	Fork	
3	1	1134-0031-00	Ledaxelstopp	Pivot Shaft Stop	
4	1	9595-0262-00	Spännstift	Locating Pin	
5	1	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	Rak/straight
5	1	9501-0504-01	Smörjnippel	Grease Nipple M6 90	90
6	1	1134-2171-01	Fjäder	Spring	
7	1	1134-6466-01	Ram-Bakre Kpl (5-01)	Frame-Rear Assy	
8	1	1134-5705-01	Distans	Spacer	
9	2	9547-0001-00	Ledlager Ge17Es	Bearing	
10	2	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
11	1	1134-5988-01	Centrumaxel	Centre Shaft	
13	2	9699-0035-02	Bricka	Washer	
14	2	9959-1025-16	Skruv	Screw	
15	2	9403-0048-70	Täckpropp Ikpt 13-6,5S	Cover Plug	
16	1	1134-6586-01	Durk (5-01)	Floor Plate	
17	1	1134-6372-04	Durkmatta	Floor Mat Hst	
18	2	9893-0616-16	Relä Skruv	Relay Screw	
19	1	1134-5944-01	Tankhylla Kpl. 5-01	Tank Shelf Assy	
20	2	9945-0816-16	Skruv	Screw	
21	2	9959-0820-16	Skruv	Screw	
22	2	9739-0831-22	Mutter	Nut	
24	1	1134-5676-01	Stötfångare	Rear Bumper	
25	2	1134-4100-01	Täckpropp	Plug	
26	2	1134-0240-00	Skruv	Screw	
27	2	1134-4242-01	Distansbricka	Washer	
28	2	9665-0002-00	Bricka	Washer	
29	2	9747-0831-02	Mutter Låsmutter	Nut	
30	2	9943-0516-16	Skruv	Screw	





Utgåva Issue 43 - 2014		Pedallyft Pedal lift			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4117-01	Fäste	Bracket	
2	2	1134-2684-01	Lager	Bearing	
3	1	1134-4945-01	Lyftspärr kpl	Lift Catch Assy	
7	1	9404-0027-01	O-ring	O-ring	
8	1	9650-0039-04	Spärring Sga 8	Lock Ring	
9	1	9595-0276-01	Spiralspännstift 8*24	Locating Pin	
10	1	9997-0640-12	Skruv	Screw	
11	1	9747-0631-02	Mutter Låsmutter	Nut	
13	1	9897-0820-16	Skruv	Screw	
14	1	9747-0831-02	Mutter Låsmutter	Nut	
15	1	1137-0109-01	Lyftarm Kpl (Grå) 7-14	Lift Arm Assy	
15	1	1134-4860-01	Lyftgaffel	Lift Fork	
16	2	1134-0240-00	Skruv	Screw	
17	1	1134-4938-01	Lyftpedal	Lift Pedal	
18	2	9997-0625-16	Skruv	Screw	
19	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
20	1	4231-0013-00	Fjäder	Spring	




Utgåva Issue 43 - 2014		Sits	Seat		
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6444-01	Sits (Xb 150) Stiga	Seat	
2	1	1134-6090-01	Glidplatta-Övre 5-01	Slide Plate-Upper	
3	1	1134-3262-01	Fjäder	Spring	
4	1	1134-6073-01	Handtag Kpl 5-01	Handle Assy	
5	1	9893-0616-16	Relä Skruv	Relay Screw	
6	1	9747-0631-02	Mutter Låsmutter	Nut	
7	1	1134-6068-01	Glidplatta-Undre Kpl 5-01	Slide Plate-Lower	
8	1	1134-3156-01	Brytare	Switch	
9	1	1134-3156-02	Brytare (grå)	Switch	
10	1	1134-5302-01	Fjäder	Spring	
11	1	1134-5299-01	Tryckplatta	Push Plate	
12	1	9699-0090-02	Bricka	Washer	
13	1	1134-1565-06	Distans	Spacer	
14	1	9997-0840-12	Skruv	Screw	
15	1	9747-0831-02	Mutter Låsmutter	Nut	
16	1	1134-5179-01	Spärr	Catch	
17	1	9675-0012-02	Starlock	Locking washer	
18	2	1134-0240-00	Skruv	Screw	
19	2	1134-4620-02	Fjädermutter	Nut	
22	4	1134-6078-01	Bricka	Flange Washer	
23	4	9959-0820-16	Skruv	Screw	
30	1	1134-5698-01	Sitskonsol Kpl 1-00	Seat Bracket Assy	
31	1	1134-4256-01	Fjäder	Spring	
32	1	9924-1235-19	Skruv	Screw	
33	1	9747-1231-02	Mutter	Nut	
34	1	1134-3990-01	Armsvep Kpl 041-00	Attachment-Side Panel	
35	2	9897-0820-16	Skruv	Screw	
36	2	9739-0831-22	Mutter	Nut	
37	1	1134-4130-01	Undre Lock (1-00)	Cover Lower	
38	4	9840-8013-16	Skruv	Screw	
40	2	9897-0880-12	Skruv	Screw	
41	2	1134-1565-08	Distans	Spacer	
42	4	9897-0820-16	Skruv	Screw	
43	6	9747-0831-02	Mutter Låsmutter	Nut	







Utgåva Issue 43 - 2014		Styrning Steering			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6374-06	Kedja	Chain	83 lönk
2	1	1134-9084-01	Styrwire	Steering Wire	Sats vö+h÷/kit L+R
4	2	1134-2824-02	Kedjelås Fz	Chain Lock	
5	2	1134-3817-01	Fjäder	Spring	L = 58 mm
6	2	9699-0090-02	Bricka	Washer	
7	2	9747-0831-02	Mutter Låsmutter	Nut	
8	4	1134-2816-01	Kedjehjul	Sprocket	
9	4	1134-0041-02	Bussning	Bushing	
10	4	9699-0035-02	Bricka	Washer	
11	2	9997-1050-16	Skruv	Screw	
12	2	9897-1040-12	Skruv	Screw	
13	4	9739-1031-22	Mutter	Nut	
14	2	1134-9025-01	Linhjul	Steering Pulley	Sats 2 st/kit of 2
15	2	1134-0041-01	Bussning	Bushing	
16	2	1134-0046-00	Wireklämma	Wire Clamp	
17	2	9997-1030-16	Skruv	Screw	
18	2	9739-1031-22	Mutter	Nut	
19	1	1134-5349-01	Styrkonsol Kpl (Gul) 1-00	Steering Console (Yellow) 1-00	
20	4	9897-0820-16	Skruv	Screw	
21	4	9739-0831-22	Mutter	Nut	
22	1	1134-1305-05	Rattrör Nedre	Steering Column, Lower	
23	2	1134-1901-01	Lager	Bearing	
24	2	9893-0616-16	Relä Skruv	Relay Screw	
25	1	1137-0079-02	Rattstång Kpl	Steering Rod Assy	
26	1	1134-2837-01	Distans	Spacer	
27	1	1134-5496-03	Ratt	Steering Wheel	




Utgåva Issue 43 - 2014		Sits	Seat		
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6444-01	Sits (Xb 150) Stiga	Seat	
2	1	1134-6090-01	Glidplatta-Övre 5-01	Slide Plate-Upper	
3	1	1134-3262-01	Fjäder	Spring	
4	1	1134-6073-01	Handtag Kpl 5-01	Handle Assy	
5	1	9893-0616-16	Relä Skruv	Relay Screw	
6	1	9747-0631-02	Mutter Låsmutter	Nut	
7	1	1134-6068-01	Glidplatta-Undre Kpl 5-01	Slide Plate-Lower	
8	1	1134-3156-01	Brytare	Switch	
9	1	1134-3156-02	Brytare (grå)	Switch	
10	1	1134-5302-01	Fjäder	Spring	
11	1	1134-5299-01	Tryckplatta	Push Plate	
12	1	9699-0090-02	Bricka	Washer	
13	1	1134-1565-06	Distans	Spacer	
14	1	9997-0840-12	Skruv	Screw	
15	1	9747-0831-02	Mutter Låsmutter	Nut	
16	1	1134-5179-01	Spärr	Catch	
17	1	9675-0012-02	Starlock	Locking washer	
18	2	1134-0240-00	Skruv	Screw	
19	2	1134-4620-02	Fjädermutter	Nut	
22	4	1134-6078-01	Bricka	Flange Washer	
23	4	9959-0820-16	Skruv	Screw	
30	1	1134-5698-01	Sitskonsol Kpl 1-00	Seat Bracket Assy	
31	1	1134-4256-01	Fjäder	Spring	
32	1	9924-1235-19	Skruv	Screw	
33	1	9747-1231-02	Mutter	Nut	
34	1	1134-3990-01	Armsvep Kpl 041-00	Attachment-Side Panel	
35	2	9897-0820-16	Skruv	Screw	
36	2	9739-0831-22	Mutter	Nut	
37	1	1134-4130-01	Undre Lock (1-00)	Cover Lower	
38	4	9840-8013-16	Skruv	Screw	
40	2	9897-0880-12	Skruv	Screw	
41	2	1134-1565-08	Distans	Spacer	
42	4	9897-0820-16	Skruv	Screw	
43	6	9747-0831-02	Mutter Låsmutter	Nut	




Utgåva Issue 43 - 2014		Fotreglage Foot controls			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5655-01	Kopplingspedal Kpl	Clutch Pedal	
2	1	1134-9024-01	Lager (4 St)	Bearing	
3	1	1134-5677-02	Distans	Spacer	
4	1	9997-1070-12	Skruv	Screw	
5	1	9699-0030-02	Bricka	Washer	
6	1	9739-1031-22	Mutter	Nut	
7	1	1134-6005-01	Reglagewire	Control Cable	
8	1	4231-0013-00	Fjäder	Spring	
9	1	1134-6467-01	Wirefäste	Cable Holder	
10	2	9959-0820-16	Skruv	Screw	
11	1	9739-0831-22	Mutter	Nut	
12	1	9747-0831-02	Mutter Låsmutter	Nut	
13	1	1134-6353-01	Drivpedal	Drive Pedal	
14	2	1134-6313-01	Lager	Bearing	
15	2	1134-2700-01	Fäste	Bracket	
16	2	9959-0820-16	Skruv	Screw	
17	2	9739-0831-22	Mutter	Nut	
18	1	9997-0835-16	Skruv	Screw	
19	1	9739-0831-22	Mutter	Nut	
22	1	1134-2766-05	Reglagevajer	Speed Control Cable	
23	2	9570-0001-00	Vinkellänk As8 Din 71802M5	Elbow Link	
24	2	9739-0531-22	Mutter	Nut	
25	2	9747-0531-02	Mutter	Nut	
27	1	1134-6317-01	Wirefäste	Wire Bracket	
28	2	9959-0620-16	Skruv	Screw	
29	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
30	1	1134-3395-01	Fäste 24 (5-01)	Attachment	
31	2	9959-0820-16	Skruv	Screw	
32	2	9739-0831-22	Mutter	Nut	
33	1	1134-2021-01	Växelwirefäste	Clamp	
34	1	1134-5353-01	Bromsstång	Brake Rod	
34	1	1134-5101-01	Bromsstång	Brake Rod	
36	1	1134-2786-01	Knopp	Knob	
36	1	1134-3808-01	Knopp	Knob	
37	1	1131-1497-01	Fjäder	Brake Spring	
38	1	1134-4002-01	Fäste	Brake Rod Attachment	
39	1	9838-9516-12	Skruv	Screw	
43	1	1134-6340-02	Fotstöd (5-01)	Foot Rest	
44	1	9959-0620-16	Skruv	Screw	
45	1	9739-0631-22	Mutter Strålkastare	Nut Working lamp	




Utgåva Issue 43 - 2014		Elsystem Electric system			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5751-01	Batteri	Battery	
2	1	1134-5994-01	Batteribygel	Battery Loop	
3	1	1134-5995-01	Batteribygel	Battery Loop	
4	1	1134-4481-02	Vingmutter	Wing Nut	
5	1	9747-0631-02	Mutter Låsmutter	Nut	
6	1	1134-2962-01	Solenoid Kpl Service	Solenoid	Inkl. pos 7
7	2	9794-5131-02	Mutter	Nut	
8	2	9852-8013-16	Skruv	Screw	
9	2	9699-0060-02	Bricka	Washer	
10	1	1134-4970-02	Kabel	Cable	
11	1	1134-3491-01	Säkringshållare	Fuse Holder	
12	1	1134-3496-07	Säkring (30A Grön)	Fuse (30A)	30A
12	1	1134-3496-06	Säkring (20A)	Fuse (20A)	20A
12	1	1134-3496-01	Säkring (10A)	Fuse (10A)	10A
13	1	1134-3631-01	Lock (5-01)	Cover-Fuse Holder	
14	1	1134-3399-02	Brytare	Switch	
15	2	9943-0516-16	Skruv	Screw	
19	1	1134-7535-01	Honkontakt	Female Connector	
21	2	9840-7716-16	Skruv	Screw	
22	1	1134-0234-02	Batterikabel (+)	Battery Cable (+)	
23	1	1134-2310-01	Batteriskydd	Guard Cap (+)	
24	2	9579-0018-01	Buntband L390	Cable	L=390
24	5	9579-0003-00	Buntband	Cable Holder	
27	1	1137-0075-01	Fäste	Attachment 2010	
28	1	9959-0820-16	Skruv	Screw	
29	1	9739-0831-22	Mutter	Nut	
33	2	9400-0358-01	Led-Lampa	Led-Lamp	
34	1	1134-7505-01	Kabelhärva	Wiring harness	
37	1	9959-0612-16	Skruv	Screw	
38	1	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
39	1	1134-6454-01	Jordplåt	Ground Plate	
40	1	1137-0027-01	Kablage (Honda)	Harness	Honda
40	1	1134-6441-01	Kabelhärva	Wiring harness	B&S




Utgåva Issue 43 - 2014		Motor	Engine		
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6116-02	Luftkanal	Air Duct	B&S
2	4	9955-3725-16	Skruv	Screw	
4	1	9578-0011-01	Rörklämma 38	Tube Clamp	
5	1	1134-6024-01	Ljuddämpare Kpl	Muffler Assy	
6	1	9959-0820-16	Skruv	Screw	
7	1	9739-0831-22	Mutter	Nut	
8	1	1134-5827-01	Oljeavtappning Kpl	Oil Drain Assy	Inkl. pos 9 - 12
9	1	1134-5825-01	Nippel	Nipple	
10	1	9578-0023-04	Slangklämma 15*8 (Vit)	Hose Clamp	
11	1	1134-3499-02	Slangklämma	Hose Clamp	
12	1	1134-5826-01	Plugg	Plug	
15	1	9600-0251-01	Kil	Key	
16	1	1134-5017-01	Bricka	Washer	
17	1	9987-5332-16	Skruv	Screw	
18	1	1134-5938-01	Bränsletank	Fuel Tank	
19	1	1134-5532-01	Tanklock	Fuel Tank Cap	
20	1	1134-3224-01	Bensinkran	Fuel Shut-Off Valve	
21	1	1134-3225-01	Gummibussning	Grommet	
22	1	1134-2975-13	Bensinslang	Fuel Tube	L = 1100
23	1	9578-0023-02	Slangklämma D12*8 (Svart)	Hose Clamp	
24	1	9578-0023-02	Slangklämma D12*8 (Svart)	Hose Clamp	
25	1	1134-5942-01	Tankbygel	Tank Loop	
26	1	1134-5996-01	Tankbygel	Tank Loop	
27	1	1134-4481-02	Vingmutter	Wing Nut	
28	1	9747-0631-02	Mutter Låsmutter	Nut	
29	1	9579-0003-00	Buntband	Cable Holder	
30	1	9852-8013-16	Skruv	Screw	
31	1	1134-0433-00	Packning	Gasket	
32	2	1134-4930-01	Skruv	Screw	
50	1	1134-6234-01	Deflektor	Heat Deflector	
51	2	9943-0516-16	Skruv	Screw	
52	1	1134-6251-01	Deflektor	Heat Deflector	
53	4	9959-0612-16	Skruv	Screw	
54	4	9739-0631-22	Mutter Strålkastare	Nut Working lamp	




Utgåva Issue 43 - 2014		Transmission			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4000-02	Spännarm Kpl 15	Tension Arm	
2	1	1134-3459-01	Spännrulle	Tension Roller	
3	1	9924-1035-16	Skruv	Screw	
4	1	9799-1031-02	Mutter	Nut	
5	1	1134-9058-01	Kilrem	V-Belt	9585-0091-01
6	1	9997-0625-16	Skruv	Screw	
7	1	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
7	1	9747-0631-02	Mutter Låsmutter	Nut	
8	1	1134-3377-02	Reglagestång	Control Rod	
9	1	4231-0013-00	Fjäder	Spring	
10	1	1134-4171-01	Ledtapp	Pivot Pin	
11	1	1134-4183-01	Fjäder	Spring	
12	2	1134-3456-01	Bussning	Bushing	
13	1	9747-0631-02	Mutter Låsmutter	Nut	
14	1	1134-1565-08	Distans	Spacer	
15	1	9997-0870-16	Skruv	Screw	
16	1	9699-0056-02	Bricka	Washer	
17	1	9747-0831-02	Mutter Låsmutter	Nut	
18	1	1134-6414-01	Fjäder	Spring	
19	1	9699-0060-02	Bricka	Washer	
20	1	1137-0123-01	Transaxel K46Ci	Transaxle K46Ci	Kanzaki K46Ci
21	4	9997-0870-16	Skruv	Screw	L = 70 mm
21	4	9960-0860-12	Skruv	Screw	L = 60 mm
22	4	9747-0831-02	Mutter Låsmutter	Nut	
23	1	1134-3913-01	Reaktionsstag 5-01 F24	Strut	
24	1	9959-0825-16	Skruv	Screw	
25	1	9997-0845-12	Skruv	Screw	
26	1	9699-0090-02	Bricka	Washer	
27	2	9747-0831-02	Mutter Låsmutter	Nut	
28	1	9747-0631-02	Mutter Låsmutter	Nut	
29	1	1134-2765-02	Oljetank	Oil Tank	
30	1	1134-2777-02	Tanklock	Filler Cap	
31	1	1134-3734-01	Plugg (Service)	Vent Plug	
32	1	1134-2778-01	Fästband5-01	Band	
33	2	9852-8013-16	Skruv	Screw	
35	1	9578-0023-04	Slangklämma 15*8 (Vit)	Hose Clamp	15*8
36	1	1134-2779-09	Slang	Tube	L = 290 mm
39	1	1134-3203-01	Kabelgenomföring	Grommet	
40	1	1134-4015-01	Dragstång	Pull Rod	
41	1	1134-4014-01	Plastknopp	Knob	
42	1	1134-4713-01	Vinkelfäste	Angle Bracket	
43	1	1134-2790-01	Kabelgenomföring	Cable Protection	
44	1	9959-0820-16	Skruv	Screw	
45	1	9739-0831-22	Mutter	Nut	
46	1	9675-0009-02	Starlockbricka	Starlock	
51	1	1134-3289-02	Remstyrning	Belt Guide	
52	1	9959-0820-16	Skruv	Screw	
53	1	9699-0056-02	Bricka	Washer	
54	1	9739-0831-22	Mutter	Nut	



Utgåva Issue 43 - 2014		Transmission			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
55	1	1134-5941-01	Tankkonsol 5-01	Tank Bracket	
56	2	9959-0820-16	Skruv	Screw	
57	2	9739-0831-22	Mutter	Nut	
70	2	1134-3376-01	Distansplåt	Spacer Plate	Excellent



Utgåva Issue 43 - 2014		Hjul Wheels			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	1134-0075-01	Framaxeltapp	Front Axle	
2	2	9595-0258-00	Spännstift	Locating Pin	
3	2	1134-4844-05	Hjulnav Kpl	Wheel Hub Assy	
3	1	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
4	1	1134-9026-01	Bussning	Bearing	Sats 4 st/kit of 4
5	2	1134-5255-01	Fälg	Rim	Compact 14
5	2	1134-4558-01	Fälg	Rim	
6	2	9545-0126-01	Däck	Tyre	16 x 6.00 - 8
6	2	9545-0116-00	Däck	Tyre	16 x 7.50 - 8
7	2	9545-0500-00	Ventil	Valve Assy.	
8	6	9731-1031-22	Mutter	Nut	
10	8	1134-0341-01	Bricka	Washer	
11	2	9599-0080-02	SaxSprint Sp 4*28	Cotter Pin	
12	2	1134-4844-02	Hjulnav Kpl	Wheel Hub Assy	
13	2	1134-4558-01	Fälg	Rim	
13	2	1134-5255-01	Fälg	Rim	
14	2	9545-0126-01	Däck	Tyre	16 x 6.00 - 8
14	2	9545-0116-00	Däck	Tyre	16 x 7.50 - 8
15	2	9545-0500-00	Ventil	Valve Assy.	
16	6	9731-1031-22	Mutter	Nut	
18	2	1134-4796-01	Navkapsel	Hub Cap	
19	2	9947-0540-19	Skruv	Screw	
20	2	1134-2471-01	Kil	Key	
21	2	9699-0042-02	Bricka	Washer	
22	2	9653-0001-04	Spårryttare Rs	Lock Ring	
26	2	9699-0042-02	Bricka	Washer	
45	1	13-0992-61	Rac Snabbfäste 2Wd Park	Rac Quick Connection 2Wd	Inkl. pos 11,26,46-51
46	1	1134-7465-01	Sats-Fästen (Vä+Hö Inkl Skruv)	Attachment Kit	Inkl. pos 50-51
47	2	1137-0077-01	Låssprint	Locking Pin	
48	2	9548-0026-01	Glidlager 20E7X26-20	Bearing	
50	2	9898-1035-16	Skruv	Screw	
51	2	9739-1031-22	Mutter	Nut	
99	1	9545-0203-00	Innerslang	Inner Tube	Reservdel/spare part



Utgåva Issue 43 - 2014		Kraftuttag Power take-off			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5548-01	Distans	Spacer	Inkl. pos 3A-3B
2	1	1134-5109-01	Spännhjulssarm	Tension Wheel Arm	
3	1	1137-0128-01	Spännhjul Kpl	Tension Roller Assy	
3	1	9549-0019-00	Kullager	Ball Bearing	
3	1	9651-0040-04	Spårring Sgh 40	Circlip	
4	1	1134-1888-04	Distans	Spacer	
5	1	1134-5111-01	Fjäder	Spring	
6	1	9699-0056-02	Bricka	Washer	
7	1	9739-0831-22	Mutter	Nut	Inkl. pos 11-12
8	1	9997-0855-12	Skruv	Screw	
10	1	1137-0004-01	Centrumremskiva Smst	Centre Pulley Assy	
11	1	1134-0051-09	Distans	Spacer	
12	2	9549-0019-00	Kullager	Ball Bearing	
13	1	1134-5112-01	Fjäder	Spring	
14	2	9945-0816-16	Skruv	Screw	
15	1	1134-5110-01	Hake	Hook	
16	2	9893-0616-16	Relä Skruv	Relay Screw	
18	1	1134-2018-02	Spännarm Kpl	Tension Arm	9585-0129-01
19	1	1134-9027-02	Spännrulle (Grå)	Tension Roller (Grey)	
20	1	1134-9071-01	Kilrem	V-Belt	
21	1	9997-1030-16	Skruv	Screw	
22	1	9799-1031-02	Mutter	Nut	
23	1	1134-4111-01	Bromsarm Kpl	Brake Arm	
24	1	1134-4164-03	Bromsklots	Brake Pad	
25	1	9897-0825-16	Skruv	Screw	
26	1	9747-0831-02	Mutter Låsmutter	Nut	
27	1	1134-4162-01	Bromsstång	Brake Rod	
28	1	9675-0008-02	Starlockbricka	Starlock	
29	1	1134-4170-01	Nippel	Nippel	
30	1	9699-0025-02	Bricka	Washer	
31	1	9747-0631-02	Mutter Låsmutter	Nut	
32	1	4231-0013-00	Fjäder	Spring	
33	1	1134-4231-01	Fjäder	Brake Spring	
34	1	1134-1565-10	Distans	Spacer	
35	1	9997-0860-12	Skruv	Screw	
36	1	9699-0056-02	Bricka	Washer	
37	1	9739-0831-22	Mutter	Nut	
38	1	1134-4163-01	Ansattsskruv	Shoulder Bolt	
39	1	9731-1031-22	Mutter	Nut	
40	1	1134-3958-01	Remstyrning	Belt Guide	
41	2	9893-0616-16	Relä Skruv	Relay Screw	
42	1	1134-0041-03	Bussning	Bushing	
43	1	9997-1070-12	Skruv	Screw	
44	1	9739-1031-22	Mutter	Nut	
45	1	1134-3654-01	Fingerskydd 5-01 24	Guard	
46	2	9959-0612-16	Skruv	Screw	
47	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
48	1	9699-0090-02	Bricka	Washer	
49	2	9699-0035-02	Bricka	Washer	

code	pos.	q.ty	page									
13-0992-61	45	1	p. 29	1134-3631-01	13	1	p. 21	1134-5302-01	10	1	p. 17	
	31		p. 3	1134-3654-01	45	1	p. 31	1134-5349-01	19	1	p. 15	
1131-1497-01	37	1	p. 19	1134-3734-01	31	1	p. 25	1134-5353-01	34	1	p. 19	
1134-0031-00	3	1	p. 9	1134-3808-01	36	1	p. 19	1134-5496-03	27	1	p. 15	
1134-0041-01	15	2	p. 15	1134-3817-01	5	2	p. 15	1134-5512-01	13	1	p. 3	
1134-0041-02	9	4	p. 15	1134-3913-01	23	1	p. 25	1134-5532-01	19	1	p. 23	
1134-0041-03	42	1	p. 31	1134-3958-01	40	1	p. 31	1134-5548-01	1	1	p. 31	
1134-0046-00	16	2	p. 15	1134-3963-02	2	1	p. 9	1134-5655-01	1	1	p. 19	
1134-0051-09	11	1	p. 31	1134-3970-02	26	1	p. 5	1134-5676-01	24	1	p. 9	
1134-0075-01	1	2	p. 29	1134-3970-05	25	1	p. 5	1134-5677-02	3	1	p. 19	
1134-0234-02	22	1	p. 21	1134-3979-01	18	1	p. 5	1134-5698-01	30	1	p. 13	
1134-0240-00	16	2	p. 11	1134-3990-01	34	1	p. 13	1134-5698-01	30	1	p. 17	
1134-0240-00	18	2	p. 13	1134-3990-01	34	1	p. 17	1134-5705-01	8	1	p. 9	
1134-0240-00	18	2	p. 17	1134-4000-02	1	1	p. 25	1134-5751-01	1	1	p. 21	
1134-0240-00	26	2	p. 9	1134-4002-01	38	1	p. 19	1134-5825-01	9	1	p. 23	
1134-0341-01	10	8	p. 29	1134-4012-03	15	1	p. 7	1134-5826-01	12	1	p. 23	
1134-0433-00	31	1	p. 23	1134-4012-04	16	1	p. 7	1134-5827-01	8	1	p. 23	
1134-1305-05	22	1	p. 15	1134-4014-01	41	1	p. 25	1134-5938-01	18	1	p. 23	
1134-1565-06	13	1	p. 13	1134-4015-01	40	1	p. 25	1134-5941-01	55	1	p. 27	
1134-1565-06	13	1	p. 17	1134-4100-01	25	2	p. 9	1134-5942-01	25	1	p. 23	
1134-1565-08	14	1	p. 25	1134-4111-01	23	1	p. 31	1134-5944-01	19	1	p. 9	
1134-1565-08	41	2	p. 13	1134-4117-01	1	1	p. 11	1134-5988-01	11	1	p. 9	
1134-1565-08	41	2	p. 17	1134-4130-01	37	1	p. 13	1134-5994-01	2	1	p. 21	
1134-1565-10	34	1	p. 31	1134-4130-01	37	1	p. 17	1134-5995-01	3	1	p. 21	
1134-1888-04	4	1	p. 31	1134-4162-01	27	1	p. 31	1134-5996-01	26	1	p. 23	
1134-1901-01	23	2	p. 15	1134-4163-01	38	1	p. 31	1134-6005-01	7	1	p. 19	
1134-2018-02	18	1	p. 31	1134-4164-03	24	1	p. 31	1134-6024-01	5	1	p. 23	
1134-2021-01	33	1	p. 19	1134-4170-01	29	1	p. 31	1134-6025-01	1	1	p. 7	
1134-2171-01	6	1	p. 9	1134-4171-01	10	1	p. 25	1134-6026-01	6	1	p. 7	
1134-2310-01	23	1	p. 21	1134-4176-01	4	2	p. 5	1134-6027-01	7	1	p. 7	
1134-2471-01	20	2	p. 29	1134-4176-01	12	2	p. 5	1134-6027-02	8	1	p. 7	
1134-2684-01	2	2	p. 11	1134-4183-01	11	1	p. 25	1134-6068-01	7	1	p. 13	
1134-2700-01	15	2	p. 19	1134-4231-01	33	1	p. 31	1134-6068-01	7	1	p. 17	
1134-2765-02	29	1	p. 25	1134-4242-01	27	2	p. 9	1134-6073-01	4	1	p. 13	
1134-2766-05	22	1	p. 19	1134-4256-01	31	1	p. 13	1134-6073-01	4	1	p. 17	
1134-2777-02	30	1	p. 25	1134-4256-01	31	1	p. 17	1134-6078-01	22	4	p. 13	
1134-2778-01	32	1	p. 25	1134-4360-01	17	1	p. 5	1134-6078-01	22	4	p. 17	
1134-2779-09	36	1	p. 25	1134-4481-02	4	1	p. 21	1134-6090-01	2	1	p. 13	
1134-2786-01	36	1	p. 19	1134-4481-02	27	1	p. 23	1134-6090-01	2	1	p. 17	
1134-2790-01	43	1	p. 25	1134-4558-01	5	2	p. 29	1134-6113-02	17	1	p. 3	
1134-2816-01	8	4	p. 15	1134-4558-01	13	2	p. 29	1134-6116-02	1	1	p. 23	
1134-2824-02	4	2	p. 15	1134-4620-02	19	2	p. 13	1134-6234-01	50	1	p. 23	
1134-2837-01	26	1	p. 15	1134-4620-02	19	2	p. 17	1134-6241-01	19	1	p. 7	
1134-2962-01	6	1	p. 21	1134-4713-01	42	1	p. 25	1134-6251-01	52	1	p. 23	
1134-2975-13	22	1	p. 23	1134-4796-01	18	2	p. 29	1134-6310-01	9	4	p. 7	
1134-3156-01	8	1	p. 13	1134-4800-01	21	1	p. 7	1134-6313-01	14	2	p. 19	
1134-3156-01	8	1	p. 17	1134-4801-01	24	1	p. 7	1134-6317-01	27	1	p. 19	
1134-3156-02	9	1	p. 13	1134-4844-02	12	2	p. 29	1134-6340-02	43	1	p. 19	
1134-3156-02	9	1	p. 17	1134-4844-05	3	2	p. 29	1134-6353-01	13	1	p. 19	
1134-3203-01	39	1	p. 25	1134-4860-01	15	1	p. 11	1134-6372-04	17	1	p. 9	
1134-3224-01	20	1	p. 23	1134-4930-01	32	2	p. 23	1134-6374-06	1	1	p. 15	
1134-3225-01	21	1	p. 23	1134-4938-01	17	1	p. 11	1134-6414-01	18	1	p. 25	
1134-3262-01	3	1	p. 13	1134-4945-01	3	1	p. 11	1134-6441-01	40	1	p. 21	
1134-3262-01	3	1	p. 17	1134-4970-02	10	1	p. 21	1134-6444-01	1	1	p. 13	
1134-3289-02	51	1	p. 25	1134-5017-01	16	1	p. 23	1134-6444-01	1	1	p. 17	
1134-3376-01	70	2	p. 27	1134-5101-01	34	1	p. 19	1134-6454-01	39	1	p. 21	
1134-3377-02	8	1	p. 25	1134-5109-01	2	1	p. 31	1134-6461-01	31	1	p. 5	
1134-3395-01	30	1	p. 19	1134-5110-01	15	1	p. 31	1134-6466-01	7	1	p. 9	
1134-3399-02	14	1	p. 21	1134-5111-01	5	1	p. 31	1134-6467-01	9	1	p. 19	
1134-3456-01	12	2	p. 25	1134-5112-01	13	1	p. 31	1134-6586-01	16	1	p. 9	
1134-3459-01	2	1	p. 25	1134-5179-01	16	1	p. 13	1134-7465-01	46	1	p. 29	
1134-3491-01	11	1	p. 21	1134-5179-01	16	1	p. 17	1134-7505-01	34	1	p. 21	
1134-3496-01	12	1	p. 21	1134-5255-01	5	2	p. 29	1134-7535-01	19	1	p. 21	
1134-3496-06	12	1	p. 21	1134-5255-01	13	2	p. 29	1134-9024-01	2	1	p. 19	
1134-3496-07	12	1	p. 21	1134-5299-01	11	1	p. 13	1134-9025-01	14	2	p. 15	
1134-3499-02	11	1	p. 23	1134-5299-01	11	1	p. 17	1134-9026-01	4	1	p. 29	
				1134-5302-01	10	1	p. 13	1134-9027-02	19	1	p. 31	

code	pos.	q.ty	page
9943-0516-16	30	2	p. 9
9943-0516-16	51	2	p. 23
9945-0816-16	8	6	p. 5
9945-0816-16	14	2	p. 31
9945-0816-16	20	2	p. 9
9946-0525-16	19	3	p. 5
9946-0525-16	43	2	p. 5
9947-0540-19	19	2	p. 29
9950-0570-12	20	2	p. 5
9955-3725-16	2	4	p. 23
9959-0612-16	37	1	p. 21
9959-0612-16	46	2	p. 31
9959-0612-16	53	4	p. 23
9959-0620-16	28	2	p. 19
9959-0620-16	44	1	p. 19
9959-0820-16	6	1	p. 23
9959-0820-16	10	2	p. 19
9959-0820-16	14	2	p. 3
9959-0820-16	16	2	p. 19
9959-0820-16	17	1	p. 7
9959-0820-16	21	2	p. 9
9959-0820-16	23	4	p. 13
9959-0820-16	23	4	p. 17
9959-0820-16	28	1	p. 21
9959-0820-16	31	2	p. 19
9959-0820-16	44	1	p. 25
9959-0820-16	52	1	p. 25
9959-0820-16	56	2	p. 27
9959-0825-16	24	1	p. 25
9959-1025-16	14	2	p. 9
9960-0860-12	21	4	p. 25
9987-5332-16	17	1	p. 23
9997-0535-16	31	3	p. 7
9997-0625-16	6	1	p. 25
9997-0625-16	18	2	p. 11
9997-0640-12	10	1	p. 11
9997-0835-16	18	1	p. 19
9997-0840-12	14	1	p. 13
9997-0840-12	14	1	p. 17
9997-0845-12	25	1	p. 25
9997-0855-12	8	1	p. 31
9997-0860-12	35	1	p. 31
9997-0870-16	15	1	p. 25
9997-0870-16	21	4	p. 25
9997-1030-16	17	2	p. 15
9997-1030-16	21	1	p. 31
9997-1050-16	11	2	p. 15
9997-1070-12	4	1	p. 19
9997-1070-12	43	1	p. 31
118210027/0	11	2	p. 3