



www.stiga.com

Illustrated Parts List

for model:

Park CH 2 WD

- Use GLOBAL GARDEN PRODUCT genuine spare parts specified in the parts list for repair and/or replacement.
- Then contents described in the parts list may change due to improvement.
- The drawings of the spare part are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.







© Copyright 2014 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.





THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.

www.ggp-group.com







Utgåva Issue 2013-11		Bildnr Picture No 2014E		PARK 2WD MONTERINGSDETALJER		PARK 2WD ASSEMBLY PARTS		Sida Page 2	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6384 6311 6310 6380	6320							
4	2	2			9595-0262-00	Spännstift.....	Locating pin		
5	1	1			9699-0103-02	Shims	Flat washer		0.5 mm
6	1	1			9699-0114-02	Shims	Flat washer		1.0 mm
10	2	2			1134-4734-01	Tändningsnyckel.....	Ignition key		
13	1	1			1134-5512-01	Dragplåt	Towing plate.....		
14	2	2			9959-0820-16	Skruv.....	Screw.....		
15	2	2			9739-0831-22	Mutter	Nut.....		
17	1	1			1134-6113-02	Batteriskruvar	Battery screws.....		
18	2	2			9898-1035-16	Skruv.....	Screw.....		
19	2	2			9739-1031-22	Mutter	Nut.....		





Utgåva Issue 2013-11		Bildnr Picture No 2820A		PARK 2WD KAROSS-FRAM		PARK 2WD BODY WORK-FRONT		Sida Page 4	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6384 6311 6310 6380	6320							
1	1	1		1137-0048-01	Skärm-vä, grå	Mud guard-LH, grey			
2	1	1		1137-0048-02	Skärm-hö, grå	Mud guard-RH, grey			
3	2	2		9893-0616-16	Skruv.....	Screw.....			
4	4	4		1134-4176-01	Clips.....	Clips.....			
5	2	2		9699-0060-02	Planbricka.....	Flat washer			
6	2	2		9747-0631-02	Låsmutter.....	Lock nut			
7	2	2		1137-0088-01	Stödplåt.....	Support plate			
8	6	6		9945-0816-16	Skruv.....	Screw.....			
9	4	4		9699-0056-02	Planbricka.....	Flat washer			
10	1	1		1137-0049-01	Stötfångare-grå	Bumper-grey			
11	6	6		9893-0616-16	Skruv.....	Screw.....			
12	2	2		1134-4176-01	Clips.....	Clips			
17	1	1		1134-4360-01	Kåpa-inre	Cover-inner			
18	1	1		1134-3979-01	Kåpa-yttre.....	Cover-outer			
19	3	3		9946-0525-16	Skruv.....	Screw.....			
20	2	2		9950-0570-12	Skruv.....	Screw.....			
21	2	2		9747-0531-02	Mutter	Nut.....			
23	4	4		9893-0616-16	Skruv.....	Screw.....			
25	1	1		1134-3970-05	Kantlist-vä, grå	Moulding-LH, grey			
26	1	1		1134-3970-02	Kantlist-hö, grå.....	Moulding-RH, grey.....			
27	4	4		9893-0616-16	Skruv.....	Screw.....			
28	2	2		9840-8013-16	Skruv.....	Screw.....			
29	2	2		9897-0616-16	Vagnsbult.....	Carriage bolt.....			
31	1	1		1134-6461-01	Bakstycke	Rear plate			
40	1	1		1137-0050-01	Frontkåpa-nedre.....	Front panel-lower.....			
41	2	2		9838-9516-12	Skruv.....	Screw			
42	1	1		1137-0051-01	Frontkåpa-övre	Front panel-upper.....			
43	2	2		9946-0525-16	Skruv.....	Screw.....			
44	1	1		1137-0052-01	Lamphållare.....	Lamp holder			
45	1	1		1137-0053-01	Toppkåpa	Top panel.....			
46	2	2		9838-9516-12	Skruv.....	Screw			
47	1	1		1137-0054-01	Lampglas	Lamp glass			





Utgåva Issue 2013-11		Bildnr Picture No 2016D		PARK 2WD KAROSS-BAK		PARK 2WD BODY WORK-REAR		Sida Page 6	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6384 6311 6310 6380	6320							
1	1	1		1134-6025-01	Motorhuv	Engine hood		Sats 3 st/kit of 3	
2	4	4		9893-0616-16	Skruv.....	Screw.....			
3	1	1		1134-9028-01	Gummistropp-sats	Rubber strap kit.....			
4	1	1		9632-0513-00	Popnit.....	Pop rivet.....			
5	1	1		9699-0120-02	Bricka	Washer.....			
6	1	1		1134-6026-01	Motorlucka	Engine cover			
7	1	1		1134-6027-01	Ändavslut-vä.....	Bumper end-LH.....			
8	1	1		1134-6027-02	Ändavslut-hö	Bumper end-RH.....			
9	4	4		1134-6310-01	Clips.....	Clips			
15	1			1134-4012-03	Stödkonsol-hö.....	Support-RH.....			
16	1			1134-4012-04	Stödkonsol-vä.....	Support-LH.....			
17	1			9959-0820-16	Skruv.....	Screw.....			
18	1			9739-0831-22	Mutter	Nut.....			
19	1			1134-6241-01	Huvstöd.....	Hood support.....			
20	3	3		9893-0616-16	Skruv.....	Screw.....			
21	1			1134-4800-01	Innerskärm-hö.....	Inner mud guard-RH.....			
22	4			9699-0060-02	Planbricka.....	Flat washer			
23	4			9893-0616-16	Skruv.....	Screw.....			
24	1			1134-4801-01	Innerskärm-vä.....	Inner mud guard-LH.....			








Utgåva Issue		Bildnr Picture No		PARK 2WD RAM		PARK 2WD FRAME		Sida Page	
2013-11		2017B						8	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6384 6311 6310 6380	6320							
1	1	1		1137-0388-01	Ram-främre.....	Frame-front		Rak/straight 90°	
2	1	1		1137-1119-02	Midjegaffel	Clevis			
3	1	1		1134-0031-00	Ledaxelstopp.....	Pivot shaft stop.....			
4	1	1		9595-0262-00	Spännstift.....	Locating pin			
5A	1	1		9501-0500-00	Smörjnippel	Grease joint			
5B	1	1		9501-0504-01	Smörjnippel	Grease joint			
6	1	1		1134-2171-01	Fjäder.....	Spring			
7	1	1		1134-6466-02	Ram-bakre	Frame-rear.....			
8	1	1		1134-5705-01	Distans	Spacer.....			
9	2	2		9547-0001-00	Ledlager.....	Bearing			
10	2	2		9501-0500-00	Smörjnippel	Grease joint			
11	1	1		1134-5988-01	Centrumaxel	Centre shaft			
13	2	2		9699-0035-02	Planbricka.....	Flat washer			
14	2	2		9959-1025-16	Skruv.....	Screw.....			
15	2	2		9403-0048-70	Täckpropp.....	Plug			
16	1	1		1134-6586-01	Durk.....	Floor plate			
17	1	1		1134-6372-04	Durkmatta.....	Floor mat			
18	2	2		9893-0616-16	Skruv.....	Screw.....			
19	1	1		1134-5944-01	Tankhylla	Tank shelf			
20	2	2		9945-0816-16	Skruv.....	Screw.....			
21	2	2		9959-0820-16	Skruv.....	Screw.....			
22	2	2		9739-0831-22	Mutter	Nut.....			
24	1	1		1134-5676-01	Stötfångare.....	Bumper.....			
25	2	2		1134-4100-01	Täckpropp.....	Plug			
26	2	2		1134-0240-00	Ansatskruv	Shoulder screw.....			
27	2	2		1134-4242-01	Distansbricka	Spacer washer			
28	2	2		9665-0002-00	Brickfjäder.....	Bowed washer.....			
29	2	2		9747-0831-02	Mutter	Lock nut			
30	2	2		9943-0516-16	Skruv.....	Screw.....			







Utgåva Issue 2013-11		Bildnr Picture No 1023F		PARK 2WD PEDAL LYFT		PARK 2WD PEDAL LIFT		Sida Page 10	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6384 6311 6310 6380	6320							
1	1	1		1134-4117-01	Fäste.....	Bracket			
2	2	2		1134-2684-01	Lager.....	Bearing			
3	1	1		1134-4945-01	Lyftspärr kpl	Lift catch assy			
7	1	1		9404-0027-01	O-ring	O-ring			
8	1	1		9650-0039-04	Seegersäkring	Lock ring			
9	1	1		9595-0276-01	Spännstift.....	Locating pin			
10	1	1		9997-0640-12	Skruv.....	Screw.....			
11	1	1		9747-0631-02	Låsmutter.....	Lock nut			
13	1	1		9897-0820-16	Skruv.....	Screw.....			
14	1	1		9747-0831-02	Mutter	Lock nut			
15	1	1		1137-0109-01	Lyftarm	Lift arm			
16	2	2		1134-0240-00	Ansattsskruv	Shoulder screw.....			
17	1	1		1134-4938-01	Lyftpedal.....	Lift pedal			
18	2	2		9997-0625-16	Skruv.....	Screw.....			
19	2	2		9739-0631-22	Mutter	Nut.....			
20	1	1		4231-0013-00	Fjäder.....	Spring.....			







Utgåva Issue 2013-11		Bildnr Picture No 2019B		PARK 2WD SITS		PARK 2WD SEAT		Sida Page 12	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6384 6311 6310 6380	6320							
1	1	1		1134-6444-01	Sits	Seat.....			
2	1	1		1134-6090-01	Glidplatta	Slide plate.....			
3	1	1		1134-3262-01	Tryckfjäder	Compression spring			
4	1	1		1134-6073-01	Handtag	Handle			
5	1	1		9893-0616-16	Skruv	Screw.....			
6	1	1		9747-0631-02	Låsmutter	Lock nut			
7	1	1		1134-6068-01	Glidplatta-undre.....	Slide plate-lower			
8	1	1		1134-3156-01	Brytare (svart).....	Switch (black)			
9	1	1		1134-3156-02	Brytare (grå)	Switch (grey).....			
10	1	1		1134-5302-01	Fjäder	Spring			
11	1	1		1134-5299-01	Tryckplatta	Push plate			
12	1	1		9699-0090-02	Planbricka	Flat washer			
13	1	1		1134-1565-06	Distans	Spacer			
14	1	1		9997-0840-12	Skruv	Screw.....			
15	1	1		9747-0831-02	Mutter	Lock nut			
16	1	1		1134-5179-01	Spärr	Catch			
17	1	1		9675-0012-02	Starlock	Locking washer.....			
18	2	2		1134-0240-00	Ansatsskruv	Shoulder screw.....			
19	2	2		1134-4620-02	Fjädermutter	Spring nut.....			
22	4	4		1134-6078-01	Ansatsbricka	Flange washer			
23	4	4		9959-0820-16	Skruv	Screw.....			
30	1	1		1134-5698-01	Sitskonsol	Seat bracket			
31	1	1		1134-4256-01	Sitsfjäder.....	Seat spring.....			
32	1	1		9924-1235-19	Skruv	Screw.....			
33	1	1		9747-1231-02	Låsmutter	Lock nut			
34	1	1		1134-3990-01	Armsvep	Attachment-side panel			
35	2	2		9897-0820-16	Skruv	Screw.....			
36	2	2		9739-0831-22	Mutter	Nut.....			
37	1	1		1134-4130-01	Lock-undre	Cover-lower			
38	4	4		9840-8013-16	Skruv	Screw.....			
40	2	2		9897-0880-12	Skruv	Screw.....			
41	2	2		1134-1565-08	Distans	Spacer			
42	4	4		9897-0820-16	Skruv	Screw.....			
43	6	6		9747-0831-02	Mutter	Lock nut			





- 1
- 2
- 3
- 4
- 5A
- 5B
- 6
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14




Utgåva Issue 2013-11		Bildnr Picture No 1787F		PARK 2WD STYRNING		PARK 2WD STEERING		Sida Page 14
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6311 6310 6384							
1	1			1134-6374-10	Kedja.....	Chain		129 länk
2	2			1134-6374-09	Kedja.....	Chain		35 länk
3	1			1134-6374-02	Kedja.....	Chain		41 länk
4	1			1134-6374-05	Kedja.....	Chain		47 länk
5	1			1134-3550-01	Ändnippel.....	End nipple		L = 110 mm
68	1			1134-3550-02	Ändnippel.....	End nipple		L = 90 mm
6	4			1134-3565-01	Skarvnippel.....	Connection nipple		
7	12			1134-2824-02	Kedjelås.....	Chain lock		
8	2			1134-5652-01	Fäste.....	Attachment.....		
9	4			1134-5651-01	Bygel.....	Bracket.....		
10	2			1134-2816-01	Kedjehjul.....	Sprocket		
11	2			1134-0041-02	Linhjulshylsa.....	Idler wheel bush.....		
12	2			1134-4817-01	Kolvstängssprint.....	Pin		
13	2			9699-0035-02	Planbricka.....	Flat washer		
14	2			9599-0054-02	Saxpinne.....	Cotter pin		
15	1			1134-3817-01	Tryckfjäder.....	Compression spring		L = 58 mm
69	1			1134-3817-02	Tryckfjäder.....	Compression spring		L = 33 mm
16	2			9699-0090-02	Planbricka.....	Flat washer		
17	2			9747-0831-02	Mutter.....	Lock nut		
18	4			1134-2816-01	Kedjehjul.....	Sprocket		
19	4			1134-5653-01	Distans.....	Spacer.....		
20	2			9699-0035-02	Planbricka.....	Flat washer		
21	2			9997-1060-12	Skruv.....	Screw.....		
22	2			9739-1031-22	Mutter.....	Nut.....		
23	2			9897-1060-12	Skruv.....	Screw.....		
24	2			9731-1031-22	Mutter.....	Nut.....		
25	3			1134-3547-01	Kedjehjul.....	Sprocket		
26	2			1134-0041-01	Linhjulshylsa.....	Bushing		
27	2			1134-0046-00	Linhållare.....	Wire clamp.....		
28	2			9997-1040-16	Skruv.....	Screw.....		
29	2			9699-0035-02	Planbricka.....	Flat washer		
30	2			9739-1031-22	Mutter.....	Nut.....		
31	1			1137-0066-01	Styrkonsol.....	Steering bracket.....		
32	4			9897-0820-16	Skruv.....	Screw.....		
33	4			9739-0831-22	Mutter.....	Nut.....		
34	1			1134-1305-03	Rattrör-nedre.....	Steering column-lower.....		
35	2			1134-1901-01	Lager.....	Bearing.....		
36	1			1137-0120-02	Rattstång.....	Steering rod.....		
41	2			9893-0616-16	Skruv.....	Screw.....		
42	1			1134-2837-03	Distans.....	Spacer.....		
52	1			1134-5173-02	Ratt kpl.....	Steering wheel assy.....		
53	1			1134-3769-01	Styrknopp kpl.....	Steering wheel button.....		
54	1			1134-3752-01	Knoppfäste.....	Knob holder		
55	1			9997-0870-16	Skruv.....	Screw.....		
56	1			1134-1565-06	Distans.....	Spacer.....		
57	3			9699-0090-02	Planbricka.....	Flat washer		
58	1			9747-0831-02	Mutter.....	Lock nut		
59	1			9403-0043-70	Plugg.....	Plug		
60	1			9403-0113-00	Mutterhatt.....	Nut cap		
63	1			1137-0070-01	Rattrör-inre kpl.....	Steering tube-inner.....		
64	1			1134-5177-01	Slid.....	Slide		
65	1			9710-0631-12	Fyrkantmutter.....	Square nut		
66	1			1134-4481-02	Vingmutter.....	Wing nut.....		
67	1			9997-0630-12	Skruv.....	Screw.....		
70	1			1134-6380-03	Styrkedja kpl.....	Steering chain assy.....		Inkl. pos 1 - 14



REAR
TRANSMISSION







Utgåva Issue 2013-11		Bildnr Picture No 2408C		PARK 2WD STYRNING		PARK 2WD STEERING		Sida Page 16	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6320	6380							
1	1				1134-6374-06	Kedja.....	Chain		83 länk
2	3				1134-6374-02	Kedja.....	Chain		41 länk
3	1				1134-6374-04	Kedja.....	Chain		45 länk
4	1				1134-3550-01	Ändnippel	End nipple		L = 110 mm
61	1				1134-3550-02	Ändnippel	End nipple		L = 90 mm
5	4				1134-3565-01	Skarvnippel.....	Connection nipple		
6	10				1134-2824-02	Kedjelås	Chain lock		
7	1				1134-3817-01	Tryckfjäder	Compression spring		L = 58 mm
62	1				1134-3817-02	Tryckfjäder	Compression spring		L = 33 mm
8	2				9699-0090-02	Planbricka.....	Flat washer		
9	2				9747-0831-02	Mutter	Lock nut		
10	4				1134-2816-01	Kedjehjul	Sprocket		
11	4				1134-0041-02	Linhjulshylsa	Idler wheel bush.....		
12	4				9699-0035-02	Planbricka.....	Flat washer		
13	2				9997-1050-16	Skruv.....	Screw.....		
14	2				9897-1040-12	Skruv.....	Screw.....		
15	4				9739-1031-22	Mutter	Nut.....		
16	3				1134-3547-01	Kedjehjul	Sprocket		
17	2				1134-0041-01	Linhjulshylsa	Bushing		
18	2				1134-0046-00	Linhållare.....	Wire clamp		
19	2				9997-1030-16	Skruv.....	Screw.....		
20	2				9739-1031-22	Mutter	Nut.....		
21	1				1137-0066-01	Styrkonsol.....	Steering bracket.....		
22	4				9897-0820-16	Skruv.....	Screw.....		
23	4				9739-0831-22	Mutter	Nut.....		
24	1				1137-0044-01	Rattrör-nedre.....	Steering tube-lower.....		
25	1				9549-0017-00	Kullager	Ball bearing.....		
26	1				9945-0816-16	Skruv.....	Screw.....		
27	1				1137-0045-01	Rattstång	Steering rod		
28	1				1134-4114-01	Bussning	Bushing		
29	1				1134-4118-01	Koppling	Coupling.....		
30	2				9595-0256-01	Spännstift.....	Pin		
31	1				9695-0011-00	Bricka	Washer		
32	1				1134-5173-02	Ratt kpl	Steering wheel assy.....		
33	1				1134-3769-01	Styrknopp kpl	Steering wheel button.....		
34	1				1134-3752-01	Knoppfäste.....	Knob holder		
35	1				9997-0870-16	Skruv.....	Screw.....		
36	1				1134-1565-06	Distans	Spacer		
37	3				9699-0090-02	Planbricka.....	Flat washer		
38	1				9747-0831-02	Mutter	Lock nut		
39	1				9403-0043-70	Plugg.....	Plug		
40	1				9403-0113-00	Mutterhatt	Nut cap		
42	1				1134-6420-01	Momentförstärkare	Steering booster.....		Inkl. pos 63 and 64
63	1				1139-2106-01	Drev	Pinion		
64	1				1139-2074-01	Reparationsatts	Seal kit		
43	3				9939-0612-16	Skruv.....	Screw.....		
47	1				1134-7073-01	Vinkeladapter.....	Hydraulic coupling.....		
48	1				1137-0195-02	Hydraulslang.....	Hydraulic tube.....		L = 1740 mm
49	1				1134-6323-01	Banjobult	Banjo bolt.....		
50	1				1137-0214-03	Hydraulslang.....	Hydraulic tube.....		L = 2050 mm
51	2				1134-4948-02	Tredobricka.....	Tredo washer		
52	2				1134-4282-01	Hydraulnippel.....	Hydraulic nipple.....		
65	1				9404-0028-01	O-ring	O-ring		
53	1				1137-0070-01	Rattrör-inre kpl	Steering tube-inner		
54	1				1134-5177-01	Slid.....	Slide		
55	1				9710-0631-12	Fyrkantmutter	Square nut		
56	1				1134-4481-02	Vingmutter.....	Wing nut.....		
57	1				9997-0630-12	Skruv.....	Screw.....		
58	1				1137-0112-01	Bygel.....	Guide.....		
59	2				9897-0616-16	Vagnsbult	Carriage bolt.....		
60	2				9739-0631-22	Mutter	Nut.....		
70	1				1134-6379-02	Styrkedja kpl.....	Steering chain assy.....		Inkl. pos 1 - 6




Utgåva Issue 2013-11		Bildnr Picture No 1991D		PARK 2WD HANDREGLAGE		PARK 2WD HAND CONTROLS		Sida Page 18	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6320 6384	6311	6310	6380					
1	1	1	1	1	1134-4156-01	Vinkelhållare.....	Panel bracket-inner		
2	2	2	2	2	9897-0820-16	Skruv.....	Screw.....		
3	2	2	2	2	9739-0831-22	Mutter	Nut.....		
4	1	1	1	1	9695-0011-00	Bricka	Washer.....		
5	1	1	1	1	1134-4065-01	Reglageaxel	Control shaft.....		
6	1	1	1	1	1134-4079-01	Fjäder.....	Spring.....		
7	1	1	1	1	1134-4080-03	Reglagehylsa.....	Control sleeve		
8	2	2	2	2	9959-0820-16	Skruv.....	Screw.....		
9	1	1	1	1	1134-4077-01	Gasreglage	Throttle control		
10	1	1	1	1	1134-4078-01	Knopp	Knob.....		
11	1	1	1	1	1134-0240-00	Ansattsskruv	Shoulder screw.....		
12	2	2	2	2	1134-4242-01	Distansbricka	Spacer washer		
13	1	1	1	1	9694-0001-00	Fjäderbricka.....	Washer.....		
14	1	1	1	1	9747-0831-02	Mutter	Lock nut		
15	1	1			1137-0063-02	Gaswire.....	Throttle cable		L1 = 925 mm
15			1	1	1137-0063-03	Gaswire.....	Throttle cable		L1 = 1413 mm
16	1	1	1	1	1137-0115-01	Överfall.....	Cable clamp		
17	1	1	1	1	9943-0516-16	Skruv.....	Screw.....		
18	1	1	1	1	1134-4072-01	Aggregatspak	Control lever		
19	1	1	1	1	1134-2551-01	Reglageknopp.....	Knob.....		
20	1	1	1	1	1134-3573-03	Wire.....	PTO cable.....		
21	1	1	1	1	1134-5358-01	Brytarfäste	Switch bracket.....		
22	2	2	2	2	9852-8013-16	Skruv.....	Screw.....		
23	1	1	1	1	9400-0360-01	Mikrobrytare.....	Micro switch		
24	2	2	2	2	9840-7716-16	Skruv.....	Screw.....		L = 16 mm
25	1	1	1	1	1134-6328-01	Frontfäste	Panel bracket-front.....		
26	2	2	2	2	9893-0616-16	Skruv.....	Screw.....		
27	1	1	1	1	1134-6327-01	Frontplåt	Front plate		
28	4	4	4	4	9893-0616-16	Skruv.....	Screw.....		
32			1	1	1134-6096-02	Kassett	Dashboard		
32	1	1			1134-6096-05	Kassett	Dashboard		
33	4	4	4	4	9946-0525-16	Skruv.....	Screw.....		
34	1	1	1	1	1134-4154-01	Täckbricka	Cover.....		
35	5	5	5	5	1134-4129-01	Täckbricka	Cover.....		
36	1	1	1	1	1134-4093-01	Tändningslås.....	Ignition switch		
39	1	1	1	1	1134-4749-01	Mutter	Nut.....		
40					1134-2872-03	Chokereglage.....	Choke control.....		
40			1	1	1137-0062-03	Chokereglage.....	Choke control.....		
40			1	1	1134-4338-01	Reglageknopp.....	Control knob		
41			1	1	9699-0090-02	Planbricka.....	Flat washer.....		
42	1	1	1	1	9400-0282-01	Brytare m.diod.....	Switch w.diode.....		
44	1	1	1	1	1134-6097-02	Timräknare.....	Hour meter		
45	1	1			1134-4100-01	Täckpropp.....	Plug		
49	1	1	1	1	9400-0280-03	Vippa-höjdinställning	Cover-height adjust.....		
99	1	1	1	1	9400-0290-01	Verktyg f.vippa	Tool for cover.....		Tillbehör/Accessory


Utgåva Issue 2013-11		Bildnr Picture No 2206C				PARK 2WD FOTREGLAGE		PARK 2WD FOOT CONTROLS		Sida Page 20	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes		
	6384	6311	6310	6320 6380							
1	1	1	1	1	1134-5655-01	Broms/kopplingspedal.....	Brake/clutch pedal		Sats 4 st/kit of 4		
2	1	1	1	1	1134-9024-01	Lager.....	Bearing				
3	1	1	1	1	1134-5677-02	Distans	Spacer.....				
4	1	1	1	1	9997-1070-12	Skruv.....	Screw.....				
5	1	1	1	1	9699-0030-02	Planbricka.....	Flat washer				
6	1	1	1	1	9739-1031-22	Mutter	Nut.....				
7	1	1	1	1	1134-6005-01	Wire	Cable				
8	1	1	1	1	4231-0013-00	Fjäder.....	Spring				
9	1	1	1	1	1134-6467-01	Wirefäste.....	Cable holder				
10	2	2	2	2	9959-0820-16	Skruv.....	Screw.....				
11	1	1	1	1	9739-0831-22	Mutter	Nut.....				
12	1	1	1	1	9747-0831-02	Mutter	Lock nut				
13	1	1	1	1	1134-6353-01	Drivpedal	Drive pedal.....				
14	2	2	2	2	1134-6313-01	Lager.....	Bearing				
15	2	2	2	2	1134-2700-01	Fäste.....	Bracket				
16	2	2	2	2	9959-0820-16	Skruv.....	Screw.....				
17	2	2	2	2	9739-0831-22	Mutter	Nut.....				
18	1	1	1	1	9997-0835-16	Skruv.....	Screw.....				
19	1	1	1	1	9739-0831-22	Mutter	Nut.....				
20	1	1	1	1	9959-0820-16	Skruv.....	Screw.....				
21	1	1	1	1	9739-0831-22	Mutter	Nut.....				
22	1	1	1	1	1134-2766-05	Reglagewire.....	Speed control cable.....				
23	2	2	2	2	9570-0001-00	Vinkellänk.....	Elbow link				
24	2	2	2	2	9739-0531-22	Mutter	Nut.....				
25	2	2	2	2	9747-0531-02	Mutter	Nut.....				
27	1	1	1	1	1134-6317-01	Wirefäste.....	Cable holder				
28	2	2	2	2	9959-0620-16	Skruv.....	Screw.....				
29	2	2	2	2	9739-0631-22	Mutter	Nut.....				
30	1	1	1	1	1134-3395-01	Fäste.....	Attachment				
31	2	2	2	2	9959-0820-16	Skruv.....	Screw.....				
32	2	2	2	2	9739-0831-22	Mutter	Nut.....				
33	1	1	1	1	1134-2021-01	Växelwirefäste	Clamp				
34	1	1	1	1	1134-5353-01	Bromsstång	Brake rod.....				
36	1	1	1	1	1134-2786-01	Plastknopp	Plastic knob				
37	1	1	1	1	1131-1497-01	Fjäder.....	Spring				
38	1	1	1	1	1134-4002-01	Fäste.....	Brake rod attachment				
39	3	3	3	3	9838-9516-12	Skruv.....	Screw.....				
43	2	2	2	2	1134-6340-02	Fotstöd.....	Foot rest				
44	2	4	4	4	9959-0620-16	Skruv.....	Screw.....				
45	2	4	4	4	9739-0631-22	Mutter	Nut.....				




Utgåva Issue 2013-11		Bildnr Picture No 2020H		PARK 2WD ELUTRUSTNING		PARK 2WD EL.EQUIPMENT		Sida Page 22	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6320 6384	6311	6310	6380					
1	1	1	1	1	1134-5751-01	Batteri	Battery		
2	1	1	1	1	1134-5994-01	Batteribygel	Battery loop.....		
3	1	1	1	1	1134-5995-01	Batteribygel	Battery loop.....		
4	1	1	1	1	1134-4481-02	Vingmutter	Wing nut.....		
5	1	1	1	1	9747-0631-02	Låsmutter	Lock nut		
6	1	1	1	1	1134-2962-01	Solenoid kpl	Solenoid assy		Inkl. pos 7
7	2	2	2	2	9794-5131-02	Mutter	Nut.....		
8	2	2	2	2	9852-8013-16	Skruv.....	Screw.....		
9	2	2	2	2	9699-0060-02	Planbricka.....	Flat washer.....		
10	1	1	1	1	1134-4970-02	Kabel-röd.....	Cable-red.....		
11	1	1	1	1	1134-3491-01	Säkringshållare	Fuse holder.....		
12	1	1	1	1	1134-3496-01	Säkring.....	Fuse		10A
12	1	1	1	1	1134-3496-06	Säkring.....	Fuse		20A
12	1	1	1	1	1134-3496-07	Säkring.....	Fuse		30A
13	1	1	1	1	1134-3631-01	Lock-säkringsdosa.....	Cover-fuse holder.....		
14	1	1	1	1	1134-3399-02	Brytare	Switch		
15	2	2	2	2	9943-0516-16	Skruv.....	Screw.....		
19	1	1			1134-7535-01	Honkontakt	Female terminal		
21	2	2			9840-7716-16	Skruv.....	Screw.....		
22	1	1	1	1	1134-0234-02	Batterikabel (+).....	Battery cable (+)		
23	1	1	1	1	1134-2310-01	Batteriskydd.....	Guard cap		
24	5	5	7	7	9579-0003-00	Buntband.....	Cable holder		
24	2	2			9579-0018-01	Buntband.....	Cable tie		L=390
27	1	1			1137-0075-01	Fäste.....	Bracket		
28	1	1			9959-0820-16	Skruv.....	Screw.....		
29	1	1			9739-0831-22	Mutter	Nut.....		
33	2	2			9400-0358-01	LED-lampa	LED-lamp		
34	1	1			1134-7505-01	Kablage.....	Harness.....		
37			1	1	9959-0612-16	Skruv.....	Screw.....		
38			1	1	9739-0631-22	Mutter	Nut.....		
39			1	1	1134-6454-01	Jordplåt	Ground plate.....		
40	1	1	1	1	1134-6441-01	Kablage.....	Harness.....		B&S



Utgåva Issue 2013-11		Bildnr Picture No 2021		PARK 2WD MOTOR		PARK 2WD ENGINE		Sida Page 24	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6384	6320 6311							
1	1	1		1134-6116-02	Luftring.....	Air duct.....			
2	4	4		9955-3725-16	Skruv.....	Screw.....			
3		1		1134-6100-01	Grenrör.....	Exhaust pipe.....			
3	1			1134-6334-01	Grenrör.....	Exhaust pipe.....			
4	1	1		9578-0011-01	Klämma.....	Clamp.....			
5	1	1		1134-6024-01	Ljuddämpare.....	Muffler.....			
6	1	1		9959-0820-16	Skruv.....	Screw.....			
7	1	1		9739-0831-22	Mutter.....	Nut.....			
8	1	1		1134-5827-01	Oljeavtappning kpl.....	Oil drain assy.....		Inkl. pos 9 - 12	
9	1	1		1134-5825-01	Nippel.....	Nipple.....			
10	1	1		9578-0023-04	Slangklämma.....	Hose clamp.....			
11	1	1		1134-3499-02	Slangklämma.....	Hose clamp.....			
12	1	1		1134-5826-01	Plugg.....	Plug.....			
13	1	1		1137-0206-01	Motorremskiva.....	Engine pulley.....		Ø = 85 mm	
14	1	1		1137-0208-01	Motorremskiva.....	Engine pulley.....		Ø = 139 mm	
15	1	1		9600-0251-01	Kil.....	Key.....			
16	1	1		1134-5017-01	Bricka.....	Washer.....			
17	1	1		9987-5332-16	Skruv.....	Screw.....			
18	1	1		1134-5938-01	Bränsletank.....	Fuel tank.....			
19	1	1		1134-5532-01	Tanklock.....	Fuel tank cap.....			
20	1	1		1134-3224-01	Bensinkran.....	Fuel shut-off valve.....			
21	1	1		1134-3225-01	Gummibussning.....	Grommet.....			
22	1,1	1,1		9505-0001-01	Bensinslang (meter).....	Fuel line (metre).....		Per meter	
23	1	1		9578-0023-02	Slangklämma.....	Hose clamp.....			
24	1	1		9578-0023-02	Slangklämma.....	Hose clamp.....			
25	1	1		1134-5942-01	Tankbygel.....	Tank loop.....			
26	1	1		1134-5996-01	Tankbygel.....	Tank loop.....			
27	1	1		1134-4481-02	Vingmutter.....	Wing nut.....			
28	1	1		9747-0631-02	Låsmutter.....	Lock nut.....			
29	1	1		9579-0003-00	Buntband.....	Cable holder.....			
30	1	1		9852-8013-16	Skruv.....	Screw.....			
31	1	1		1134-0433-00	Ljuddämparpackning.....	Muffler gasket.....			
32	2	2		1134-4930-01	Skruv.....	Screw.....			
50	1	1		1134-6234-01	Deflektor.....	Heat deflector.....			
51	2	2		9943-0516-16	Skruv.....	Screw.....			
52	1	1		1134-6251-01	Deflektor.....	Heat deflector.....			
53	4	4		9959-0612-16	Skruv.....	Screw.....			
54	4	4		9739-0631-22	Mutter.....	Nut.....			



Utgåva Issue 2013-11		Bildnr Picture No 2207C		PARK 2WD MOTOR		PARK 2WD ENGINE		Sida Page 26	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6310 6380								
2	4				9955-3725-16	Skruv.....	Screw.....		
3	1				1134-6339-01	Grenrör	Exhaust pipe.....		
4	1				9578-0011-01	Klämma	Clamp.....		
5	1				1134-6024-01	Ljuddämpare.....	Muffler.....		
6	1				9959-0820-16	Skruv.....	Screw.....		
7	1				9739-0831-22	Mutter	Nut.....		
8	1				1134-5827-04	Oljeavtappning kpl	Oil drain assy		Inkl. pos 9 - 12
9	1				1134-5825-01	Nippel	Nipple.....		
10	1				9578-0023-04	Slangklämma	Hose clamp.....		
11	1				1134-3499-02	Slangklämma	Hose clamp.....		
12	1				1134-5826-01	Plugg.....	Plug		
13	1				1137-0206-01	Motorremskiva	Engine pulley		Ø = 85 mm
14	1				1137-0208-01	Motorremskiva	Engine pulley		Ø = 139 mm
15	1				9600-0251-01	Kil	Key		
16	1				1134-5017-01	Bricka	Washer.....		
17	1				9987-5332-16	Skruv.....	Screw		
18	1				1134-5938-01	Bränsletank	Fuel tank.....		
19	1				1134-5532-01	Tanklock	Fuel tank cap.....		
20	1				1134-3224-01	Bensinkran.....	Fuel shut-off valve		
21	1				1134-3225-01	Gummibussning.....	Grommet		
22	1,1				9505-0001-01	Bensinslang (meter).....	Fuel line (metre).....		Per meter
23	1				9578-0023-02	Slangklämma	Hose clamp.....		
24	1				9578-0023-02	Slangklämma	Hose clamp.....		
25	1				1134-5942-01	Tankbygel	Tank loop.....		
26	1				1134-5996-01	Tankbygel	Tank loop.....		
27	1				1134-4481-02	Vingmutter.....	Wing nut.....		
28	1				9747-0631-02	Låsmutter.....	Lock nut		
29	1				9579-0003-00	Buntband.....	Cable holder		
30	1				9852-8013-16	Skruv.....	Screw.....		
32	4				9939-0820-16	Skruv.....	Screw.....		
42	1				1134-0994-02	Rörklammer.....	Tube clamp.....		
50	1				1134-6234-01	Deflektor.....	Heat deflector.....		
51	2				9943-0516-16	Skruv.....	Screw.....		
52	1				1134-6251-01	Deflektor.....	Heat deflector.....		
53	4				9959-0612-16	Skruv.....	Screw.....		
54	4				9739-0631-22	Mutter	Nut.....		




Utgåva Issue 2013-11	Bildnr Picture No 1996C	PARK 2WD TRANMISSION K 46		PARK 2WD TRANSMISSION K 46		Sida Page 28			
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6310 6380								
1	1	1	1		1134-4000-02	Spännarm.....	Tension arm.....		
2	1	1	1		1134-3459-01	Spännrulle.....	Tension roller.....		
3	1	1	1		9924-1035-16	Skruv.....	Screw.....		
4	1	1	1		9799-1031-02	Mutter.....	Nut.....		
5	1	1	1		1134-9058-01	Drivrem.....	V-belt.....		
6	1	1	1		9997-0625-16	Skruv.....	Screw.....		
7	1	1	1		9739-0631-22	Mutter.....	Nut.....		
7A	1	1	1		9747-0631-02	Låsmutter.....	Lock nut.....		
8	1	1	1		1134-3377-02	Reglagestång.....	Control rod.....		
9	1	1	1		4231-0013-00	Fjäder.....	Spring.....		
10	1	1	1		1134-4171-01	Ledtapp.....	Pivot pin.....		
11	1	1	1		1134-4183-01	Tryckfjäder.....	Compression spring.....		
12	2	2	2		1134-3456-01	Bussning.....	Bushing.....		
13	1	1	1		9747-0631-02	Låsmutter.....	Lock nut.....		
14	1	1	1		1134-1565-08	Distans.....	Spacer.....		
15	1	1	1		9930-0870-12	Skruv.....	Screw.....		
16	1	1	1		9699-0056-02	Planbricka.....	Flat washer.....		
17	1	1	1		9747-0831-02	Mutter.....	Lock nut.....		
18	1	1	1		1134-6414-01	Fjäder.....	Spring.....		
19	1	1	1		9699-0060-02	Planbricka.....	Flat washer.....		
20	1	1	1		1137-0123-01	Transaxel kpl.....	Transaxle assy.....		
21	4	4	4		9960-0860-12	Skruv.....	Screw.....		
21			4		9997-0870-16	Skruv.....	Screw.....		
22	4	4	4		9747-0831-02	Mutter.....	Lock nut.....		
23	1	1	1		1134-3913-01	Reaktionsstag.....	Strut.....		
24	1	1	1		9959-0825-16	Skruv.....	Screw.....		
25	1	1	1		9997-0845-12	Skruv.....	Screw.....		
26	1	1	1		9699-0090-02	Planbricka.....	Flat washer.....		
27	2	2	2		9747-0831-02	Mutter.....	Lock nut.....		
28	1	1	1		9747-0631-02	Låsmutter.....	Lock nut.....		
29	1	1	1		1134-2765-02	Oljetank.....	Oil tank.....		
30	1	1	1		1134-2777-02	Tanklock.....	Filler cap.....		
31	1	1	1		1134-3734-01	Luftningsplugg.....	Vent plug.....		
32	1	1	1		1134-2778-01	Fästband.....	Retainer strap.....		
33	2	2	2		9852-8013-16	Skruv.....	Screw.....		
35A	1	1	1		9578-0023-04	Slangklämma.....	Hose clamp.....		15*8
35B	1	1	1		9578-0035-01	Slangklämma.....	Hose clamp.....		14,6-17,8
36	1	1	1		1134-2779-09	Slang.....	Tube.....		L = 290 mm
39	1	1	1		1134-3203-01	Kabelgenomföring.....	Grommet.....		
40	1	1	1		1134-4015-01	Dragstång.....	Pull rod.....		
41	1	1	1		1134-4014-01	Plastknopp.....	Plastic button.....		
42	1	1	1		1134-4713-01	Vinkel.....	Bracket.....		
43	1	1	1		1134-2790-01	Gummihylsa.....	Rubber grommet.....		
44	1	1	1		9959-0820-16	Skruv.....	Screw.....		
45	1	1	1		9739-0831-22	Mutter.....	Nut.....		
46	1	1	1		9675-0009-02	Starlock.....	Starlock.....		
51	1	1	1		1134-3289-02	Remstyrning.....	Belt guide.....		
52	1	1	1		9959-0820-16	Skruv.....	Screw.....		
53	1	1	1		9699-0056-02	Planbricka.....	Flat washer.....		
54	1	1	1		9739-0831-22	Mutter.....	Nut.....		
55	1	1	1		1134-5941-01	Tankkonsol.....	Tank bracket.....		
56	2	2	2		9959-0820-16	Skruv.....	Screw.....		
57	2	2	2		9739-0831-22	Mutter.....	Nut.....		
70			2		1134-3376-01	Mellanlägg.....	Spacer plate.....		


=9585-0091-01

Kanzaki K46CI
L = 60 mm
L = 70 mm


15*8
14,6-17,8
L = 290 mm



Utgåva Issue 2013-11		Bildnr Picture No 2410A		PARK 2WD TRANMISSION K 574		PARK 2WD TRANSMISSION K 574		Sida Page 30	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6320								
1	1				1134-4000-02	Spännarm.....	Tension arm.....		
2	1				1134-3459-01	Spännrulle.....	Tension roller		
3	1				9924-1035-16	Skruv.....	Screw.....		
4	1				9799-1031-02	Mutter.....	Nut.....		
5	1				1134-9058-01	Drivrem.....	V-belt.....		=9585-0091-01
6	1				9997-0625-16	Skruv.....	Screw.....		
7	1				9739-0631-22	Mutter.....	Nut.....		
7A	1				9747-0631-02	Låsmutter.....	Lock nut		
8	1				1134-3377-02	Reglagestång.....	Control rod.....		
9	1				4231-0013-00	Fjäder.....	Spring.....		
10	1				1134-4171-01	Ledtapp.....	Pivot pin		
11	1				1134-4183-01	Tryckfjäder.....	Compression spring		
12	2				1134-3456-01	Bussning.....	Bushing		
13	1				9747-0631-02	Låsmutter.....	Lock nut		
14	1				1134-1565-08	Distans.....	Spacer.....		
15	1				9997-0870-16	Skruv.....	Screw.....		
16	1				9699-0056-02	Planbricka.....	Flat washer		
17	1				9747-0831-02	Mutter.....	Lock nut		
18	1				1134-6414-01	Fjäder.....	Spring.....		
19	1				9699-0060-02	Planbricka.....	Flat washer		
20	1				1137-0126-01	Transaxel kpl.....	Transaxle assy		Kanzaki K57V
21	4				9960-0860-12	Skruv.....	Screw.....		L = 60 mm
22	4				9747-0831-02	Mutter.....	Lock nut		
23	1				1134-3913-01	Reaktionsstag.....	Strut.....		
24	1				9959-0825-16	Skruv.....	Screw.....		
25	1				9997-0845-12	Skruv.....	Screw.....		
26	1				9699-0090-02	Planbricka.....	Flat washer		
27	2				9747-0831-02	Mutter.....	Lock nut		
28	1				9747-0631-02	Låsmutter.....	Lock nut		
29	1				1134-2765-02	Oljetank.....	Oil tank.....		
30	1				1134-2777-02	Tanklock.....	Filler cap		
31	1				1134-3734-01	Luftningsplugg.....	Vent plug		
32	1				1134-2778-01	Fästband.....	Retainer strap		
33	2				9852-8013-16	Skruv.....	Screw.....		
35A	1				9578-0023-04	Slangklämma.....	Hose clamp.....		15*8
35B	1				9578-0035-01	Slangklämma.....	Hose clamp.....		14,6-17,8
36	1				1134-2779-09	Slang.....	Tube.....		L = 290 mm
39	1				1134-3203-01	Kabelgenomföring.....	Grommet		
40	1				1134-4015-01	Dragstång.....	Pull rod.....		
41	1				1134-4014-01	Plastknopp.....	Plastic button.....		
42	1				1134-4713-01	Vinkel.....	Bracket		
43	1				1134-2790-01	Gummihylsa.....	Rubber grommet		
44	1				9959-0820-16	Skruv.....	Screw.....		
45	1				9739-0831-22	Mutter.....	Nut.....		
46	1				9675-0009-02	Starlock.....	Starlock		
51	1				1134-3289-02	Remstyrning.....	Belt guide		
52	1				9959-0820-16	Skruv.....	Screw.....		
53	1				9699-0056-02	Planbricka.....	Flat washer		
54	1				9739-0831-22	Mutter.....	Nut.....		
55	1				1134-5941-01	Tankkonsol.....	Tank bracket.....		
56	2				9959-0820-16	Skruv.....	Screw.....		
57	2				9739-0831-22	Mutter.....	Nut.....		
62	1				1134-7245-01	Adapter-rak.....	Coupling-straight		
63	1				1134-4948-01	Tredobricka.....	Seal washer		
64	1				1134-6042-01	Snabbkoppling-hane.....	Quick coupling-male.....		



Utgåva Issue 2013-11		Bildnr Picture No 1346E		PARK 2WD HJUL		PARK 2WD WHEEL		Sida Page 32	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6384 6311 6310 6380	6320							
1	2	2		1134-0075-00	Framaxeltapp	Front axle			
2	2	2		9595-0258-00	Spännstift	Locating pin			
3	2	2		1134-4844-05	Hjulnav kpl	Wheel hub Assy			
3A	1A	1A		9501-0500-00	Smörjnippel	Grease joint			
4	1	1		1134-9026-01	Lagerbussning.....	Bearing bush kit		Sats 4 st/kit of 4	
5	2	2		1134-4558-01	Fälg	Rim.....			
6	2	2		9545-0116-00	Däck.....	Tyre		16 x 7.50 - 8	
7	2	2		9545-0500-00	Ventil.....	Valve			
8	6	6		9731-1031-22	Mutter	Nut.....			
10	6	6		1134-0341-01	Bricka	Washer.....		20,5x36x1,5 mm	
11	2	2		9599-0080-02	Saxsprint	Cotter pin			
12	2	2		1134-4844-02	Hjulnav	Wheel hub			
13	2	2		1134-4558-01	Fälg	Rim.....			
14	2	2		9545-0116-00	Däck.....	Tyre		16 x 7.50 - 8	
15	2	2		9545-0500-00	Ventil.....	Valve			
16	6	6		9731-1031-22	Mutter	Nut.....			
18	2	2		1134-4796-01	Navkapsel	Hub cap			
19	2	2		9947-0540-19	Skruv.....	Screw.....			
20	2	2		1134-2471-01	Kil	Key			
21	2	2		1134-0341-01	Bricka	Washer.....		20,5x36x1,5 mm	
22	2	2		9653-0001-04	Spårryttare	Lock ring			
26	2	2		9699-0042-02	Planbricka	Flat washer		20x36x3,0 mm	
45	1	1		13-0992-61	Snabbfäste kpl	Quick connections.....		Inkl. pos 11,26,46-51	
46	1	1		1134-7465-01	Fästen kpl, vä+hö	Attachment kit, LH+RH....		Inkl. pos 50-51	
47	2	2		1137-0077-01	Låssprint	Locking pin			
48	2	2		9548-0026-01	Glidlager	Bearing.....			
50	2	2		9898-1035-16	Skruv.....	Screw.....			
51	2	2		9739-1031-22	Mutter	Nut.....			
99				9545-0203-00	Innerslang	Inner tube		Reservdel/spare part	



Utgåva Issue 2013-11		Bildnr Picture No 1030H		PARK 2WD KRAFTUTTAG		PARK 2WD POWER TAKE-OFF		Sida Page 34
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6384 6311 6310 6380	6320						
1	1			1134-5548-01	Distans	Spacer		Inkl. pos 3A-3B
2	1			1134-5109-01	Spännhjularm	Tension wheel arm		
3	1			1137-0128-01	Spännrulle kpl.....	Tension roller assy		
3A	1			9549-0019-00	Kullager	Ball bearing		Inkl. pos 11-12
3B	1			9651-0040-04	Låsring	Retaining ring.....		
4	1			1134-1888-04	Distans	Spacer		
5	1			1134-5111-01	Fjäder	Spring		=9585-0213-01
6	1			9699-0056-02	Planbricka	Flat washer		
7	1			9739-0831-22	Mutter	Nut		
8	1			9997-0855-12	Skruv	Screw		=9585-0213-01
10	1			1137-0209-01	Centrumremskiva kpl	Centre pulley assy		
11	1			1134-0051-09	Distans	Spacer		
12	2			9549-0019-00	Kullager	Ball bearing		=9585-0213-01
13	1			1134-5112-01	Fjäderfäste	Spring attachment		
14	2			9945-0816-16	Skruv	Screw		
15	1			1134-5110-01	Hake	Hook		=9585-0213-01
16	2			9893-0616-16	Skruv	Screw		
18	1			1134-2018-02	Spännarm	Tension arm		
19	1			1134-9027-02	Spännrulle-grå	Tension roller-grey		=9585-0213-01
20	1			1134-9173-01	Drivrem	V-belt		
21	1			9997-1030-16	Skruv	Screw		
22	1			9799-1031-02	Mutter	Nut		=9585-0213-01
23	1			1134-4111-01	Bromsarm	Brake arm		
24	1			1134-4164-03	Bromsklots	Brake pad		
25	1			9897-0825-16	Skruv	Screw		=9585-0213-01
26	1			9747-0831-02	Mutter	Lock nut		
27	1			1134-4162-01	Bromsstång	Brake rod		
28	1			9675-0008-02	Starlock	Locking washer		=9585-0213-01
29	1			1134-4170-01	Nippel	Nipple		
30	1			9699-0025-02	Planbricka	Washer		
31	1			9747-0631-02	Låsmutter	Lock nut		=9585-0213-01
32	1			4231-0013-00	Fjäder	Spring		
33	1			1134-4231-01	Dragfjäder	Spring		
34	1			1134-1565-10	Distans	Spacer		=9585-0213-01
35	1			9997-0860-12	Skruv	Screw		
36	1			9699-0056-02	Planbricka	Flat washer		
37	1			9739-0831-22	Mutter	Nut		=9585-0213-01
38	1			1134-4163-01	Ansatsskruv	Shoulder bolt		
39	1			9731-1031-22	Mutter	Nut		
40	1			1134-3958-01	Remstyrning	Belt guide		=9585-0213-01
41	2			9893-0616-16	Skruv	Screw		
42	1			1134-0041-03	Hylsa	Collar		
43	1			9997-1070-12	Skruv	Screw		=9585-0213-01
44	1			9739-1031-22	Mutter	Nut		
45	1			1134-3654-01	Fingerskydd	Finger guard		
46	2			9959-0612-16	Skruv	Screw		=9585-0213-01
47	2			9739-0631-22	Mutter	Nut		
48	1			9699-0090-02	Planbricka	Flat washer		
49	2			9699-0035-02	Planbricka	Flat washer		