



www.stiga.com

Illustrated Parts List

for model:

Park Compact 2 WD

- Use GLOBAL GARDEN PRODUCT genuine spare parts specified in the parts list for repair and/or replacement.
- Then contents described in the parts list may change due to improvement.
- The drawings of the spare part are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.









© Copyright 2014 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.



THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.

www.ggp-group.com








Utgåva Issue 2014-11		Bildnr Picture No 1638D		PARK 2WD MONTERINGSDETALJER		PARK 2WD ASSEMBLY PARTS		Sida Page 2	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
2	1				1134-6113-01	Batteriskruvar	Battery screws		
4	2				9595-0262-00	Spännstift.....	Locating pin		
5A	1				9699-0103-02	Shims	Flat washer		0.5 mm
5B	1				9699-0114-02	Shims	Flat washer		1.0 mm
6	2				1134-4185-01	Ansatsbricka	Flange washer		
7	2				9959-0820-16	Skruv.....	Screw.....		
8	2				1134-4481-01	Vingmutter	Wing nut.....		
9	4				9699-0056-02	Planbricka.....	Flat washer		
10	2				1134-4734-01	Tändningsnyckel.....	Ignition key		
12	2				9997-0820-16	Skruv.....	Screw.....		
13	1				1134-5512-01	Dragplåt	Towing plate.....		
14	2				9959-0820-16	Skruv.....	Screw.....		
15	2				9739-0831-22	Mutter	Nut.....		
18	2				9898-1035-16	Skruv.....	Screw.....		
19	2				9739-1031-22	Mutter	Nut.....		
31	1					Bruksanvisning.....	Owners manual		As PDF




Utgåva Issue 2014-11		Bildnr Picture No 1658B		PARK 2WD KAROSS		PARK 2WD BODY WORK		Sida Page 4	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-5263-02	Motorhuv-gul.....	Engine hood-yellow		Sats 3 st/kit of 3
2	7				9838-9530-12	Skruv.....	Screw.....		
3	1				1134-9028-01	Gummistropp-sats	Rubber strap kit.....		
4	1				9632-0516-00	Popnit.....	Pop rivet.....		
5	1				9699-0120-02	Bricka	Washer.....		
6	1				1134-5264-01	Motorlucka-grå.....	Engine cover-grey		
7	1				1134-5308-01	Stänkskärm vä-grå.....	Mud guard LH-grey		
8	1				1134-5308-02	Stänkskärm hö-grå.....	Mud guard RH-grey		
9	4				9893-0616-16	Skruv.....	Screw.....		
10	4				1134-4176-01	Clips.....	Clips		
11	2				1137-0088-01	Stödplåt.....	Support plate		
12	6				9945-0816-16	Skruv.....	Screw.....		
13	4				9699-0056-02	Planbricka	Flat washer		
14	1				1134-5306-01	Stötfångare, front-vä.....	Bumper, front-LH		
15	1				1134-5306-02	Stötfångare, front-hö.....	Bumper, front-RH		
16	2				9893-0616-16	Skruv.....	Screw.....		
18	1				1134-5305-01	Front-nedre	Front plate-lower.....		
19	2				9893-0616-16	Skruv.....	Screw.....		
20	1				1134-5320-02	Front-övre	Front-upper		
21	2				9946-0525-16	Skruv.....	Screw.....		
22	1				1134-6241-01	Huvstöd.....	Hood support.....		
23	3				9893-0616-16	Skruv.....	Screw.....		
24	1				1134-3970-05	Kantlist-vä, grå	Moulding-LH, grey		
25	1				1134-3970-02	Kantlist-hö, grå	Moulding-RH, grey.....		
26	2				9893-0616-16	Skruv.....	Screw.....		
27	2				9699-0060-02	Planbricka	Flat washer		
28	2				9747-0631-02	Låsmutter.....	Lock nut		
29	2				9897-0616-16	Vagnsbult	Carriage bolt.....		
99	1				1134-6440-02	Dekalsats.....	Label kit		




Utgåva Issue 2014-11		Bildnr Picture No 1669D		PARK 2WD RAM		PARK 2WD FRAME		Sida Page 6	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1137-0388-01	Ram-främre.....	Frame-front		Inkl. pos 2-5 Rak/straight 90°
2	1				1134-3963-02	Midjegaffel	Clevis		
3	1				1134-0031-00	Ledaxelstopp.....	Pivot shaft stop.....		
4	1				9595-0262-00	Spännstift.....	Locating pin		
5A	1				9501-0500-00	Smörjnippel	Grease joint		
5B	1				9501-0504-01	Smörjnippel	Grease joint		
6	1				1134-2171-01	Fjäder.....	Spring		
7	1				1134-6466-02	Ram-bakre	Frame-rear.....		
8	1				1134-5705-01	Distans	Spacer.....		
9	2				9547-0001-00	Ledlager.....	Bearing		
10	2				9501-0500-00	Smörjnippel	Grease joint		
11	1				1134-5988-01	Centrumaxel	Centre shaft		
13	2				9699-0035-02	Planbricka	Flat washer		
14	2				9959-1025-16	Skruv.....	Screw.....		
16	1				1134-6586-01	Durk.....	Floor plate		
17	1				1134-6372-04	Durkmatta.....	Floor mat.....		
18	2				9893-0616-16	Skruv.....	Screw.....		
19	2				9403-0048-70	Täckpropp.....	Plug		
20	2				9945-0816-16	Skruv.....	Screw.....		
21	2				9959-0820-16	Skruv.....	Screw.....		
22	2				9739-0831-22	Mutter	Nut.....		
28	1				1134-4975-01	Gummibuffert	Rubber block.....		
29	1				9950-0570-12	Skruv.....	Screw.....		
30	2				9739-0531-22	Mutter	Nut.....		
31	1				1134-5337-02	Stötfångare-bak, grå	Bumper-rear, grey		
32	2				1134-0240-00	Ansatsskruv	Shoulder screw		
33	2				1134-4242-01	Distansbricka	Spacer washer		
34	2				9665-0002-00	Brickfjäder.....	Bowed washer		
35	2				9747-0831-02	Mutter	Lock nut		
36	2				9943-0516-16	Skruv.....	Screw.....		
37	2				1134-5345-01	Stag	Attachment		
38	1				1134-5344-01	Batterihylla	Battery shelf.....		
39	4				9945-0816-16	Skruv.....	Screw.....		




Utgåva Issue 2014-11		Bildnr Picture No 1023D		PARK 2WD PEDALLYFT		PARK 2WD PEDAL LIFT		Sida Page 8	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-4117-01	Fäste.....	Bracket		
2	2				1134-2684-01	Lager.....	Bearing		
3	1				1134-4945-01	Lyftspärr kpl	Lift catch assy		
7	1				9404-0027-01	O-ring	O-ring		
8	1				9650-0039-04	Seegersäkring	Lock ring		
9	1				9595-0276-01	Spännstift.....	Locating pin		
10	1				9997-0640-12	Skruv.....	Screw.....		
11	1				9747-0631-02	Låsmutter.....	Lock nut		
13	1				9897-0820-16	Skruv.....	Screw.....		
14	1				9747-0831-02	Mutter	Lock nut		
15	1				1134-4860-01	Lyftgaffel	Lift fork		
16	2				1134-0240-00	Ansattsskruv	Shoulder screw.....		
17	1				1134-4938-01	Lyftpedal.....	Lift pedal		
18	2				9997-0625-16	Skruv.....	Screw.....		
19	2				9739-0631-22	Mutter	Nut.....		
20	1				4231-0013-00	Fjäder.....	Spring.....		





Utgåva Issue 2014-11		Bildnr Picture No 1657B		PARK 2WD SITS		PARK 2WD SEAT		Sida Page 10	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
2	1				1134-6444-01	Sits	Seat.....		
3	1				1134-5301-01	Sitsplatta	Seat plate.....		
4	2				1134-0240-00	Ansatssskruv	Shoulder screw.....		
5	2				9747-0831-02	Mutter	Lock nut		
6	1				1134-5454-01	Spärr	Catch		
7	1				9675-0012-02	Starlock.....	Locking washer.....		
10	4				9893-0616-16	Skruv.....	Screw.....		
11	1				1134-5300-01	Bakstycke-gul.....	Rear plate-yellow.....		
12	1				1134-5296-04	Sitskonsol-gul.....	Seat bracket-yellow.....		
13	1				1134-4256-01	Sitsfjäder.....	Seat spring.....		
14	1				9924-1235-19	Skruv.....	Screw.....		
15	1				9747-1231-02	Låsmutter.....	Lock nut		
16	1				9997-0840-12	Skruv.....	Screw.....		
17	1				1134-1565-06	Distans	Spacer.....		
18	1				1134-5302-01	Fjäder.....	Spring.....		
19	1				1134-5299-01	Tryckplatta.....	Push plate		
20	1				9699-0090-02	Planbricka.....	Flat washer		
21	1				9747-0831-02	Mutter	Lock nut		
22	1				1134-3156-02	Brytare (grå)	Switch (grey).....		
26	2				9897-0880-12	Skruv.....	Screw.....		L = 80 mm
27	2				1134-1565-08	Distans	Spacer.....		
28	4				9897-0820-16	Skruv.....	Screw.....		L = 20 mm
29	6				9747-0831-02	Mutter	Lock nut		




- 2
- 3
- 7
- 8
- 9
- 10
- 11
- 12
- 13
- 14














Utgåva Issue 2014-11		Bildnr Picture No 1670B		PARK 2WD HANDREGLAGE		PARK 2WD HAND CONTROLS		Sida Page 14	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-6301-01	Aggregatsspak	Engagement lever.....		
2	1				1134-2551-01	Reglageknopp	Knob.....		
3	1				1134-3790-02	Lager.....	Bearing		
4	1				9699-0090-02	Planbricka	Flat washer		
5	1				4231-0013-00	Fjäder	Spring		
6	1				1134-5368-01	Panel	Dashboard		
7	1				9400-0360-01	Mikrobrytare	Micro switch		
8	4				9946-0525-16	Skruv.....	Screw.....		
9	1				1134-3573-05	Reglagewire.....	Control cable.....		
20	1				1134-5465-02	Gasreglage	Throttle lever.....		
21	1				1134-4078-01	Knopp	Knob.....		
22	1				1134-5464-01	Fäste.....	Bracket		
23	1				1134-0240-00	Ansattsskruv	Shoulder screw.....		
24	2				1134-4242-01	Distansbricka	Spacer washer		
25	1				9694-0001-00	Fjäderbricka	Washer.....		
26	1				9747-0831-02	Mutter	Lock nut		
27	1				1134-4197-03	Gaswire	Throttle cable		
28	1				9500-9991-00	Wireklämma	Cable clamp		
29	1				9943-0516-16	Skruv.....	Screw.....		








Utgåva Issue 2014-11		Bildnr Picture No 2026A		PARK 2WD FOTREGLAGE		PARK 2WD FOOT CONTROLS		Sida Page 16	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6102	6103	6100						
1	1				1134-5655-01	Broms/kopplingspedal.....	Brake/clutch pedal		Sats 4 st/kit of 4
2	1				1134-9024-01	Lager.....	Bearing		
3	1				1134-5677-02	Distans	Spacer.....		
4	1				9997-1070-12	Skruv.....	Screw.....		
5	1				9699-0030-02	Planbricka.....	Flat washer		
6	1				9739-1031-22	Mutter	Nut.....		
7	1				1134-6005-01	Wire	Cable		
8	1				4231-0013-00	Fjäder.....	Spring		
9	1				1134-6467-01	Wirefäste.....	Cable holder.....		
10	2				9959-0820-16	Skruv.....	Screw.....		
11	1				9739-0831-22	Mutter	Nut.....		
12	1				9739-0831-22	Mutter	Nut.....		
13	1				1134-6353-01	Drivpedal	Drive pedal.....		
14	2				1134-6313-01	Lager.....	Bearing		
15	2				1134-2700-01	Fäste.....	Bracket		
16	2				9959-0820-16	Skruv.....	Screw.....		
17	2				9739-0831-22	Mutter	Nut.....		
18	1				9997-0835-16	Skruv.....	Screw.....		
19	1				9739-0831-22	Mutter	Nut.....		
22	1				1134-2766-05	Reglagewire.....	Speed control cable.....		
23	2				9570-0001-00	Vinkellänk.....	Elbow link.....		
24	2				9739-0531-22	Mutter	Nut.....		
25	2				9747-0531-02	Mutter	Nut.....		
26	1				1134-6317-01	Wirefäste.....	Cable holder.....		
28	2				9959-0620-16	Skruv.....	Screw.....		
29	2				9739-0631-22	Mutter	Nut.....		
30	1				1134-3395-01	Fäste.....	Attachment.....		
31	2				9959-0820-16	Skruv.....	Screw.....		
32	2				9739-0831-22	Mutter	Nut.....		
33	1				1134-2021-01	Växelwirefäste.....	Clamp.....		
34	1				1134-5353-01	Bromsstång	Brake rod.....		
35	1				1134-2786-01	Plastknopp	Plastic knob		
36	1				1131-1497-01	Fjäder.....	Spring		
37	1				1134-4002-01	Fäste.....	Brake rod attachment		
38	3				9838-9516-12	Skruv.....	Screw		




Utgåva Issue 2014-11		Bildnr Picture No 1671G		PARK 2WD ELUTRUSTNING		PARK 2WD EL. EQUIPMENT		Sida Page 18	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6102 6103	6100							
1	1	1		1134-4804-01	Batteri	Battery			
2	1			1134-5769-01	Kablage.....	Harness.....			
2		1		1137-0455-01	Kablage.....	Harness.....			
2A	1	1		9400-0327-01	Säkringshållare	Fuse holder.....		Inkl. pos 2B 20A	
2B	1	1		1134-3496-06	Säkring.....	Fuse			
3	1	1		1134-5343-01	Batterikonsol.....	Battery bracket.....			
4	3	3		9852-8013-16	Skruv.....	Screw.....			
5	2	2		9699-0060-02	Planbricka.....	Flat washer			
6	1	1		1134-2962-01	Solenoid kpl.....	Solenoid assy		nkl. pos 8	
7	2	2		9852-8013-16	Skruv.....	Screw.....			
8	2	2		9794-5131-02	Mutter	Nut.....			
9	1	1		1134-4093-01	Tändningslås.....	Ignition switch			
10	1	1		1134-4749-01	Mutter	Nut.....			
11	1	1		1134-5245-01	Batterirem.....	Battery strap			
12	1			1134-2167-01	Kabel.....	Cable			
12		1		1134-2167-02	Kabel.....	Cable			
13	1	1		1134-0234-02	Batterikabel (+).....	Battery cable (+)			
14	1	1		1134-2310-01	Batteriskydd.....	Guard cap			
15	1	1		9795-3531-02	Mutter	Nut.....		1/4" UNC	
16	15	15		9579-0003-00	Buntband.....	Cable holder			
25	1	1		1134-3399-02	Brytare	Switch			
26	2	2		9997-0520-16	Skruv.....	Screw.....			
27	2	2		9747-0531-02	Mutter	Nut.....			
28		1		1134-6454-01	Jordplåt	Ground plate.....			
29		2		9959-0612-16	Skruv.....	Screw.....			
30		2		9739-0631-22	Mutter	Nut.....			
32		1		1137-0441-01	Fäste.....	Bracket			
33		2		9945-0816-16	Skruv.....	Screw.....			






Utgåva Issue 2014-11		Bildnr Picture No 1672E		PARK 2WD MOTOR B&S		PARK 2WD ENGINE B&S		Sida Page 20	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6103	6102							
1	4	4		9955-3725-16	Skruv.....	Screw.....		3/8" UNC x 25 mm	
3A		1		1134-5370-01	Ljuddämpare.....	Muffler.....			
3A	1			1134-7784-01	Ljuddämpare.....	Muffler.....			
4	1	1		1134-0433-00	Ljuddämparpackning.....	Muffler gasket.....			
5	2	2		1134-4930-01	Skruv.....	Screw.....			
6	1	1		9959-0820-16	Skruv.....	Screw.....			
7	1	1		9739-0831-22	Mutter.....	Nut.....			
8	1	1		1134-5390-01	Dragkroksbalk.....	Tow bar bracket.....			
9	4	4		9945-0816-16	Skruv.....	Screw.....			
14	1	1		1137-0082-01	Motorremskiva.....	Engine pulley.....			Ø = 139 mm Ø = 85 mm L = 2 1/2"
15	1	1		1137-0007-01	Motorremskiva.....	Engine pulley.....			
16	1	1		9600-0251-01	Kil.....	Key.....			
17	1	1		1134-5017-01	Bricka.....	Washer.....			
18	1	1		9987-5332-16	Skruv.....	Screw.....			
19	1	1		1134-6618-01	Bränsletank.....	Fuel tank.....			
20	1	1		1134-5532-01	Tanklock.....	Fuel tank cap.....			
21	1	1		1134-3224-01	Bensinkran.....	Fuel shut-off valve.....			
22	1	1		1134-3225-01	Gummibussning.....	Grommet.....			
23	0,52	0,52		9505-0001-01	Bensinslang (meter).....	Fuel line (metre).....			Per meter
24	1	1		9578-0023-02	Slangklämma.....	Hose clamp.....			
25	1	1		1134-6627-01	Tankkonsol.....	Fuel tank bracket.....			
26	2	2		9959-0820-16	Skruv.....	Screw.....			
27	2	2		9739-0831-22	Mutter.....	Nut.....			
28	2	2		1134-5346-01	Tankbygel.....	Fuel tank loop.....			
29	2	2		9747-0631-02	Låsmutter.....	Lock nut.....			
30	1	1		9579-0003-00	Buntband.....	Cable holder.....			
40	1	1		9578-0023-02	Slangklämma.....	Hose clamp.....			
41	1	1		1134-5827-01	Oljeavtappning kpl.....	Oil drain assy.....		Inkl. pos 42 - 45	
42	1	1		1134-5825-01	Nippel.....	Nipple.....			
43	1	1		9578-0023-04	Slangklämma.....	Hose clamp.....			
44	1	1		1134-3499-02	Slangklämma.....	Hose clamp.....			
45	1	1		1134-5826-01	Plugg.....	Plug.....			




Utgåva Issue 2014-11		Bildnr Picture No 2902		PARK 2WD MOTOR HONDA		PARK 2WD ENGINE HONDA		Sida Page 22	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6100								
1	2				9987-5132-12	Skruv.....	Screw.....		Engine part
2	2				9699-0056-02	Bricka	Washer.....		
3	2				9997-0845-12	Skruv.....	Screw.....		
4	2				9747-0831-02	Mutter	Nut.....		
5	1				1137-0444-01	Ljuddämpare.....	Muffler		
6						Ljuddämparpackning.....	Muffler gasket.....		
7	2				9935-0820-16	Skruv.....	Screw.....		
8	1				9959-0820-16	Skruv.....	Screw.....		
9	1				9739-0831-22	Mutter	Nut.....		
10	1				1134-5390-01	Dragkroksbalk	Tow bar bracket.....		
11	4				9945-0816-16	Skruv.....	Screw.....		
12	1				1137-0445-01	Distans	Spacer.....		
13	1				1137-0206-01	Motorremskiva	Engine pulley		
14	1				1137-0208-01	Motorremskiva	Engine pulley		
15	1				9600-0251-01	Kil	Key.....		
16	1				1134-50174-01	Bricka	Washer.....		
17	1				9987-5332-16	Skruv.....	Screw.....		
18	1				1134-6618-01	Bränsletank	Fuel tank.....		
19	1				1134-5532-01	Tanklock	Fuel tank cap		
20	1				1134-3224-01	Bensinkran	Fuel shut-off valve		
21	1				1134-3225-01	Gummibussning.....	Grommet		
22	0,52				9505-0001-01	Bensinslang.....	Fuel line	Per meter	
22	2				9578-0023-02	Slangklämma	Hose clamp.....		
23	1				1134-6627-01	Tankkonsol	Fuel tank bracket.....		
24	2				9959-0820-16	Skruv.....	Screw.....		
25	2				9739-0831-22	Mutter	Nut.....		
26	2				1134-5346-01	Tankbygel	Fuel tank loop		
27	2				112154510/0	Mutter	Nut.....		
30	1				1137-0095-01	Fäste-bränslepump.....	Bracket-fuel pump		
31	2				9939-0820-16	Skruv.....	Screw.....		
32	1				1137-0114-01	Bränslepump.....	Fuel pump		
33	2				9893-0616-16	Skruv.....	Screw.....		
34	4				9578-0023-07	Slangklämma	Hose clamp.....		
35	1				1137-0103-01	T-rör	Joint pipe.....		
36	0,04				9505-0001-01	Bensinslang.....	Fuel hose	Per meter	
37	2				9578-0023-02	Slangklämma	Hose clamp.....		
38	1				1134-5827-05	Oljeavtappning kpl	Oil drain assy		
39	1				1134-5825-01	Nippel	Nipple.....		
40	1				9578-0023-04	Slangklämma	Hose clamp.....		
41	1				1134-3499-02	Slangklämma	Hose clamp.....		
42	1				1134-5826-01	Plugg.....	Plug		
43	1				1137-0415-01	Adapter	Adapter.....		
50	2				1137-0442-01	Fäste	Bracket		



Utgåva Issue 2014-11		Bildnr Picture No 1668B		PARK 2WD TRANSMISSION		PARK 2WD TRANSMISSION		Sida Page 24
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6103 6102	6100						
1	1	1		1134-4000-02	Spännarm.....	Tension arm.....		
2	1	1		1134-3459-01	Spännrulle.....	Tension roller.....		
3	1	1		9924-1035-16	Skruv.....	Screw.....		
4	1	1		9799-1031-02	Mutter.....	Nut.....		
5	1	1		1134-9058-01	Drivrem.....	V-belt.....		
6	1	1		9997-0625-16	Skruv.....	Screw.....		
7	1	1		9739-0631-22	Mutter.....	Nut.....		
7A	1	1		9747-0631-02	Låsmutter.....	Lock nut.....		
8	1	1		1134-3377-02	Reglagestång.....	Control rod.....		
9	1	1		4231-0013-00	Fjäder.....	Spring.....		
10	1	1		1134-4171-01	Ledtapp.....	Pivot pin.....		
11	1	1		1134-4183-01	Tryckfjäder.....	Compression spring.....		
12	2	2		1134-3456-01	Bussning.....	Bushing.....		
13	1	1		9747-0631-02	Låsmutter.....	Lock nut.....		
14	1	1		1134-1565-08	Distans.....	Spacer.....		
15	1	1		9997-0870-16	Skruv.....	Screw.....		
16	1	1		9699-0056-02	Planbricka.....	Flat washer.....		
17	1	1		9747-0831-02	Mutter.....	Lock nut.....		
18	1	1		1134-6414-01	Fjäder.....	Spring.....		
19	1	1		9699-0060-02	Planbricka.....	Flat washer.....		
20	1	1		1137-0123-01	Transaxel kpl.....	Transaxle assy.....		
21	4	4		9960-0860-12	Skruv.....	Screw.....		Kanzaki K46CI
22	4	4		9747-0831-02	Mutter.....	Lock nut.....		
23	1	1		1134-3913-01	Reaktionsstag.....	Strut.....		
24	1	1		9959-0825-16	Skruv.....	Screw.....		
25	1	1		9997-0845-12	Skruv.....	Screw.....		
26	1	1		9699-0090-02	Planbricka.....	Flat washer.....		
27	2	2		9747-0831-02	Mutter.....	Lock nut.....		
28	1	1		9747-0631-02	Låsmutter.....	Lock nut.....		
29	1	1		1134-2765-02	Oljetank.....	Oil tank.....		
30	1	1		1134-2777-02	Tanklock.....	Filler cap.....		
31	1	1		1134-3734-01	Luftningsplugg.....	Vent plug.....		
32	1	1		1134-2778-01	Fästband.....	Retainer strap.....		
33	2	2		9852-8013-16	Skruv.....	Screw.....		
34	2	2		9699-0099-02	Bricka.....	Washer.....		
35	2	2		9578-0035-01	Slangklämma.....	Hose clamp.....		14,6-17,8
36	1			1134-2779-07	Slang.....	Tube.....		L = 140 mm
36		1		1134-2779-12	Slang.....	Tube.....		L = 205 mm
40	1	1		1134-4015-01	Dragstång.....	Pull rod.....		
41	1	1		1134-4014-01	Plastknopp.....	Plastic button.....		
42	1	1		1134-4713-01	Vinkel.....	Bracket.....		
42	1	1		1134-2790-01	Gummihylsa.....	Rubber grommet.....		
44	1	1		9959-0820-16	Skruv.....	Screw.....		
45	1	1		9739-0831-22	Mutter.....	Nut.....		
46	1	1		9675-0009-02	Starlock.....	Starlock.....		
51	1	1		1134-3289-02	Remstyrning.....	Belt guide.....		
52	1	1		9959-0820-16	Skruv.....	Screw.....		
53	1	1		9699-0056-02	Planbricka.....	Flat washer.....		
54	1	1		9739-0831-22	Mutter.....	Nut.....		
55		2		1134-3376-01	Mellanlägg.....	Space plate.....		



Utgåva Issue 2014-11		Bildnr Picture No 1346E		PARK 2WD HJUL		PARK 2WD WHEEL		Sida Page 24	
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	6102	6103 6100							
1	2	2		1134-0075-00	Framaxeltapp	Front axle			
2	2	2		9595-0258-00	Spännstift	Locating pin			
3	2	2		1134-4844-05	Hjulnav kpl	Wheel hub Assy			
3A	1	1		9501-0500-00	Smörjnippel	Grease joint			
4	1	1		1134-9026-01	Lagerbussning	Bearing bush kit		Sats 4 st/kit of 4	
5		2		1134-4558-01	Fälg	Rim			
5	2			1134-5255-01	Fälg	Rim			
6		2		9545-0116-00	Däck	Tyre		16 x 7.50 - 8	
6	2			9545-0126-01	Däck	Tyre		16 x 6.00 - 8	
7	2	2		9545-0500-00	Ventil	Valve			
8	6	6		9731-1031-22	Mutter	Nut			
10	4	4		1134-0341-01	Bricka	Washer		20,5 x 36 x 1,5 mm	
11	2	2		9599-0080-02	Saxsprint	Cotter pin			
12	2	2		1134-4844-02	Hjulnav	Wheel hub			
13		2		1134-4558-01	Fälg	Rim			
13	2			1134-5255-01	Fälg	Rim			
14		2		9545-0116-00	Däck	Tyre		16 x 7.50 - 8	
14	2			9545-0126-01	Däck	Tyre		16 x 6.00 - 8	
15	2	2		9545-0500-00	Ventil	Valve			
16	6	6		9731-1031-22	Mutter	Nut			
18	2	2		1134-4796-01	Navkapsel	Hub cap			
19	2	2		9947-0540-19	Skruv	Screw			
20	2	2		1134-2471-01	Kil	Key		L = 58 mm	
21	2	2		1134-0341-01	Bricka	Washer		20,5 x 36 x 1,5 mm	
22	2	2		9653-0001-04	Spärryttare	Lock ring			
26	2	2		9699-0042-02	Planbricka	Flat washer		20 x 36 x 3,0 mm	
45	1	1		13-0992-61	Snabbfäste kpl	Quick connections		Inkl. pos 11,26,46-51	
46	1	1		1134-7465-01	Fästen kpl, vä+hö	Attachment kit, LH+RH.....		Inkl. pos 50-51	
47	2	2		1137-0077-01	Låssprint	Locking pin			
48	2	2		9548-0026-01	Glidlager	Bearing			
50	2	2		9898-1035-16	Skruv	Screw			
51	2	2		9739-1031-22	Mutter	Nut			
99				9545-0203-00	Innerslang	Inner tube		Reservdel/spare part	



Utgåva Issue		Bildnr Picture No		PARK 2WD KRAFTUTTAG		PARK 2WD PTO		Sida Page	
2014-11		1030E						24	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6100	6103	6102						
1	1				1134-5548-01	Distans	Spacer		
2	1				1134-5109-01	Spännhjularm	Tension wheel arm		
3	1				1137-0128-01	Spännrulle kpl.....	Tension roller assy		Inkl. pos 3A-3B
3A	1				9549-0019-00	Kullager	Ball bearing		
3B	1				9651-0040-04	Låsring	Retaining ring.....		
4	1				1134-1888-04	Distans	Spacer		
5	1				1134-5111-01	Fjäder	Spring		
6	1				9699-0056-02	Planbricka	Flat washer		
7	1				9739-0831-22	Mutter	Nut		
8	1				9997-0855-12	Skruv	Screw		
10	1				1137-0004-01	Centrumremskiva kpl	Centre pulley assy		Inkl. pos 11-12
11	1				1134-0051-09	Distans	Spacer		
12	2				9549-0019-00	Kullager	Ball bearing		
13	1				1134-5112-01	Fjäderfäste	Spring attachment		
14	2				9945-0816-16	Skruv	Screw		
15	1				1134-5110-01	Hake	Hook		
16	2				9893-0616-16	Skruv	Screw		
18	1				1134-2018-02	Spännarm	Tension arm		
19	1				1134-9027-02	Spännrulle-grå	Tension roller-grey		
20	1				1134-9071-01	Drivrem	V-belt		9585-0129-01
21	1				9997-1030-16	Skruv	Screw		
22	1				9799-1031-02	Mutter	Nut		
23	1				1134-4111-01	Bromsarm	Brake arm		
24	1				1134-4164-03	Bromsklots	Brake pad		
25	1				9897-0825-16	Skruv	Screw		
26	1				9747-0831-02	Mutter	Lock nut		
27	1				1134-4162-01	Bromsstång	Brake rod		
28	1				9675-0008-02	Starlock	Locking washer		
29	1				1134-4170-01	Nippel	Nipple		
30	1				9699-0025-02	Planbricka	Washer		
31	1				9747-0631-02	Låsmutter	Lock nut		
32	1				4231-0013-00	Fjäder	Spring		
33	1				1134-4231-01	Dragfjäder	Spring		
34	1				1134-1565-10	Distans	Spacer		
35	1				9997-0860-12	Skruv	Screw		
36	1				9699-0056-02	Planbricka	Flat washer		
37	1				9739-0831-22	Mutter	Nut		
38	1				1134-4163-01	Ansatsskruv	Shoulder bolt		
39	1				9731-1031-22	Mutter	Nut		
40	1				1134-3958-01	Remstyrning	Belt guide		
41	2				9893-0616-16	Skruv	Screw		
42	1				1134-0041-03	Hylsa	Collar		
43	1				9997-1070-12	Skruv	Screw		
44	1				9739-1031-22	Mutter	Nut		
45	1				1134-3654-01	Fingerskydd	Finger guard		
46	2				9959-0612-16	Skruv	Screw		
47	2				9739-0631-22	Mutter	Nut		
48	1				9699-0090-02	Planbricka	Flat washer		
49	2				9699-0035-02	Planbricka	Flat washer		