



Reservdelskatalog Parts Catalogue

VILLA 12










13-2725-15 - Season 2014

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
 - The contents described in the parts list may change due to improvement.
 - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
 - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.



© Copyright 2014 Global Garden Products

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


www.stiga.com




Utgåva Issue 43 - 2014		Monteringsdetaljer Assembly parts			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	9595-0262-00	Spännstift	Locating Pin	
2	1	9699-0114-02	Bricka	Washer	1.0 mm
2	1	9699-0103-02	Bricka	Washer	0.5 mm
3	2	1134-4185-01	Ansatsbricka	Flange Washer	
5	4	9699-0056-02	Bricka	Washer	
6	2	1134-4481-01	Vingmutter	Wing Nut	
7	1	1134-4627-01	Dragkrok	Tow Bar	
8	2	9959-0820-16	Skruv	Screw	
9	4	9997-0820-16	Skruv	Screw	
10	1	1134-4734-01	Tändningsnyckel	Ignition Key	
10	1	1134-6125-01	Tändningsnyckel	Ignition Key	
11	1	1134-5245-01	Batterirem	Battery Strap	
12	1	1134-6113-01	Skruv	Screw	
13	2	9898-1035-16	Skruv	Screw	
14	2	9739-1031-22	Mutter	Nut	
21	1	8211-0036-90	Bruksanvisning	Owner's Manual	13-2725
21	1	8211-0011-90	Bruksanvisning	Owner's Manual	13-2718, 13-2719
21	1	8211-0011-80	Bruksanvisning	Owner's Manual	
21	1	8211-0012-80	Bruksanvisning	Owner's Manual	
21	1	8211-0603-80	Monteringsanvisning	Assy Instructions	
21	1	8211-0603-90	Monteringsanvisning	Assy Instruction	
21	1	8211-0701-80	Säkerhetsföreskrifter	Safety Regulations	
21	1	8211-0701-91	Säkerhetsföreskrifter	Safety Regulations	
21	1	8211-0950-80	Garantikort	Warranty Card	
21	1	8211-0960-90	Garantikort	Warranty Card	




Utgåva Issue 43 - 2014		Kaross Body Work			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5283-02	Motorhuv Gul	Engine Hood Yellow	
2	7	9838-9530-12	Skruv	Screw	
3	1	1134-5284-02	Motorlucka-Grå7-14	Engine Cover-Grey	Grey
3	1	1134-5284-03	Motorlucka (Svart)	Engine Cover (Black)	Black
4	1	1134-5307-01	Stötfångare, fram-hö	Mud Guard-Lh (Grey)	Grey
4	1	1134-5307-03	Skärm-Vä (Svart) 5-01	Mud Guard-Lh (Black)	Black
5	1	1134-5307-02	Skärm-Hö (Grå) 7-14	Mud Guard-Rh (Grey)	Grey
5	1	1134-5307-04	Skärm-Hö (Svart) 5-01	Mud Guard-Rh (Black)	Black
6	2	1137-0088-01	Stödplåt	Support Plate	
7	4	9699-0056-02	Bricka	Washer	
8	6	9945-0816-16	Skruv	Screw	
9	4	1134-4176-01	Clips	Clips	
10	4	9893-0616-16	Relä Skruv	Relay Screw	
11	1	1134-5306-01	Stötfångare Front-Vä Grå	Bumper Front-Lh (Grey)	Grey
11	1	1134-5306-03	Stötfångare, fram-vä	Bumper Front-Lh (Black)	Black
12	1	1134-5306-02	Stötfångare Front-Hö Grå	Bumper Front-Rh (Grey)	Grey
12	1	1134-5306-04	Stötfångare, fram-vä	Bumper Front-Rh (Black)	Black
13	1	1134-5305-01	Front Nedre Gul	Lower Hood Yellow	
14	6	9893-0616-16	Relä Skruv	Relay Screw	
15	1	1134-5304-01	Front Övre (Gul) 1-00	Front Upper (Yellow)	
16	2	9946-0525-16	Skruv	Screw	
17	2	1134-4790-02	Styrning	Hood Guide (Black)	
18	2	9838-9530-12	Skruv	Screw	
19	2	9699-0060-02	Bricka	Washer	
99	1	1134-6426-01	Dekal	Label	Villa 12




Utgåva Issue 43 - 2014		Ram Frame			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6635-01	Ram Kpl (5-01)	Frame	
2	1	1134-5293-02	Durk	Floor Plate	Black line
2	1	1134-5293-01	Durk (Grå) 7-14	Floor Plate (Grey)	
3	2	9893-0616-16	Relä Skruv	Relay Screw	
4	1	1134-5338-02	Durkmatta	Floor Mat	
4	1	1134-5338-03	Durkmatta-Manuell	Floor Mat-Manual	
5	1	1134-5453-03	Stötfångare-bakre	Rear Bumper (Grey)	Grey
5	1	1134-5453-01	Stötfångare-bakre	Rear Bumper (Black)	Black line
6	1	1134-6630-01	Stag-Vä (5-01)	Attachment-Lh	
7	1	1134-6630-02	Stag-Hö (5-01)	Attachment-Rh	
8	2	1134-0240-00	Skruv	Screw	
9	2	1134-4242-01	Distansbricka	Washer	
10	2	9694-0001-00	Bricka	Washer	
11	2	9747-0831-02	Mutter Låsmutter	Nut	
12	2	9943-0516-16	Skruv	Screw	
13	2	9959-0820-16	Skruv	Screw	L = 20 mm
14	2	9959-0825-16	Skruv	Screw	L = 25 mm
15	1	9739-0831-22	Mutter	Nut	
16	3	9739-0831-22	Mutter	Nut	




Utgåva Issue 43 - 2014		Pedallyft Pedal lift			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4117-01	Fäste	Bracket	
2	2	9959-1025-16	Skruv	Screw	
3	2	9739-1031-22	Mutter	Nut	
4	2	1134-2684-01	Lager	Bearing	
5	1	1134-4945-01	Lyftspärr kpl	Lift Catch Assy	
9	1	9404-0027-01	O-ring	O-ring	
10	1	9650-0039-04	Spärring Sga 8	Lock Ring	
11	1	9595-0276-01	Spiralspännstift 8*24	Locating Pin	
12	1	9997-0640-12	Skruv	Screw	
13	1	9747-0631-02	Mutter Låsmutter	Nut	
15	1	9897-0820-16	Skruv	Screw	
16	1	9747-0831-02	Mutter Låsmutter	Nut	
17	1	1134-4860-01	Lyftgaffel	Lift Fork	
18	2	1134-0240-00	Skruv	Screw	
19	1	1134-4938-01	Lyftpedal	Lift Pedal	
20	2	9997-0625-16	Skruv	Screw	
21	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
22	1	4231-0013-00	Fjäder	Spring	




Utgåva Issue 43 - 2014		Seat			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5534-01	Fjäder	Spring	Black line
1	1	1134-5506-01	Sits "Stiga"	Seat Stiga	
3	1	1134-5301-01	Sitsplatta	Upper Seat Bracket	
4	2	1134-0240-00	Skruv	Screw	
5	2	9747-0831-02	Mutter Låsmutter	Nut	
6	1	1134-5454-01	Spärr	Catch	
7	1	9675-0012-02	Starlock	Locking washer	
12	1	1134-5296-05	Sitskonsol Kpl (Svart) 5-01	Seat Bracket (Black)	Black line
12	1	1134-5296-04	Sitskonsol Kpl (Gul) 1-00	Seat Bracket (Yellow)	
13	1	1134-4256-01	Fjäder	Spring	
14	1	9924-1235-19	Skruv	Screw	
15	1	9747-1231-02	Mutter	Nut	
16	1	9997-0840-12	Skruv	Screw	
17	1	1134-1565-06	Distans	Spacer	
18	1	1134-5302-01	Fjäder	Spring	
19	1	1134-5299-01	Tryckplatta	Push Plate	
20	1	9699-0090-02	Bricka	Washer	
21	1	9747-0831-02	Mutter Låsmutter	Nut	
22	1	1134-3156-02	Brytare (grå)	Switch	
28	4	9959-0820-16	Skruv	Screw	L = 20 mm
29	2	9959-0825-16	Skruv	Screw	L = 25 mm
30	2	9699-0056-02	Bricka	Washer	
31	6	9739-0831-22	Mutter	Nut	




Utgåva Issue 43 - 2014		Styrning Steering			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	3	1134-0041-01	Bussning	Bushing	
2	3	1134-0046-00	Wireklämma	Wire Clamp	
3	1	1134-9025-01	Linhjul	Steering Pulley	Sats 2 st/kit of 2
4	3	9997-1040-16	Skruv	Screw	L = 40 mm
5	2	9739-1031-22	Mutter	Nut	
6	1	1134-9154-01	Styrwire	Steering Cable	
7	1	1134-1310-01	Fjäder	Spring	
8	1	9699-0056-02	Bricka	Washer	
9	1	9747-0831-02	Mutter Låsmutter	Nut	
11	1	1134-5349-03	Styrkonsol Kpl (Grå) 7-14	Steering Console (Grey)	
12	4	9897-0820-16	Skruv	Screw	
13	4	9739-0831-22	Mutter	Nut	
15	1	1134-1305-05	Rattrör Nedre	Steering Column, Lower	
16	2	1134-1901-01	Lager	Bearing	
17	2	9893-0616-16	Relä Skruv	Relay Screw	
18	2	9699-0060-02	Bricka	Washer	
19	1	1134-5495-01	Rattstång	Steering Rod	
20	1	1134-1933-01	Linhjul	Steering Pulley	
21	1	9595-0262-00	Spännstift	Locating Pin	
22	1	1134-5496-01	Ratt	Steering Wheel	
32	1	1134-3047-01	Distans	Spacer	
33	2	9699-0104-02	Bricka	Washer	
36	2	1134-3047-01	Distans	Spacer	
37	1	1134-0041-05	Bussning	Bushing	
38	1	1134-0046-00	Wireklämma	Wire Clamp	
39	1	1134-9025-01	Linhjul	Steering Pulley	Sats 2 st/kit of 2
40	1	9997-1060-12	Skruv	Screw	





Utgåva Issue 43 - 2014		Handreglage Hand controls			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-5286-01	Reglagepanel-Vä (Grå)	Dashboard-Lh (Grey)	Grey
1	1	1134-5286-02	Reglagepanel-Vä (Svart)	Dashboard-Lh (Black)	Black
2	2	1134-5531-01	Dämpare	Absorber	
3	3	9893-0616-16	Relä Skruv	Relay Screw	
4	1	1134-5357-01	Fäste	Bracket	
5	2	9838-9516-12	Skruv	Screw	
6	1	1134-4077-01	Gasreglage	Throttle Cable	
7	1	1134-4078-01	Knopp	Knob	
8	1	1134-0240-00	Skruv	Screw	
9	1	9694-0001-00	Bricka	Washer	
10	2	1134-4242-01	Distansbricka	Washer	
11	1	9747-0831-02	Mutter Låsmutter	Nut	
12	1	1134-1597-13	Gasreglage	Throttle Cable	
13	1	9500-9991-00	Kabelklämma	Wire Clamp	
14	1	9943-0516-16	Skruv	Screw	
15	1	9579-0003-00	Buntband	Cable Holder	
20	1	9997-0812-02	Skruv	Screw	
21	1	1134-5274-02	Distans	Spacer	
22	3	1134-3047-01	Distans	Spacer	
23	1	1134-5271-01	Reglagefäste	Control Bracket	
24	1	1134-5275-01	Växelspak Kpl	Gearshift Lever	
25	1	1134-5535-01	Fjäder	Spring	
26	1	9997-0890-12	Skruv	Screw	
27	1	9747-0831-02	Mutter Låsmutter	Nut	
28	1	1134-5268-01	Stång	Shifter Rod	
29	1	9675-0009-02	Starlockbricka	Starlock	
30	1	1134-5271-01	Reglagefäste	Control Bracket	
31	1	1134-5276-01	Reglagespak Kpl	Control Lever	
32	1	9997-0890-12	Skruv	Screw	
33	1	9747-0831-02	Mutter Låsmutter	Nut	
34	1	1134-5356-01	Reaktionsstag	Strut	
35	1	9747-0831-02	Mutter Låsmutter	Nut	
36	2	9400-0360-01	Mikrobrytare	Microswitch	
37	4	9840-7716-16	Skruv	Screw	
38	1	1134-5358-01	Brytarfäste	Switch Bracket	
39	2	9943-0516-16	Skruv	Screw	
40	1	1134-5285-01	Reglagepanel Man-Hö (Grå)	Dashboard Man-Rh (Grey)	
40	1	1134-5285-03	Reglagepanel Man-Hö (Svart)	Dashboard Man-Rh (Black)	
41	2	1134-5531-01	Dämpare	Absorber	
42	4	9893-0616-16	Relä Skruv	Relay Screw	
43	2	1134-2551-01	Knopp	Knob	
44	1	1134-3573-06	Kraftuttagwire	Pto Cable	
45	1	1134-1242-02	Fjäder	Spring	
50	1	1134-4093-01	Tändningslås	Ignition Switch	
51	1	1134-4749-01	Mutter	Nut	




Utgåva Issue 43 - 2014		Fotreglage		Foot controls	
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4802-01	Pedal5-01 F15	Pedal	
2	2	1134-4624-01	Lager	Bearing	
3	4	9897-0640-12	Skruv	Screw	
4	4	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
5	1	1134-4795-01	Kopplingsstång	Clutch Rod	
6	1	1134-2138-01	Skruvögla	Eye Bolt	
7	1	9739-1031-22	Mutter	Nut	
8	1	9731-1031-22	Mutter	Nut	
9	1	9739-0831-22	Mutter	Nut	
10	1	9747-0831-02	Mutter Låsmutter	Nut	
11	1	9595-0208-00	Spiralspnst Prym N4X20	Locating Pin	
14	1	1134-4777-01	Bromsstång	Brake Rod	
15	1	1134-4617-01	Fjäder	Spring	
16	2	1134-2138-01	Skruvögla	Eye Bolt	
17	2	9699-0035-02	Bricka	Washer	
18	4	9595-0208-00	Spiralspnst Prym N4X20	Locating Pin	
19	2	9739-0831-22	Mutter	Nut	
20	1	9747-0831-02	Mutter Låsmutter	Nut	
26	1	1134-5353-01	Bromsstång	Brake Rod	
27	1	1134-2786-01	Knopp	Knob	
28	1	1131-1497-01	Fjäder	Brake Spring	
29	1	1134-4002-01	Fäste	Brake Rod Attachment	
30	3	9838-9516-12	Skruv	Screw	
31	1	1134-4714-01	Vinkelfäste	Angle Bracket	
32	2	9959-0820-16	Skruv	Screw	
33	2	9739-0831-22	Mutter	Nut	
34	1	1134-4715-01	Plåttriangel	Triangular Plate	
35	1	1134-0240-00	Skruv	Screw	
36	1	9694-0001-00	Bricka	Washer	
37	1	9699-0036-02	Bricka	Washer	
38	1	9747-0831-02	Mutter Låsmutter	Nut	
39	1	1134-4717-02	Gängstång	Threaded Rod	
40	2	9570-0004-00	Vinkellänk As 10 Din71802M6	Elbow Link	
41	2	9747-0631-02	Mutter Låsmutter	Nut	
42	2	9739-0631-22	Mutter Strålkastare	Nut Working lamp	
43	1	1134-6351-01	Växelarm	Shift Lever	Dana 6800-7
44	1	9987-5016-16	Skruv	Screw	
45	1	9699-0060-02	Bricka	Washer	
46	1	9675-0009-02	Starlockbricka	Starlock	
51	1	1134-4793-01	Stopplåt	Stop Plate	
52	1	4231-0013-00	Fjäder	Spring	
53	2	1134-4779-01	Bussning	Bushing	
58	1	9747-0831-02	Mutter Låsmutter	Nut	




Utgåva Issue 43 - 2014		Elsystem Electric system			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4804-01	Batteri	Battery	
8	1	1134-2042-02	Batterikabel	Battery Cable	L = 350 mm
9	1	9838-9516-12	Skruv	Screw	
10	1	9747-0831-02	Mutter Låsmutter	Nut	
11	1	9739-0631-22	Mutter Strålkastare	Nut Working lamp	M6
11	1	9795-3531-02	Mutter	Nut	1/4 UNC
12	3	9579-0003-00	Buntband	Cable Holder	
22	1	9699-0060-02	Bricka	Washer	
26	1	1134-2962-01	Solenoid Kpl Service	Solenoid	
27	2	9794-5131-02	Mutter	Nut	
28	1	1134-0234-02	Batterikabel (+)	Battery Cable (+)	L = 395 mm
29	1	1134-2310-01	Batteriskydd	Guard Cap (+)	
30	1	1134-4702-02	Kabel (+)	Cable	L = 480 mm
32	1	1134-3496-06	Säkring (20A)	Fuse (20A)	20A
32	1	1134-7218-01	Kabelhärva	Wiring harness	







Utgåva Issue 43 - 2014		Motor	Engine		
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
3	4	9955-3725-16	Skruv	Screw	3/8" x 25
5	1	1134-6626-01	Bränsletank	Fuel Tank	
6	1	1134-5532-01	Tanklock	Fuel Tank Cap	
7	1	1134-3224-01	Bensinkran	Fuel Shut-Off Valve	
8	1	1134-3225-01	Gummibussning	Grommet	
9	1	1134-2975-18	Bensinslang	Fuel Tube	L = 260 mm
9	1	1134-2975-18	Bensinslang	Fuel Tube	L = 260 mm
9	1	1134-2975-10	Bensinslang	Fuel Tube	L = 210 mm
10	2	9578-0023-02	Slangklämma D12*8 (Svart)	Hose Clamp	
12	1	1134-4808-01	Tankbygel	Tank Clamp	
13	1	9699-0060-02	Bricka	Washer	
14	1	9747-0631-02	Mutter Låsmutter	Nut	
15	1	1134-4807-02	Fäste	Support	
16	4	9829-8830-12	Skruv	Screw	
19	2	1134-0433-00	Packning	Gasket	
19	1	1134-0433-00	Packning	Gasket	
22	2	1134-4930-01	Skruv	Screw	
22	4	1134-4930-01	Skruv	Screw	
22	4	1134-4930-01	Skruv	Screw	
23	1	1134-6623-01	Ljuddämpare	Muffler	
24	1	1134-6634-01	Avgasrör Kpl (Villa)	Exhaust Pipe	
25	2	9893-0616-16	Relä Skruv	Relay Screw	
26	1	1134-6699-01	Värmskydd Kpl	Heat Guard	
27	4	9893-0616-16	Relä Skruv	Relay Screw	
99	1	118550439/0	Motor Kpl	Engine Assembled	GGP WM 12,5
99	1	1134-9500-01	Motor Ggp 12,5 Hp Kpl	Engine Assembled	GGP WM 12,5







Utgåva Issue 43 - 2014		Transmission			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-4611-01	Motorremskiva	Engine Belt Pulley	
4	1	1134-6637-01	Remstyrning	Belt Guide	
5	1	9699-0056-02	Bricka	Washer	
6	1	1134-4519-01	Spännarm Kpl. 5-01 F15	Tension Arm	
7	1	1134-9091-01	Spännrulle	Tension Roller	
8	1	1134-4614-01	Distans	Spacer	
9	1	9997-1040-16	Skruv	Screw	
10	1	9699-0035-02	Bricka	Washer	
11	1	9739-1031-22	Mutter	Nut	
12	1	1134-9027-02	Spännrulle (Grå)	Tension Roller (Grey)	
13	1	1134-1795-01	Remhållare	Belt Stirrup	
14	1	9997-1040-16	Skruv	Screw	
15	2	9699-0035-02	Bricka	Washer	
16	1	9739-1031-22	Mutter	Nut	
17	1	1134-9065-01	Kilrem	V-Belt	= 9585-0124-01
18	1	1134-1565-08	Distans	Spacer	
19	1	9997-0870-16	Skruv	Screw	
20	2	9699-0056-02	Bricka	Washer	
21	1	9739-0831-22	Mutter	Nut	
22	1	1134-5214-01	Fjäder	Spring	
23	1	1134-6338-01	Transaxel (Dana 6800-7)	Transaxle (Dana 6800-7)	Dana 6800-7
24	4	9960-0860-12	Skruv	Screw	
25	4	9747-0831-02	Mutter Låsmutter	Nut	
26	1	1134-4687-01	Momentstag 5-01 F24	Strut	
27	1	9945-0816-16	Skruv	Screw	
28	1	1134-1849-01	Remskiva	Belt Pulley	
30	1	9650-0016-04	Spårring Sga	Circlip	
31	1	1134-4707-01	Remstyrning	Belt Guide	
32	1	9942-0820-16	Skruv	Screw	
41	1	1134-2138-01	Skruvögla	Eye Bolt	
42	1	1134-4779-01	Bussning	Bushing	
43	1	9739-0831-22	Mutter	Nut	
44	1	9747-0831-02	Mutter Låsmutter	Nut	



Utgåva Issue 43 - 2014		Hjul Wheels			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-6703-01	Bakaxel	Rear Axle	
2	2	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
3	1	1134-5009-02	Spindel Kpl-Vä (5-01 H40)	Stub Axle	
4	1	1134-5009-01	Spindel Kpl-Hö (5-01 H40)	Right Stub Axle	
5	2	9699-0088-02	Bricka	Washer	
6	2	9650-0020-04	Spårring	Circlip	
7	1	1134-5316-01	Linhjul	Steering Pulley	
8	1	1134-5575-01	Distans	Spacer	
9	1	1134-9024-01	Lager (4 St)	Bearing	Sats 4 st/kit of 4
10	1	9699-0104-02	Bricka	Washer	
11	1	9997-1680-12	Skruv	Screw	
12	2	1134-3247-05	Styrstag	Tie Rod	
13	1	9997-0835-12	Skruv	Screw	L = 35 mm
13	2	9997-0825-16	Skruv	Screw	L = 25 mm
14	2	9699-0090-02	Bricka	Washer	
15	3	9747-0831-02	Mutter Låsmutter	Nut	
16	2	1134-4706-01	Fälg (3.50 X 6)	Rim	
17	1	1134-9026-01	Bussning	Bearing	Sats 4 st/kit of 4
18	2	9545-0117-00	Däck	Tyre	13 x 5.00 - 6
19	2	9545-0500-00	Ventil	Valve Assy.	
20	2	1134-0341-01	Bricka	Washer	
21	2	9650-0020-04	Spårring	Circlip	
22	2	1134-4344-01	Kapsel (Svart)	Hub Cap Black	
25	1	9501-0500-00	Smörjkopp Kort Rak	Grease Dispenser	
26	1	9699-0088-02	Bricka	Washer	
27	1	9650-0020-04	Spårring	Circlip	
28	2	1134-5255-01	Fälg	Rim	
29	2	9545-0126-01	Däck	Tyre	16 x 6.00 - 8
30	2	9545-0500-00	Ventil	Valve Assy.	
32	6	9731-1031-22	Mutter	Nut	
33	2	1134-2471-03	Kil	Key	
34	2	9653-0001-04	Spårryttare Rs	Lock Ring	
35	2	1134-0341-01	Bricka	Washer	
36	2	1134-4844-02	Hjulnav Kpl	Wheel Hub Assy	
37	2	1134-4845-02	Navhylsa	Hub Sleeve	
38	2	1134-4981-01	Bricka	Washer	
50	2	1134-6274-01	rödskapsfäste Kpl	Attachment	Inkl. pos 51 - 52
51	1	1134-9026-01	Bussning	Bearing	Sats 4 st/kit of 4
52	1	9501-0502-00	Smörjnippel	Grease Joint	



Utgåva Issue 43 - 2014		Kraftuttag Power take-off			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0081-01	Motorremskiva	Engine Pulley	
2	1	1134-5017-01	Bricka	Washer	
3	1	9987-5332-16	Skruv	Screw	
4	1	1134-5058-01	Remstyrning	Belt Guide	
5	1	1134-5057-01	Remstyrning	Belt Guide	
6	1	9600-0251-01	Kil	Key	"L = 2 1/2" "
7	2	9699-0056-02	Bricka	Washer	
8	1	1134-4650-01	Monteringsbygel5-01 H40	Pulley Bracket	
9	2	9945-0816-16	Skruv	Screw	
10	1	1137-0003-01	Mellanremskiva Smst	Intermediate Belt Pulley	Inkl. pos 11-12
11	1	1134-0051-12	Distans	Spacer	
12	2	9549-0019-00	Kullager	Ball Bearing	
14	2	1134-0052-00	Distans	Spacer	
15	1	9997-1040-16	Skruv	Screw	
16	1	9699-0035-02	Bricka	Washer	
17	1	1134-9079-01	Drivrem	Drive Belt	9585-0139-01
18	1	1134-5231-01	Spännarm 5-01 F24	Tension Arm	
19	1	1134-6329-01	Spännrulle Kpl	Tension Roller Assy	
20	1	1134-4619-01	Distans	Spacer	
21	1	9997-1060-12	Skruv	Screw	
22	1	9747-1031-02	Mutter Låsmutter	Nut	
23	1	1134-6314-01	Spännarmsfäste	Tension Arm Attachment	
24	1	9997-0640-12	Skruv	Screw	
25	1	9747-0631-02	Mutter Låsmutter	Nut	
26	1	1134-4619-01	Distans	Spacer	
27	1	9930-1050-12	Skruv	Screw	
28	1	9699-0035-02	Bricka	Washer	
29	1	9747-1031-02	Mutter Låsmutter	Nut	
30	1	1134-4708-02	Fäste	Bracket	
31	2	9945-0816-16	Skruv	Screw	
32	1	9699-0035-02	Bricka	Washer	
36	1	1131-1507-00	Fjäder	Spring	
40	1	1134-5037-01	Bygel Kpl (Svart) 5-01 F15	Mounting Bracket (Black)	
41	1	1137-0004-01	Centrumremskiva Smst	Centre Pulley Assy	Inkl. pos 42-43
42	1	1134-0051-09	Distans	Spacer	
43	2	9549-0019-00	Kullager	Ball Bearing	
44	1	1134-1839-02	Mellanaxel	Shaft	
45	1	9699-0035-02	Bricka	Washer	
46	1	9739-1031-22	Mutter	Nut	
47	1	9997-1070-12	Skruv	Screw	
48	1	1137-0144-01	Kopplingsarm Kpl	Tension Arm Assy	
49	1	1134-1565-10	Distans	Spacer	
50	1	9997-0860-12	Skruv	Screw	
51	1	9699-0056-02	Bricka	Washer	
52	1	9739-0831-22	Mutter	Nut	
53	1	1134-9027-02	Spännrulle (Grå)	Tension Roller (Grey)	
55	1	9997-1035-16	Skruv	Screw	
56	2	9699-0035-02	Bricka	Washer	
57	1	9739-1031-22	Mutter	Nut	



Utgåva Issue 43 - 2014		Kraftuttag Power take-off			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
58	1	1134-9146-01	Kilrem	V-Belt	9585-0204-01
59	1	1134-4164-03	Bromsklots	Brake Pad	
60	1	9959-0820-16	Skruv	Screw	
61	1	9699-0090-02	Bricka	Washer	
62	1	9747-0831-02	Mutter Låsmutter	Nut	
63	2	9959-0820-16	Skruv	Screw	
64	2	9739-0831-22	Mutter	Nut	
65	1	9699-0056-02	Bricka	Washer	
66	1	1131-1506-00	Fjäder	Spring	
67	1	9997-0860-12	Skruv	Screw	
68	2	9739-0831-22	Mutter	Nut	

code	pos.	q.ty	page									
1137-0144-01	48	1	p. 27	9699-0060-02	18	2	p. 13	9838-9516-12	5	2	p. 15	
4231-0013-00	22	1	p. 9	9699-0060-02	19	2	p. 5	9838-9516-12	9	1	p. 19	
4231-0013-00	52	1	p. 17	9699-0060-02	22	1	p. 19	9838-9516-12	30	3	p. 17	
8211-0011-80	21	1	p. 3	9699-0060-02	45	1	p. 17	9838-9530-12	2	7	p. 5	
8211-0011-90	21	1	p. 3	9699-0088-02	5	2	p. 25	9838-9530-12	18	2	p. 5	
8211-0012-80	21	1	p. 3	9699-0088-02	26	1	p. 25	9840-7716-16	37	4	p. 15	
8211-0036-90	21	1	p. 3	9699-0090-02	14	2	p. 25	9893-0616-16	3	2	p. 7	
8211-0603-80	21	1	p. 3	9699-0090-02	20	1	p. 11	9893-0616-16	3	3	p. 15	
8211-0603-90	21	1	p. 3	9699-0090-02	61	1	p. 29	9893-0616-16	10	4	p. 5	
8211-0701-80	21	1	p. 3	9699-0103-02	2	1	p. 3	9893-0616-16	14	6	p. 5	
8211-0701-91	21	1	p. 3	9699-0104-02	10	1	p. 25	9893-0616-16	17	2	p. 13	
8211-0950-80	21	1	p. 3	9699-0104-02	33	2	p. 13	9893-0616-16	25	2	p. 21	
8211-0960-90	21	1	p. 3	9699-0114-02	2	1	p. 3	9893-0616-16	27	4	p. 21	
9400-0360-01	36	2	p. 15	9731-1031-22	8	1	p. 17	9893-0616-16	42	4	p. 15	
9404-0027-01	9	1	p. 9	9731-1031-22	32	6	p. 25	9897-0640-12	3	4	p. 17	
9500-9991-00	13	1	p. 15	9739-0631-22	4	4	p. 17	9897-0820-16	12	4	p. 13	
9501-0500-00	2	2	p. 25	9739-0631-22	11	1	p. 19	9897-0820-16	15	1	p. 9	
9501-0500-00	25	1	p. 25	9739-0631-22	21	2	p. 9	9898-1035-16	13	2	p. 3	
9501-0502-00	52	1	p. 25	9739-0631-22	42	2	p. 17	9924-1235-19	14	1	p. 11	
9545-0117-00	18	2	p. 25	9739-0831-22	9	1	p. 17	9930-1050-12	27	1	p. 27	
9545-0126-01	29	2	p. 25	9739-0831-22	13	4	p. 13	9942-0820-16	32	1	p. 23	
9545-0500-00	19	2	p. 25	9739-0831-22	15	1	p. 7	9943-0516-16	12	2	p. 7	
9545-0500-00	30	2	p. 25	9739-0831-22	16	3	p. 7	9943-0516-16	14	1	p. 15	
9549-0019-00	12	2	p. 27	9739-0831-22	19	2	p. 17	9943-0516-16	39	2	p. 15	
9549-0019-00	43	2	p. 27	9739-0831-22	21	1	p. 23	9945-0816-16	8	6	p. 5	
9570-0004-00	40	2	p. 17	9739-0831-22	31	6	p. 11	9945-0816-16	9	2	p. 27	
9578-0023-02	10	2	p. 21	9739-0831-22	33	2	p. 17	9945-0816-16	27	1	p. 23	
9579-0003-00	12	3	p. 19	9739-0831-22	43	1	p. 23	9945-0816-16	31	2	p. 27	
9579-0003-00	15	1	p. 15	9739-0831-22	52	1	p. 27	9946-0525-16	16	2	p. 5	
9595-0208-00	11	1	p. 17	9739-0831-22	64	2	p. 29	9955-3725-16	3	4	p. 21	
9595-0208-00	18	4	p. 17	9739-0831-22	68	2	p. 29	9959-0820-16	8	2	p. 3	
9595-0262-00	1	1	p. 3	9739-1031-22	3	2	p. 9	9959-0820-16	13	2	p. 7	
9595-0262-00	21	1	p. 13	9739-1031-22	5	2	p. 13	9959-0820-16	28	4	p. 11	
9595-0276-01	11	1	p. 9	9739-1031-22	7	1	p. 17	9959-0820-16	32	2	p. 17	
9600-0251-01	6	1	p. 27	9739-1031-22	11	1	p. 23	9959-0820-16	60	1	p. 29	
9650-0016-04	30	1	p. 23	9739-1031-22	14	2	p. 3	9959-0820-16	63	2	p. 29	
9650-0020-04	6	2	p. 25	9739-1031-22	16	1	p. 23	9959-0825-16	14	2	p. 7	
9650-0020-04	21	2	p. 25	9739-1031-22	46	1	p. 27	9959-0825-16	29	2	p. 11	
9650-0020-04	27	1	p. 25	9739-1031-22	57	1	p. 27	9959-1025-16	2	2	p. 9	
9650-0039-04	10	1	p. 9	9747-0631-02	13	1	p. 9	9960-0860-12	24	4	p. 23	
9653-0001-04	34	2	p. 25	9747-0631-02	14	1	p. 21	9987-5016-16	44	1	p. 17	
9675-0009-02	29	1	p. 15	9747-0631-02	25	1	p. 27	9987-5332-16	3	1	p. 27	
9675-0009-02	46	1	p. 17	9747-0631-02	41	2	p. 17	9997-0625-16	20	2	p. 9	
9675-0012-02	7	1	p. 11	9747-0831-02	5	2	p. 11	9997-0640-12	12	1	p. 9	
9694-0001-00	9	1	p. 15	9747-0831-02	9	1	p. 13	9997-0640-12	24	1	p. 27	
9694-0001-00	10	2	p. 7	9747-0831-02	10	1	p. 17	9997-0812-02	20	1	p. 15	
9694-0001-00	36	1	p. 17	9747-0831-02	10	1	p. 19	9997-0820-16	9	4	p. 3	
9699-0035-02	10	1	p. 23	9747-0831-02	11	1	p. 15	9997-0825-16	13	2	p. 25	
9699-0035-02	15	2	p. 23	9747-0831-02	11	2	p. 7	9997-0835-12	13	1	p. 25	
9699-0035-02	16	1	p. 27	9747-0831-02	15	3	p. 25	9997-0840-12	16	1	p. 11	
9699-0035-02	17	2	p. 17	9747-0831-02	16	1	p. 9	9997-0860-12	50	1	p. 27	
9699-0035-02	28	1	p. 27	9747-0831-02	20	1	p. 17	9997-0860-12	67	1	p. 29	
9699-0035-02	32	1	p. 27	9747-0831-02	21	1	p. 11	9997-0870-16	19	1	p. 23	
9699-0035-02	45	1	p. 27	9747-0831-02	25	4	p. 23	9997-0890-12	26	1	p. 15	
9699-0035-02	56	2	p. 27	9747-0831-02	27	1	p. 15	9997-0890-12	32	1	p. 15	
9699-0036-02	37	1	p. 17	9747-0831-02	33	1	p. 15	9997-1035-16	55	1	p. 27	
9699-0056-02	5	1	p. 23	9747-0831-02	35	1	p. 15	9997-1040-16	4	3	p. 13	
9699-0056-02	5	4	p. 3	9747-0831-02	38	1	p. 17	9997-1040-16	9	1	p. 23	
9699-0056-02	7	2	p. 27	9747-0831-02	44	1	p. 23	9997-1040-16	14	1	p. 23	
9699-0056-02	7	4	p. 5	9747-0831-02	58	1	p. 17	9997-1040-16	15	1	p. 27	
9699-0056-02	8	1	p. 13	9747-0831-02	62	1	p. 29	9997-1060-12	21	1	p. 27	
9699-0056-02	20	2	p. 23	9747-1031-02	22	1	p. 27	9997-1060-12	40	1	p. 13	
9699-0056-02	30	2	p. 11	9747-1031-02	29	1	p. 27	9997-1070-12	47	1	p. 27	
9699-0056-02	51	1	p. 27	9747-1231-02	15	1	p. 11	9997-1680-12	11	1	p. 25	
9699-0056-02	65	1	p. 29	9794-5131-02	27	2	p. 19	118550439/0	99	1	p. 21	
9699-0060-02	13	1	p. 21	9795-3531-02	11	1	p. 19					
				9829-8830-12	16	4	p. 21					