



Reservdelskatalog Parts Catalogue

VILLA 320 HST STIGA


13-5711-51 - Season 2015

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
 - The contents described in the parts list may change due to improvement.
 - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
 - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


© Copyright 2015 Global Garden Products

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


www.stiga.com



Utgåva Issue 22 - 2015		Monteringsdetaljer Assembly parts			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	9595-0262-00	Spännstift	Locating Pin	
2	4	9959-0820-16	Skruv	Screw	
3	2	1134-4185-01	Ansatsbricka	Flange Washer	
4	4	9699-0056-02	Bricka	Washer	
5	2	1134-4734-01	Tändningsnyckel	Ignition Key	
6	1	1134-6113-01	Skruv	Screw	




Utgåva Issue 22 - 2015		Kaross Body works			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0854-01	Motorlucka Gul	Engine Hood Yellow	
2	2	1137-0861-01	Fjäder	Spring	
3	2	9838-9516-12	Skruv	Screw	
4	1	1137-0859-01	Lock	Cap	
5	1	1137-0857-01			
6	4	9893-0616-16	Skruv	Screw	
7	1	1137-1015-01	Packning	Gasket	
8	1	1137-1028-01	Packning	Gasket	
9	1	1137-0855-01			
10	1	1137-0860-01	Stang	Rod	
11	1	1137-0851-01			
12	12	9893-0616-16	Skruv	Screw	
13	1	1137-0852-01			
14	2	1134-4176-01	Clips	Clips	
15	1	1137-0858-01			
16	1	1137-0853-01	Stötfångare	Bumper	




2876


Utgåva Issue 22 - 2015		Ram		Frame	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0676-01	Ram	Frame	
2	1	1137-0869-01	Ram	Frame	
3	1	1137-0870-01	Ram	Frame	
4	4	9641-0001-01	Nit	Rivet	
5	4	9959-0825-16	Skruv	Screw	
6	4	9739-0831-22	Mutter	Nut	
7	1	9547-0008-01	Lager	Bearing	
8	1	1137-0963-01	Fäste	Support	
9	2	9699-0109-02	Bricka	Washer	
10	2	9997-1040-16	Skruv	Screw	
11	2	9739-1031-22	Mutter	Nut	
12	1	1137-0906-01	Remstyrning	Belt Guide	
13	2	9893-0616-16	Skruv	Screw	
14	1	1137-0893-01	Platta	Plate	
15	2	9959-0820-16	Skruv	Screw	
16	1	127275000/0	Gummiplugg	Grommet	
17	2	1137-0064-01	Dämpare	Rubber Cone	
18	2	9739-0831-22	Mutter	Nut	
19	1	1137-0916-01	Fäste	Bracket	
20	2	9959-0820-16	Skruv	Screw	
21	2	9739-0831-22	Mutter	Nut	
22	1	1137-0923-01	Skydd	Protection	
23	2	9893-0616-16	Skruv	Screw	
24	2	9739-0631-01			




Utgåva Issue 22 - 2015		Sits Seat			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0871-01			
2	4	9945-0816-16	Skruv	Screw	
3	1	1137-0868-01			
4	1	1134-3134-01	Fjäder	Spring	
5	1	1134-3156-01	Brytare	Switch	
6	1	1134-3156-02	Brytare (gra)	Switch	
7	1	1137-1004-01			
8	1	9860-0620-16			
9	1	9747-0631-02	Mutter	Nut	
10	2	1134-3144-01	Distans	Spacer	
11	2	9852-8013-16	Skruv	Screw	
12	1	1137-0862-01	Plat	Plate	
13	1	9893-0616-16	Skruv	Screw	
14	1	1137-0872-01	Distans	Spacer	
15	1	9665-0002-00	Bricka	Washer	
16	1	9747-0631-02	Mutter	Nut	
17	1	1137-0867-01	Fäste	Bracket	
18	2	1134-0240-01	Ansattsskruv Skruv	Shoulder screw Screw	
19	2	9747-0831-02	Mutter	Nut	
20	2	1137-0913-01	Knapp	Button	
21	2	9893-0616-16	Skruv	Screw	
22	1	1137-1033-01	Stang	Rod	
23	1	9675-0008-02	Starlockbricka	Starlock	




Utgåva Issue 22 - 2015		Styrning Steering			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	1134-1901-01	Lager	Bearing	
2	1	1134-9025-01	Linhjul	Steering Pulley	
3	2	9653-0001-04	Sparryttare Rs	Lock Ring	
4	1	9945-0816-16	Skruv	Screw	
5	1	9699-0056-02	Bricka	Washer	
6	1	1137-0749-01	Fäste	Bracket	
7	1	9945-0816-16	Skruv	Screw	
8	1	1134-6378-02	Kedja	Chain	
9	4	9739-0831-22	Mutter	Nut	
10	1	1137-0905-01	Rattstang	Steering Column	
11	1	1134-2837-01	Distans	Spacer	
12	1	1134-5496-05	Ratt	Steering wheel	
13	1	1137-1000-01	Styrkonsolkapa, Svart	Steering Plate Cover	
14	1	1134-3751-01	Knopp	Knob	
15	1	1137-1005-01	Fäste	Support	
16	1	9699-0060-02	Bricka	Washer	
17	1	9997-0680-12	Skruv	Screw	
18	1	1134-1565-14	Distans	Spacer	
19	1	9403-0062-01	Lock	Cap	




Utgåva Issue 22 - 2015		Reglage		Controls	
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0992-01	Bromsvajer	Brake Cabel	
2	1	1137-0813-01	Bromspedal kpl	Pedal	
3	2	1134-6313-01	Lager	Bearing	
4	1	1137-0912-01	Distans	Spacer	
5	1	9997-0811-02	Skruv	Screw	
6	1	9739-0831-22	Mutter	Nut	
7	1	1134-0847-01			
8	2	9959-0620-16	Skruv	Screw	
9	2	9739-0631-22	Mutter	Nut	
10	1	1131-1507-00	Fjäder	Spring	
11	1	1137-0959-01	Bromspedal kpl	Pedal	
12	1	9930-0870-12	Skruv	Screw	
15	1	1137-0827-01	Fäste	Bracket	
16	2	1134-6313-01	Lager	Bearing	
17	1	1137-0802-01	Distans	Spacer	
18	1	9997-0860-12	Skruv	Screw	
19	1	9747-0831-02	Mutter	Nut	
20	1	1137-0927-01			
21	2	9893-0616-16	Skruv	Screw	
22	1	1134-2766-10	Kablage	Cable	
23	2	9570-0001-00	Vinkellänk As8 Din 71802M5	Elbow Link	
24	2	9739-0531-22	Mutter	Nut	
25	2	9747-0531-02	Mutter	Nut	
26	1	1134-6317-01	Wirefäste	Wire Bracket	
27	2	9959-0620-16	Skruv	Screw	
28	2	9739-0631-22	Mutter	Nut	
29	1	1137-0928-01	Fäste	Bracket	
30	2	9959-0825-16	Skruv	Screw	
31	2	9739-0831-22	Mutter	Nut	
32	1	1134-0266-00	Fästbygel	Attaching Clamp	
33	1	1134-0267-00	Underläggsbleck	Clamp Plate	
34	1	9997-0520-16	Skruv	Screw	
35	1	9739-0531-22	Mutter	Nut	
36	1	1137-0784-01	Pedal	Pedal	
37	2	1134-0068-00	Lager (D20,4)	Bearing (D=20,4)	
38	1	1137-0795-01	Distans	Spacer	
39	1	9997-0814-02	Skruv	Screw	
40	1	9747-0831-02	Mutter	Nut	
41	1	1134-5824-01	Fjäder	Spring	
42	1	1137-0877-01	Pedal	Pedal	
43	1	9930-0820-16	Skruv	Screw	
44	1	1137-0958-01	Pedal	Pedal	
45	1	9595-0230-00	Stift	Pin	
46	1	1137-0792-01	Bromsstang	Brake Rod	
47	2	9675-0015-02	Lasbricka	Starlock	
48	1	1137-1092-01	Fjäder	Spring	
49	1	1137-0917-01	Lyftwire	Lifting Wire	
50	1	1134-0072-02	Linhjul	Steering Pulley	
51	1	1134-0041-01	Bussning	Bushing	




Utgåva Issue 22 - 2015		Reglage Controls			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
52	1	1137-0713-02	Fäste	Bracket	
53	1	9997-1030-16	Skruv	Screw	
54	1	9739-1031-22	Mutter	Nut	
55	1	1137-1042-01	Karbinhake	Snap Hook	
56	2	1137-0952-01	Knopp	Knob	
57	1	1137-0837-01	Spak	Lever	P-broms/Parking brake
58	1	1137-0894-01	Gasreglage	Throttle Lever	
59	1	1137-0952-01	Knopp	Knob	
60	1	1137-0873-01	Plat	Plate	
61	2	9838-9516-12	Skruv	Screw	
62	1	1134-0240-00	Skruv	Screw	
63	1	1134-4242-01	Distansbricka	Washer	
64	1	9665-0002-00	Bricka	Washer	
65	1	9747-0831-02	Mutter	Nut	
66	1	1134-4197-01	Gasreglage	Throttle Cable	
67	1	9500-9991-00	Kabelklämma	Wire Clamp	
68	1	9943-0516-16	Skruv	Screw	





Utgåva Issue 22 - 2015		Motor	Engine		
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
2	1	1134-5825-01	Nippel	Nipple	
3	1	1137-1018-01	Oljeavtappningsrör	Oil Discharge Extension	
4	1	9575-0023-04			
6	1	1137-0433-00			
7	2	1134-4930-01	Skruv	Screw	
10	1	1137-0815-01	Bränsletank	Tank	
11	1	1134-3224-01	Bensinkran	Fuel Shut-Off Valve	
12	1	1134-3225-01	Gummibussning	Grommet	
13	1	9505-0001-01	Bensinslang	Fuel Tube	
14	1	9578-0023-02	Slangklämma D12*8 (Svart)	Hose Clamp	
15	1	1137-0838-01			
16	1	1135-2528-01	Gummimanschett	Rubber Cuff	
17	1	1134-5532-01	Tanklock	Fuel Tank Cap	
20	1	1137-0914-01	Fäste	Bracket	
21	3	9893-0616-16	Skruv	Screw	
22	2	9838-9516-16			
25	1	1137-0777-01	Platta	Plate	
26	1	1137-1026-01	BränsleTankskydd	Tank Protection	
27	2	9893-0616-16	Skruv	Screw	
28	4	9997-0825-16	Skruv	Screw	
29	4	9739-0831-22	Mutter	Nut	
30	4	9955-3725-16	Skruv	Screw	




Utgåva Issue 22 - 2015		Transmisson			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1134-9168-01	Drivrem	Belt	
2	1	1131-1507-00	Fjäder	Spring	
3	1	1137-0890-01	Transaxel	Transmission Unit	
4	4	9960-0860-12	Skruv	Screw	
5	1	1137-0897-01	Plat	Plate	
6	2	9997-0850-12	Skruv	Screw	
7	2	9739-0831-22	Mutter	Nut	
10	1	1137-0714-01	Motorremskiva	Engine Pulley	
11	1	9600-0251-00	Kil	Key	
12	1	1134-5017-01	Bricka	Washer	
15	1	1137-0769-01	Spak	Lever	
16	1	9997-0870-16	Skruv	Screw	
17	1	9699-0056-02	Bricka	Washer	
18	1	1134-1565-08	Distans	Spacer	
19	1	9747-0831-02	Mutter	Nut	
20	1	1134-3459-01	Spännrulle	Tension Roller	
21	1	1134-5210-05	Distans	Spacer	
22	1	9997-1016-12			
23	1	9739-1031-22	Mutter	Nut	
24	1	1137-0834-01	Stag	Rod	
25	1	9675-0009-02	Starlockbricka	Starlock	



Utgåva Issue 22 - 2015		Kraftuttag PTO			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0791-01	Spak	Lever	
2	3	1134-2989-02	Spännrulle (Gra)	Tension Roller (Grey)	
3	2	9959-1025-16	Skruv	Screw	
4	3	1134-5548-01	Distans	Spacer	
5	1	1137-0918-01	Spak	Lever	
6	2	1134-5824-01	Fjäder	Spring	
7	1	1134-9167-01	Drivrem	Belt	
8	1	1137-0717-01	Remskiva	Belt Pulley	
9	2	9549-0019-00	Kullager	Ball Bearing	
10	1	1134-0051-12	Distans	Spacer	
11	1	1134-9172-01	Drivrem	Belt	
12	1	1137-0863-01	Magnetkoppling	Magnet Clutch	
13	1	1137-0754-01	Magnetkoppling	Magnet Clutch	
14	2	9959-0820-16	Skruv	Screw	
15	2	9739-0831-26			
16	1	1137-0741-01	Remskiva	Belt Pulley	
17	3	9945-0816-16	Skruv	Screw	
20	1	1137-1013-01	Fäste	Bracket	
21	1	9739-1031-22	Mutter	Nut	
22	1	9997-1035-01			
23	1	1137-1011-01			
24	1	1134-6314-01	Spännarmsfäste	Tension Arm Attachment	
25	1	9997-0640-12	Skruv	Screw	
26	1	9747-0631-02	Mutter	Nut	
27	1	9930-1050-12	Skruv	Screw	
28	1	9699-0035-02	Bricka	Washer	
29	1	1134-4619-01	Distans	Spacer	
30	1	9739-1031-22	Mutter	Nut	
31	2	9959-0820-16	Skruv	Screw	
32	2	9739-0831-02			
33	1	1137-1029-01	Fjäder	Spring	
34	1	9997-1060-16			
35	1	9699-0035-02	Bricka	Washer	
36	1	1137-0800-01	Fäste	Bracket	



Utgåva Issue 22 - 2015		Hjul Wheel			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	2	9694-0004-00	Fjäder	Spring	
2	2	1137-0762-01	Fäste	Bracket	
3	2	9646-0098-22	Nit Kn 8X32	Rivet	
4	2	9672-0006-02	Starlock	Lock washer	
5	2	1134-0341-01	Bricka	Washer	
6	2	1137-0934-01			
7	2	1134-5127-01	Bricka	Washer	
8	2	9959-0820-16	Skruv	Screw	
9	2	1137-1006-02	Navkapsel	Hub Cap	
10	2	1134-4845-02	Navhylsa	Hub Sleeve	
11	2	1134-0341-01	Bricka	Washer	
12	2	1137-0935-01			
13	2	1134-4981-01	Bricka	Washer	
14	2	9653-0001-04	Sparryttare Rs	Lock Ring	
15	2	1134-1006-01			



Utgåva Issue 22 - 2015		Eldetaljer Electric			
Pos. Fig.	Antal Q.ty	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	1137-0991-01			
1	1	1134-3496-06	Säkring 20 Amp Gul	Fuse (20A)	
2	1	1134-3901-01	Solenoid	Solenoid	
3	2	9743-5121-32	Mutter	Nut	
4	1	1137-1056-01	Fäste	Bracket	
5	1	1137-1056-01	Fäste	Bracket	
6	2	1137-1057-01	Stang	Rod	
7	2	1134-4481-02	Vingmutter	Wing Nut	
8	2	9747-0631-02	Mutter	Nut	
9	1	1134-4093-01	Tändningslas	Ignition Switch	
10	1	1134-4749-01	Mutter	Nut	
11	2	9838-9516-12	Skruv	Screw	
12	1	9400-0282-01	Brytare (Med Diod)	Switch	
13	1	9400-0343-01	Vippa Pto (Röd)	Switch Cover-Pto	
14	1	1134-4129-01	Täckbricka	Cover	
15	1	1134-3399-01	Brytare	Switch	
16	2	9943-0516-16	Skruv	Screw	
17	1	1134-2167-03	Kabel (Minus)	Cable (-)	
18	1	1137-0664-01	Batterikabel (+)	Battery Cable (+)	
19	1	1134-0234-02	Batterikabel (+)	Battery Cable (+)	
20	1	9795-3531-02	Mutter	Nut	
21	1	9400-0324-01	Isoleringshatt	Lug Isolator	
22	1	1134-2871-01	Relä	Relay	
23	1	1134-2871-03	Relä	Relay	
24	15	9579-0003-00	Buntband	Cable Holder	

code	pos.	q.ty	page				
9739-0831-22	31	2	p. 13	9997-1030-16	53	1	p. 15
9739-0831-26	15	2	p. 21	9997-1035-01	22	1	p. 21
9739-1031-22	11	2	p. 7	9997-1040-16	10	2	p. 7
9739-1031-22	21	1	p. 21	9997-1060-16	34	1	p. 21
9739-1031-22	23	1	p. 19	127275000/0	16	1	p. 7
9739-1031-22	30	1	p. 21				
9739-1031-22	54	1	p. 15				
9743-5121-32	3	2	p. 25				
9747-0531-02	25	2	p. 13				
9747-0631-02	8	2	p. 25				
9747-0631-02	9	1	p. 9				
9747-0631-02	16	1	p. 9				
9747-0631-02	26	1	p. 21				
9747-0831-02	19	1	p. 13				
9747-0831-02	19	1	p. 19				
9747-0831-02	19	2	p. 9				
9747-0831-02	40	1	p. 13				
9747-0831-02	65	1	p. 15				
9795-3531-02	20	1	p. 25				
9838-9516-12	3	2	p. 5				
9838-9516-12	11	2	p. 25				
9838-9516-12	61	2	p. 15				
9838-9516-16	22	2	p. 17				
9852-8013-16	11	2	p. 9				
9860-0620-16	8	1	p. 9				
9893-0616-16	6	4	p. 5				
9893-0616-16	12	12	p. 5				
9893-0616-16	13	1	p. 9				
9893-0616-16	13	2	p. 7				
9893-0616-16	21	2	p. 9				
9893-0616-16	21	2	p. 13				
9893-0616-16	21	3	p. 17				
9893-0616-16	23	2	p. 7				
9893-0616-16	27	2	p. 17				
9930-0820-16	43	1	p. 13				
9930-0870-12	12	1	p. 13				
9930-1050-12	27	1	p. 21				
9943-0516-16	16	2	p. 25				
9943-0516-16	68	1	p. 15				
9945-0816-16	2	4	p. 9				
9945-0816-16	4	1	p. 11				
9945-0816-16	7	1	p. 11				
9945-0816-16	17	3	p. 21				
9955-3725-16	30	4	p. 17				
9959-0620-16	8	2	p. 13				
9959-0620-16	27	2	p. 13				
9959-0820-16	2	4	p. 3				
9959-0820-16	8	2	p. 23				
9959-0820-16	14	2	p. 21				
9959-0820-16	15	2	p. 7				
9959-0820-16	20	2	p. 7				
9959-0820-16	31	2	p. 21				
9959-0825-16	5	4	p. 7				
9959-0825-16	30	2	p. 13				
9959-1025-16	3	2	p. 21				
9960-0860-12	4	4	p. 19				
9997-0520-16	34	1	p. 13				
9997-0640-12	25	1	p. 21				
9997-0680-12	17	1	p. 11				
9997-0811-02	5	1	p. 13				
9997-0814-02	39	1	p. 13				
9997-0825-16	28	4	p. 17				
9997-0850-12	6	2	p. 19				
9997-0860-12	18	1	p. 13				
9997-0870-16	16	1	p. 19				
9997-1016-12	22	1	p. 19				