







Genuine Spare Parts






Utgåva Issue 2005- 12		Bildnr Picture No 1848		JB 240 MINI TILLER 200 CHASSI		JB 240 MINI TILLER CHASSIS		Sida Page 204	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2224 -12	2224 -82							
1	1	1			1482- 1099- 01	Mutter.....	Nut.....		Multifak EP00
2	2	2			1482- 0947- 01	Handtag.....	Plast grip.....		
3	1	1			1482- 1086- 01	Styre- överdel	Handle- upper.....		
4	2	2			1482- 1100- 01	Vingmutter.....	Wing nut		
5	1	1			1482- 1081- 01	Skruv	Screw		
6	1	1			1482- 1042- 01	Gasreglagekabel	Throttle cable		
7	2	2			1482- 0968- 01	Bult	Bolt		
8	2	2			9799- 0631- 02	Mutter.....	Nut		
9	1	1			1482- 1085- 01	Styrrör- hö	Handlebar- RH		
10	2	2			1482- 0983- 01	Mutter.....	Nut		
11	1	1			1482- 1084- 01	Styrrör- vä	Handlebar- LH		
12	1	1			1482- 1087- 01	Bygel	Clamp.....		
13	2	2			1482- 1103- 01	Plugg	Plug		
16	1	1			1482- 1097- 01	Kopplingsskål	Clutch bowl		
18	4	4			1482- 1082- 01	Nit.....	Rivet.....		
19	1	1			1482- 1096- 01	Skärmförbindning.....	Sheet connector		
21	1				1482- 1094- 01	Skärm- gul	Sheet- yellow.....		
21		1			1482- 1095- 01	Skärm- röd.....	Sheet- red.....		
24	1	1			1482- 1083- 01	Bromssporre/hjulfäste	Depth skid/wheel supp		
25	2	2			1482- 1102- 01	Stödhjul	Support wheel		
26	2	2			1482- 0968- 01	Bult	Bolt		
27	2	2			1482- 1104- 01	Bussning	Bushing.....		
28	2	2			1482- 0983- 01	Mutter.....	Nut		
29	4	4			1482- 1080- 01	Skruv	Screw		
30	1	1			1482- 1088- 01	Konsol	Console		
31	4	4			1482- 0983- 01	Mutter.....	Nut		
32	1	1			1482- 1089- 01	Växelhus kpl	Transmission assy		
33	2	2			1482- 1098- 01	Packning.....	Gasket.....		
34	2	2			1482- 1101- 01	Dammskydd	Dust cover		
35	2	2			9915- 0610- 15	Stoppskruv	Set screw		
36	4	4			9683- 0025- 02	Låsbricka	Lock washer		
37	4	4			9997- 0640- 12	Skruv	Screw		
38	1	1			1482- 1093- 01	Rotor, hö- ytter	Rotor, RH- outer		
39	1	1			1482- 1092- 01	Rotor, hö- inre	Rotor, RH- inner		
40	1	1			1482- 1091- 01	Rotor, vä- inre	Rotor, LH- inner		
41	1	1			1482- 1090- 01	Rotor, vä- yttre	Rotor, LH- outer		
42	2	2			1482- 0712- 01	Låsnål	Hair pin		
43	1	1			9598- 0002- 02	Låsnål	Pin lock		
44	1	1			1482- 0917- 01	Sprint.....	Cotter bolt		
45	1	1			1482- 0536- 01	Växelhusolja (0.5 l).....	Gear case oil (0.5 l).....		



Utgåva Issue 2005- 12		Bildnr Picture No 1661A		JB 240 MINI TILLER 200 MOTOR		JB 240 MINI TILLER 200 ENGINE		Sida Page 206	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2224 -12 -82								
1	2				1482-1079-01	• Skruv	• Screw		
3	1				1482-1076-01	• Filterelem. (papper)	• Cleaner elem. (paper)		
4	2				1482-1066-01	• Skruv	• Screw		
5	1				1482-1077-01	• Luftfilterhus	• Cleaner inside cover		
6	1				1482-1051-01	Packning	Gasket		
7	1				1482-1037-01	Chokespjäll	Choke		
8	1				1482-1028-01	Fäste	Joint board		
9	1				1482-1052-01	Förgasare	Carburettor		
10	1				1482-0987-01	Packning	Gasket		
11	6				1482-1064-01	Skruv	Screw		
12	1				1482-1000-01	Insugningsrör	Inlet manifold		
13	1				1482-0998-01	Packning	Gasket		
14	4				1482-1053-01	Styrpinne	Guide pin		
15	9				1482-1061-01	Skruv	Screw		
16	1				1482-1024-01	Fläktkåpa	Fan cover		
17	2				1482-1031-01	Ansatsbult	Shoulder screw		
18	2				1482-0996-01	Bricka	Washer		
19	2				1482-0988-01	Kopplingssko	Clutch shoe		
20	2				1482-0990-01	Bricka	Washer		
21	1				1482-0989-01	Fjäder	Spring		
22	1				1482-1054-01	Mutter	Nut		
23	1				1482-1071-01	Bricka	Washer		
24	1				1482-1032-01	Stoppkabel	Stop cord		
25	1				1482-1002-01	Gummihylsa	Grommet		
26	1				1482-1033-01	Tändspole	Magneto stator		
26A	1				1482-1034-01	Svänghjul	Flywheel		
27	4				1482-1065-01	Skruv	Screw		
28	1				1482-1013-01	Vevhushalva	Crank case half		
29	1				1482-1001-01	Ledplåt	Guide plate		
30	1				1482-1014-01	Packning	Gasket		
31	2				1482-1047-01	Tätningring	Oil seal		
32	2				1482-1072-01	Kullager	Ball bearing		
33	1				1482-1050-01	Kil	Key		
34	1				1482-1006-01	Vevaxel	Crankshaft		
35	1				1482-1015-01	Vevhushalva	Crank case half		
36	1				1482-1016-01	Hållare- startspärr	Holder- starter pawl		
37	1				1482-1019-01	Fjäder	Spring		
38	1				1482-1018-01	Startspärr	Starter pawl		
39	1				1482-1068-01	• Skruv	• Screw		
40	1				1482-0992-01	• Returfjäder	• Recoil spring		
41	1				1482-0993-01	• Linhjul	• Starter pulley		
42	1				1482-0991-01	• Starthus	• Starter body		
43	1				1482-1035-01	Stöd	Stand		
44	1				1482-0994-01	• Startsnöre	• Starter rope		
45	1				1482-1046-01	• Starthandtag	• Starter handle		
46	2				1482-1030-01	Distanshylsa	Sleeve		
47	1				1482-1062-01	Skruv	Screw		
48	1				1482-1005-01	Lock	Cover		
49	1				1482-1027-01	Cylinderkåpa	Cover		
50	1				1482-1060-01	Skruv	Screw		
51	1				1482-1003-01	Tändstiftshatt	Spark plug cap		
52	1				1482-1049-01	Fjäder	Click spring		
53	1				1482-1004-01	Tändstiftslock	Spark plug cover		
54	1				1482-1074-01	Tändstift	Spark plug		
55	4				1482-1056-01	Skruv	Screw		
56	4				1482-1069-01	Bricka	Washer		
57	4				1482-1057-01	Bricka	Washer		
58	1				1482-0999-01	Packning	Gasket		
59	1				1482-1029-01	Ljuddämpare	Muffler		
60	2				1482-0997-01	Pinnbult	Stud		
61	3				1482-1070-01	Bricka	Washer		
62	2				1482-1055-01	Mutter	Nut		
63	1				1482-1017-01	Cylinder	Cylinder		



Utgåva Issue 2005- 12		Bildnr Picture No 1661A		JB 240 MINI TILLER 200 MOTOR		JB 240 MINI TILLER 200 ENGINE		Sida Page 208	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2224 -12 -82								
64	1				1482- 1020- 01	Packning.....	Gasket.....		Inkl pos 39- 42, 44- 45
65	2				1482- 1011- 01	Kolvring.....	Piston ring.....		
66	1				1482- 1012- 01	Kolv.....	Piston.....		
67	2				1482- 1007- 01	Låsring.....	Stop ring.....		
68	1				1482- 1009- 01	Kolvbult.....	Piston pin.....		
69	1				1482- 1010- 01	Nållager.....	Needle bearing.....		
70	2				1482- 1008- 01	Låsring.....	Piston pin circlet.....		
77	1				1482- 1022- 01	Bränslerör.....	Outlet fuel pipe.....		
78	1				1482- 1021- 01	Bränslerör.....	Inlet fuel pipe.....		
79	1				1482- 1048- 01	Gummihylsa.....	Grommet.....		
80	1				1482- 1023- 01	Bränslefilter.....	Fuel filter.....		
81	1				1482- 1036- 01	Bränsletank.....	Fuel tank.....		
82	1				1482- 1059- 01	Skruv.....	Screw.....		
83	2				1482- 1063- 01	Skruv.....	Screw.....		
84	1				1482- 0995- 01	Start kpl.....	Starter assy.....		
85	1				1482- 1025- 01	Stoppknapp (metall).....	Stop button (metal).....		
85	1				1482- 1025- 02	Stoppknapp (plast).....	Stop button (plastic).....		
86	1				1482- 1026- 01	Förgasarskydd.....	Carburettor guard.....		
87	1				1482- 1067- 01	Skruv.....	Screw.....		
88	1				1482- 1042- 01	Gasreglagekabel.....	Throttle cable.....		
89	1				1482- 1044- 01	Fäste- gasreglage.....	Throttle control base.....		
90	1				1482- 1058- 01	Låsring.....	Stop ring.....		
91	1				1482- 1043- 01	Gasreglage.....	Thr. control handle.....		
92	1				1482- 1045- 01	Axel.....	Locking pin.....		
93	1				1482- 1073- 01	Skruv.....	Screw.....		
95	1				1482- 0986- 01	Tanklock kpl.....	Fuel tank cap assy.....		
96	1				1482- 1078- 01	• Filterelement (skum).....	• Cleaner elem. (foam).....		
97	1				1482- 1075- 01	Luftfilter kpl.....	Air cleaner assy.....	Inkl. pos 1- 5, 96	