



www.stiga.com

Illustrated Parts List

for model:

SILEX 103 B

- Use GLOBAL GARDEN PRODUCT genuine spare parts specified in the parts list for repair and/or replacement.
- Then contents described in the parts list may change due to improvement.
- The drawings of the spare part are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


© Copyright 2014 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.


THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.

www.ggp-group.com







POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	9948-0655-16	1	Screw	
2	1483-2016-01	1	Accelerator	
3	1483-2017-01	1	Lever	
5	9699-0056-02	4	Flat washer	
6	118800090/0	1	Right Black Handle	
7	1483-2018-01	1	Support	
8	9997-0660-12	1	Screw	
9	1483-2142-01	1	Throttle Cable	
12	9699-0100-02	1	Washer	
13	9747-0631-02	1	Lock nut	
14	118800031/0	1	Transmission Unit	
15	9747-0631-02	4	Lock nut	
16	118800091/0	1	Left Black Handle	
17	1483-2213-01	2	Handgrip	
18	118800094/0	1	Clutch Lever Black	
19	9959-0816-16	2	Screw	
20	118800096/0	1	Yellow Carter	
22	9747-0631-02	1	Lock nut	
23	9672-0004-02	1	Lock washer	
25	9959-0816-16	2	Screw	
26	118800101/0	1	Yellow Strip	
28	118800098/0	2	Plate Yellow	
30	118800093/0	1	Yellow Handle Support	
33	118800099/0	2	Spring Spur Cutter	
34	9747-0631-02	2	Lock nut	
35	9747-0631-02	2	Lock nut	
36	118800102/0	1	Spur	
37	9747-0631-02	2	Lock nut	
38	118800103/0	1	Black Blade	
39	9959-0825-16	2	Screw	
40	9699-0122-02	1	Washer	
41	9959-0816-16	1	Screw	
43	118800032/0	1	Joint	
44	9959-0825-16	2	Screw	
45	118800104/0	1	Right Bracket Support	
45	118800105/0	1	Left Bracket Support	
47	9997-0620-16	2	Screw	
48	9997-1050-16	4	Screw	
49	1483-2173-01	2	Dust Cover	
50	118800110/1	1	Right Muff	
50	118800111/1	1	Left Muff	
52	9747-1031-02	4	Lock nut	
53	118800037/0	8	Right Tine Assy	
53	118800038/0	8	Left Tine Assy	
55	9747-0631-02	16	Lock nut	
56	1483-2173-01	2	Dust Cover	
57	1483-2117-01	2	Spacer	
58	118800106/0	1	Right Wheel	
58	118800107/0	1	Left Wheel	
60	118800034/0	2	Spring	
61	118800036/0	2	Screw	
62	9747-0631-02	2	Lock nut	
63	118800033/0	2	Clamp	
64	118800035/0	2	Yellow Spacer	
65	9997-0825-16	16	Screw	
66	118800108/0	1	Right Star	
66	118800109/0	1	Left Star	




POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
68	112793101/0	8	Screw	
70	118800037/0	4	Right Tine Assy	
70	118800038/0	4	Left Tine Assy	
71	9747-0831-02	8	Lock nut	
74	112691115/0	8	Screw	
75	118800079/0	1	Knob	
76	118800354/0	1	Lever	
77	118800087/0	1	Safety Pin	
78	118800493/0	1	Fair Lead	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	118550544/0	1	Double engine pulley	
2	118800040/0	1	Pinion	
3	118800379/0	1	Pin	
3	9699-0122-02	1	Washer	
4	9699-0028-02	1	Flat washer	
5	1483-2283-01	1	Screw	
6	1483-2216-01	1	Washer	
7	9699-0122-02	1	Washer	
8	9699-0028-02	1	Flat washer	
9	1483-2283-01	1	Screw	
14	118800039/0	1	Belt	
15	9549-0001-00	1	Bearing	
16	9959-0816-16	2	Screw	
17	118800041/0	1	Pinion	
20	118800120/0	1	Cap	
21	118800119/0	1	Left Hood	
22	118800117/0	1	Lever	
23	1483-2020-01	1	Spacer	
24	9747-1031-02	1	Lock nut	
25	1483-2215-01	1	Spacer	
26	118800042/0	1	Pulley	
27	9747-1231-02	1	Nut	
28	9650-0017-04	1	Retainer ring	
30	1483-2153-01	1	Spacer	
32	118800115/0	1	Support	
33	1483-2217-01	1	Spacer	
34	9959-0816-16	4	Screw	
35	118800118/0	1	Pulley	
36	1483-2157-01	1	Spring	
37	1483-2207-01	1	Spring	
38	9915-0610-15	4	Screw	
39	1483-2149-01	2	Belt	
40	118550543/0	1	Yellow Engine Support	
42	9747-0831-02	3	Lock nut	
43	9699-0028-02	3	Flat washer	
44	9997-0835-12	6	Screw	
44	9997-0835-12	1	Screw	
45	9959-0816-16	1	Screw	
46	118800114/0	1	Yellow Side Hood	
48	1483-2075-01	1	Cap	
50	118800112/0	1	Right Hood	
51	9959-0816-16	2	Screw	
52	9959-0816-16	2	Screw	
60	118800317/0	1	Spacer	
61	118800520/0	1	Spacer	
62	118800526/0	1	Grease Dispenser	
63	118800521/0	1	Spacer	
64	118800523/0	1	Washer	
65	118800362/0	1	Snap Ring	
66	118800116/0	1	Needle Bearing	
66	1483-2153-01	1	Spacer	
67	118800533/0	1	Screw	
68	118800379/0	1	Pin	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	118800121/0	1	Control Wheel Shaft	
2	1483-2187-01	1	Oil Seal	
3	118800379/0	1	Pin	
4	1483-2212-01	1	Cap	
5	1483-2070-01	1	Oil Seal	
6	9959-0612-16	25	Screw	
7	118800373/0	1	Bearing	
10	1483-2194-01	1	Washer	
11	9747-0631-02	1	Lock nut	
12	118800123/0	1	Shaft Tine Command	
13	118800124/0	1	Gear	
14	118800125/0	1	Chain	
22	118800126/0	1	Cams Control Cutter	
23	1483-2201-01	1	Spring	
24	118800050/0	1	Bearing	
26	118800349/0	1	Ring Gear	
27	1483-2281-01	1	Dowel	
28	118800348/0	1	Ring Gear	
29	118800046/0	1	Gasket	
30	9747-0631-02	25	Lock nut	
31	118800373/0	1	Bearing	
32	118800050/0	1	Bearing	
33	118800339/0	1	Case Right, Red	
35	1483-2117-01	1	Spacer	
36	118800035/0	1	Yellow Spacer	
37	118800345/0	1	Selector	
39	118800344/0	1	Shaft	
40	9747-0631-02	6	Lock nut	
42	1483-2069-01	1	Oil Seal	
43	1483-2275-01	1	O Ring	
45	118800347/0	1	Lever	
46	118800346/0	1	Lever	
48	118800122/0	1	Bearing	
51	118800350/0	1	Ring Gear	
58	118800043/0	1	Ring Gear	
59	118800045/0	1	Joint Chair Assy	
60	118800044/0	1	Joint Chair Assy	
62	118800351/0	1	Ring Gear	
63	118800122/0	1	Bearing	
64	118800336/0	1	Case, Yellow Left	
71	118800377/0	1	Pin	
72	118800518/0	1	Belt Guide	
73	118800519/0	1	Tube	
74	118800379/0	1	Pin	
75	118800527/0	2	Pin	
76	118800517/0	2	Lever	
77	118800341/0	1	Spring, Right	
77	118800342/0	1	Spring, Left	
78	118800340/0	2	Pin	
79	112521360/0	1	Washer	
80	118800497/0	2	Cotter Pin	
81	118800358/0	1	Ring	
82	118800371/0	1	Needle Bearing	
83	118800361/0	1	Snap Ring	
84	118800370/0	1	Needle Bearing	
85	118800360/0	2	Snap Ring	
86	118800352/0	1	Spacer	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
87	118800353/0	1	Spacer	
88	118800355/0	88	Spacer	
89	118800357/0	1	Ring	
90	118800383/0	2	Screw	
91	112154330/0	2	Low Self-Locking Nut	