



[www.stiga.com](http://www.stiga.com)

# Illustrated Parts List

**for model:**

**SILEX 95 H**

- Use GLOBAL GARDEN PRODUCT genuine spare parts specified in the parts list for repair and/or replacement.
- Then contents described in the parts list may change due to improvement.
- The drawings of the spare part are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


© Copyright 2014 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.


THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.

[www.ggp-group.com](http://www.ggp-group.com)







| Chassis |              |      |                         |       |
|---------|--------------|------|-------------------------|-------|
| POS     | CODE         | Q.TY | DESCRIPTION             | NOTES |
| 1       | 9747-1031-02 | 1    | Lock nut                |       |
| 2       | 9699-0035-02 | 1    | Flat washer             |       |
| 3       | 1483-2085-01 | 1    | Spacer                  |       |
| 4       | 118800047/0  | 1    | Support                 |       |
| 5       | 9959-0816-16 | 1    | Screw                   |       |
| 6       | 9699-0028-02 | 1    | Flat washer             |       |
| 8       | 9747-0831-02 | 2    | Lock nut                |       |
| 9       | 1483-2108-01 | 2    | Spacer                  |       |
| 10      | 9959-0825-16 | 1    | Screw                   |       |
| 11      | 118800491/0  | 1    | Spacer                  |       |
| 12      | 118800048/0  | 1    | Spring Rear Cover       |       |
| 13      | 118800049/0  | 1    | Tend Arm Strap          |       |
| 14      | 1483-2001-01 | 1    | Bush                    |       |
| 15      | 118800508/0  | 1    | Support                 |       |
| 16      | 9997-1025-16 | 1    | Screw                   |       |
| 17      | 1483-2004-01 | 1    | Pulley                  |       |
| 18      | 9650-0012-04 | 1    | Circlip                 |       |
| 19      | 118800050/0  | 2    | Bearing                 |       |
| 20      | 118800051/0  | 1    | Spacer                  |       |
| 21      | 118800001/0  | 1    | Belt                    |       |
| 22      | 118800052/0  | 1    | Pulley                  |       |
| 23      | 118800053/0  | 1    | Spacer                  |       |
| 24      | 118800054/0  | 1    | Countershaft            |       |
| 25      | 118800055/0  | 1    | Pulley                  |       |
| 26      | 1483-2326-01 | 1    | Pulley                  |       |
| 27      | 1483-2352-01 | 1    | Belt                    |       |
| 28      | 112139100/0  | 1    | Key                     |       |
| 29      | 118800056/0  | 1    | Pulley                  |       |
| 30      | 118800057/0  | 1    | Spacer                  |       |
| 31      | 118800058/0  | 1    | Support                 |       |
| 32      | 1483-2203-01 | 1    | Spacer                  |       |
| 33      | 118800506/0  | 1    | Spacer                  |       |
| 36      | 9987-5225-16 | 1    | Screw                   |       |
| 37      | 9997-0835-12 | 1    | Screw                   |       |
| 38      | 9699-0122-02 | 1    | Washer                  |       |
| 39      | 118550541/0  | 1    | Yellow Engine Top Cover |       |
| 40      | 1483-2082-01 | 2    | Pulley                  |       |
| 41      | 9699-0105-02 | 2    | Washer                  |       |
| 42      | 112292100/0  | 1    | Hexagonal Nut           |       |
| 43      | 1483-2190-01 | 1    | Nut                     |       |
| 44      | 9699-0100-02 | 1    | Washer                  |       |
| 45      | 9683-0025-02 | 1    | Lock washer             |       |
| 46      | 9959-0612-16 | 1    | Screw                   |       |
| 47      | 118800059/0  | 2    | Bearing                 |       |
| 48      | 118800504/0  | 1    | Chassis Yellow          |       |
| 49      | 1483-2069-01 | 1    | Oil Seal                |       |
| 50      | 118800060/0  | 1    | Dust Cover              |       |
| 51      | 118800061/0  | 1    | Right Wheel             |       |
| 51      | 118800062/0  | 1    | Left Wheel              |       |
| 52      | 118800500/0  | 2    | Pin                     |       |
| 53      | 9501-0500-00 | 1    | Grease Dispenser        |       |
| 54      | 118800499/0  | 1    | Bushing                 |       |
| 55      | 9699-0035-02 | 2    | Flat washer             |       |
| 56      | 1483-2332-01 | 1    | Lever                   |       |
| 57      | 9747-1031-02 | 2    | Lock nut                |       |
| 58      | 1483-2075-01 | 1    | Cap                     |       |
| 59      | 118800325/0  | 1    | Gear                    |       |
| 60      | 118800327/0  | 1    | Chain                   |       |
| 61      | 118800369/0  | 1    | Bearing                 |       |
| 62      | 118800363/0  | 1    | Snap Ring               |       |
| 63      | 118800321/0  | 1    | Spacer                  |       |
| 64      | 118800364/0  | 1    | Or Ring                 |       |
| 65      | 118800372/0  | 1    | Bearing                 |       |
| 66      | 118800322/0  | 1    | Gear                    |       |
| 67      | 118800380/0  | 1    | Pin                     |       |
| 68      | 1483-2281-01 | 1    | Dowel                   |       |
| 69      | 118800323/0  | 1    | Selector                |       |
| 70      | 1483-2201-01 | 1    | Spring                  |       |
| 71      | 9959-0616-16 | 2    | Screw                   |       |
| 72      | 118800063/0  | 1    | Gear Fork               |       |
| 73      | 118800064/0  | 1    | Oil Seal                |       |
| 74      | 118800065/0  | 1    | Oil Seal                |       |
| 75      | 1483-2275-01 | 1    | O Ring                  |       |
| 76      | 118800324/0  | 1    | Gear                    |       |
| 77      | 118800326/0  | 1    | Bushing                 |       |
| 79      | 118800356/0  | 1    | Ring                    |       |



| Chassis |              |      |               |       |
|---------|--------------|------|---------------|-------|
| POS     | CODE         | Q.TY | DESCRIPTION   | NOTES |
| 80      | 118800320/0  | 1    | Dust Cover    |       |
| 81      | 118800368/0  | 1    | Bearing       |       |
| 82      | 118800318/0  | 1    | Right Housing |       |
| 82      | 118800319/0  | 1    | Left Housing  |       |
| 83      | 9997-0620-16 | 1    | Screw         |       |
| 84      | 112760475/0  | 4    | Screw         |       |
| 85      | 118800530/0  | 4    | Screw         |       |
| 86      | 9747-0531-02 | 8    | Nut           |       |
| 87      | 118800507/0  | 1    | Worm          |       |




| Handle |              |      |                        |       |
|--------|--------------|------|------------------------|-------|
| POS    | CODE         | Q.TY | DESCRIPTION            | NOTES |
| 1      | 9747-0831-02 | 9    | Nut                    |       |
| 2      | 9699-0122-02 | 4    | Washer                 |       |
| 3      | 118802964/0  | 2    | Lever                  |       |
| 4      | 118800015/0  | 1    | Spring                 |       |
| 5      | 118800071/0  | 1    | White Cover Tine       |       |
| 6      | 118800515/0  | 1    | Cover                  |       |
| 7      | 118800007/0  | 1    | Pulley                 |       |
| 8      | 118800006/0  | 1    | Belt                   |       |
| 9      | 1483-2071-01 | 1    | Bearing                |       |
| 10     | 118800516/0  | 1    | Worm                   |       |
| 11     | 1483-2189-01 | 1    | O Ring                 |       |
| 12     | 118800514/0  | 1    | Lever                  |       |
| 13     | 1483-2020-01 | 1    | Spacer                 |       |
| 14     | 118800072/0  | 1    | Black Knob             |       |
| 15     | 118800073/0  | 1    | Lever Command          |       |
| 16     | 112674550/0  | 1    | Screw                  |       |
| 17     | 118800074/0  | 1    | Locking Lever Spring   |       |
| 18     | 118800513/0  | 1    | Bushing                |       |
| 19     | 9747-0631-02 | 4    | Nut                    |       |
| 20     | 118800075/0  | 1    | White Chassis Tine     |       |
| 21     | 1483-2069-01 | 1    | Oil Seal               |       |
| 22     | 118800076/0  | 1    | Spur                   |       |
| 23     | 9699-0028-02 | 8    | Flat washer            |       |
| 24     | 9997-0825-16 | 2    | Screw                  |       |
| 25     | 118803013/0  | 4    | Washer                 |       |
| 26     | 118803018/0  | 1    | Screw                  |       |
| 27     | 118800077/0  | 1    | Blade Standard         |       |
| 28     | 9997-0835-12 | 1    | Screw                  |       |
| 29     | 118800008/0  | 1    | Right Tine Assy        |       |
| 29     | 118800009/0  | 1    | Left Tine Assy         |       |
| 30     | 9959-0825-16 | 1    | Screw                  |       |
| 31     | 9959-0816-16 | 1    | Screw                  |       |
| 32     | 1483-2013-01 | 1    | Right Tine             |       |
| 32     | 1483-2014-01 | 1    | Left Tine              |       |
| 33     | 9799-1231-02 | 1    | Nut                    |       |
| 34     | 9948-0655-16 | 1    | Screw                  |       |
| 36     | 1483-2143-01 | 1    | Accelerator            |       |
| 37     | 9699-0056-02 | 1    | Flat washer            |       |
| 38     | 9997-0850-12 | 1    | Screw                  |       |
| 39     | 1483-2021-01 | 1    | Support                |       |
| 41     | 118800003/0  | 1    | Lever                  |       |
| 42     | 1483-2005-01 | 1    | Pin                    |       |
| 43     | 1483-2213-01 | 1    | Handgrip               |       |
| 44     | 9747-0531-02 | 1    | Nut                    |       |
| 45     | 118802970/0  | 1    | Handle                 |       |
| 46     | 118802968/0  | 1    | Cable                  |       |
| 47     | 118800004/0  | 1    | Wire                   |       |
| 48     | 118800078/0  | 1    | Pin                    |       |
| 49     | 118802967/0  | 1    | Handle                 |       |
| 50     | 1483-2108-01 | 2    | Spacer                 |       |
| 51     | 112692050/0  | 2    | Screw                  |       |
| 52     | 118800492/0  | 1    | Fair Lead              |       |
| 54     | 118800079/0  | 1    | Knob                   |       |
| 55     | 1483-2142-01 | 1    | Throttle Cable         |       |
| 56     | 118800082/0  | 1    | Red Support Tube       |       |
| 57     | 118800495/0  | 1    | Hook                   |       |
| 58     | 118802962/0  | 1    | Knob                   |       |
| 59     | 118802963/0  | 1    | Handle                 |       |
| 60     | 118800524/0  | 1    | Or Ring                |       |
| 61     | 118800522/0  | 1    | Benzing Ring           |       |
| 62     | 118800010/0  | 1    | Screw                  |       |
| 64     | 1483-2078-01 | 1    | Disc                   |       |
| 65     | 118800084/0  | 1    | Frame Cover Yellow Box |       |
| 66     | 118800085/0  | 1    | Rod Clutch Gear        |       |
| 67     | 118800086/0  | 1    | Junction Rod           |       |
| 69     | 118800087/0  | 3    | Safety Pin             |       |
| 70     | 118800528/0  | 1    | Pin                    |       |
| 71     | 118800510/0  | 1    | Lever                  |       |
| 72     | 118802966/0  | 1    | Lever                  |       |
| 73     | 118803016/0  | 1    | Pin                    |       |
| 74     | 118800088/0  | 1    | Rod Gear               |       |
| 75     | 118800002/0  | 1    | Fairlead               |       |
| 76     | 118800509/0  | 1    | Spacer                 |       |
| 77     | 118800089/0  | 1    | Locking Lever Spring   |       |
| 78     | 1483-2333-01 | 1    | Plate                  |       |






| Blade |              |      |                  |       |
|-------|--------------|------|------------------|-------|
| POS   | CODE         | Q.TY | DESCRIPTION      | NOTES |
| 1     | 118800013/0  | 1    | Cover            |       |
| 2     | 9747-0831-02 | 4    | Lock nut         |       |
| 3     | 9699-0122-02 | 1    | Washer           |       |
| 4     | 9799-1031-02 | 1    | Nut              |       |
| 6     | 1483-2085-01 | 2    | Spacer           |       |
| 7     | 118800011/0  | 1    | Belt             |       |
| 8     | 118800014/0  | 1    | Grommet          |       |
| 9     | 112540060/0  | 1    | Washer           |       |
| 10    | 118800302/0  | 1    | Pulley           |       |
| 11    | 1483-2210-01 | 2    | Spacer           |       |
| 12    | 118800050/0  | 1    | Bearing          |       |
| 13    | 118800382/0  | 1    | Cap              |       |
| 14    | 118800332/0  | 1    | Shaft            |       |
| 15    | 118800333/0  | 1    | Spacer           |       |
| 16    | 118800357/0  | 1    | Ring             |       |
| 17    | 118800369/0  | 1    | Bearing          |       |
| 18    | 118800359/0  | 1    | Ring             |       |
| 19    | 118800512/0  | 1    | Support          |       |
| 20    | 118800015/0  | 1    | Spring           |       |
| 21    | 118800066/0  | 1    | Pulley           |       |
| 22    | 118800012/0  | 3    | Belt             |       |
| 23    | 1483-2285-01 | 1    | Spacer           |       |
| 24    | 118800374/0  | 1    | Bearing          |       |
| 25    | 118800067/0  | 1    | Pulley           |       |
| 26    | 118800317/0  | 1    | Spacer           |       |
| 27    | 118800315/0  | 1    | Pulley           |       |
| 28    | 9959-0816-16 | 1    | Screw            |       |
| 29    | 9699-0028-02 | 2    | Flat washer      |       |
| 30    | 9699-0028-02 | 1    | Flat washer      |       |
| 32    | 118800334/0  | 1    | Eccentric        |       |
| 33    | 118800529/0  | 2    | Pin              |       |
| 34    | 118800531/0  | 1    | Screw            |       |
| 35    | 118800358/0  | 1    | Ring             |       |
| 36    | 9747-0631-02 | 1    | Lock nut         |       |
| 37    | 118800314/0  | 1    | Pulley           |       |
| 39    | 9699-0100-02 | 1    | Washer           |       |
| 40    | 118800068/0  | 1    | Rear Guide Plate |       |
| 41    | 9959-0616-16 | 1    | Screw            |       |
| 42    | 9799-0831-02 | 1    | Nut              |       |
| 43    | 118800385/0  | 1    | Screw            |       |
| 44    | 1483-2338-01 | 1    | Plate            |       |
| 45    | 118800069/0  | 1    | Blade Support    |       |
| 46    | 118800020/0  | 1    | Top Blade        |       |
| 47    | 118800017/0  | 1    | Guide            |       |
| 49    | 112792611/0  | 4    | Screw            |       |
| 50    | 1483-2340-01 | 2    | Blade Guard      |       |
| 51    | 118800021/0  | 1    | Bottom Blade     |       |
| 52    | 1483-2336-01 | 1    | Plate            |       |
| 53    | 118800022/0  | 1    | Rivet            |       |
| 54    | 9747-1031-02 | 1    | Lock nut         |       |
| 55    | 118800621/0  | 1    | Plate            |       |
| 56    | 118800018/0  | 1    | Guide R          |       |
| 57    | 118800019/0  | 1    | Guide L          |       |
| 58    | 9997-0830-16 | 1    | Screw            |       |
| 59    | 118800070/0  | 2    | Body Bar         |       |
| 60    | 1483-2341-01 | 1    | Shoe             |       |
| 61    | 9699-0122-02 | 1    | Washer           |       |
| 62    | 118800016/0  | 1    | Support          |       |
| 63    | 118800622/0  | 1    | Plate            |       |




| Optionals On Request |              |      |              |       |
|----------------------|--------------|------|--------------|-------|
| POS                  | CODE         | Q.TY | DESCRIPTION  | NOTES |
| 1                    | 118800029/0  | 1    | Cover        |       |
| 2                    | 9847-8016-16 | 1    | Screw        |       |
| 3                    | 9747-1031-02 | 1    | Lock nut     |       |
| 4                    | 9699-0122-02 | 1    | Washer       |       |
| 5                    | 1483-2085-01 | 1    | Spacer       |       |
| 6                    | 1483-2325-01 | 1    | Pulley       |       |
| 7                    | 1483-2352-01 | 1    | Belt         |       |
| 8                    | 1483-2203-01 | 1    | Spacer       |       |
| 9                    | 1483-2192-01 | 2    | Bearing      |       |
| 11                   | 118800134/0  | 1    | Protection   |       |
| 13                   | 9699-0035-02 | 1    | Flat washer  |       |
| 14                   | 9699-0100-02 | 1    | Washer       |       |
| 15                   | 9747-0631-02 | 2    | Lock nut     |       |
| 16                   | 118800135/0  | 1    | Handle       |       |
| 17                   | 9959-0816-16 | 1    | Screw        |       |
| 18                   | 9747-0831-02 | 2    | Lock nut     |       |
| 19                   | 118800136/0  | 1    | Protection   |       |
| 21                   | 9997-0612-16 | 1    | Screw        |       |
| 22                   | 118800137/0  | 1    | Protection   |       |
| 23                   | 118800138/0  | 1    | Support      |       |
| 27                   | 118800030/0  | 1    | Shoe         |       |
| 31                   | 1483-2210-01 | 2    | Spacer       |       |
| 33                   | 118800028/0  | 1    | Support      |       |
| 34                   | 118800026/0  | 1    | Winged Blade |       |
| 36                   | 9987-5225-16 | 1    | Screw        |       |
| 39                   | 118800015/0  | 1    | Spring       |       |
| 40                   | 9699-0122-02 | 1    | Washer       |       |
| 41                   | 118800027/0  | 1    | Guard        |       |



| Front adjustable brush 82 cm |              |      |                  |       |
|------------------------------|--------------|------|------------------|-------|
| POS                          | CODE         | Q.TY | DESCRIPTION      | NOTES |
| 1                            | 118800145/0  | 1    | Knob             |       |
| 2                            | 118800146/0  | 1    | Handle           |       |
| 3                            | 118800015/0  | 1    | Spring           |       |
| 4                            | 118800147/0  | 1    | Protection       |       |
| 5                            | 9959-0816-16 | 8    | Screw            |       |
| 7                            | 9959-0616-16 | 4    | Screw            |       |
| 8                            | 9799-1231-02 | 1    | Nut              |       |
| 9                            | 9699-0035-02 | 1    | Flat washer      |       |
| 10                           | 1483-2085-01 | 3    | Spacer           |       |
| 11                           | 1483-2325-01 | 1    | Pulley           |       |
| 12                           | 118800148/0  | 1    | Belt             |       |
| 13                           | 9747-1031-02 | 2    | Lock nut         |       |
| 14                           | 118800050/0  | 1    | Bearing          |       |
| 15                           | 1483-2326-01 | 1    | Pulley           |       |
| 16                           | 118800051/0  | 1    | Spacer           |       |
| 17                           | 118800058/0  | 1    | Support          |       |
| 18                           | 1483-2108-01 | 1    | Spacer           |       |
| 22                           | 9747-0831-02 | 1    | Lock nut         |       |
| 24                           | 118800150/0  | 1    | Pin              |       |
| 27                           | 118800024/0  | 1    | Belt             |       |
| 30                           | 1483-2192-01 | 1    | Bearing          |       |
| 32                           | 1483-2068-01 | 1    | Seeger           |       |
| 33                           | 1483-2000-01 | 1    | Spacer           |       |
| 34                           | 1483-2072-01 | 1    | Needle Bearing   |       |
| 35                           | 1483-2081-01 | 1    | Screw            |       |
| 36                           | 118800151/0  | 1    | Shaft            |       |
| 37                           | 9847-8016-16 | 2    | Screw            |       |
| 38                           | 118800290/0  | 1    | Cover            |       |
| 39                           | 118800025/0  | 1    | Spring           |       |
| 42                           | 9747-1031-02 | 2    | Lock nut         |       |
| 44                           | 118800282/0  | 1    | Plate            |       |
| 45                           | 118800152/0  | 1    | Right Protection |       |
| 45                           | 118800153/0  | 1    | Left Protection  |       |
| 46                           | 9699-0121-02 | 2    | Washer           |       |
| 47                           | 9747-1231-02 | 2    | Nut              |       |
| 48                           | 112794985/0  | 2    | Screw            |       |
| 49                           | 1483-2190-01 | 1    | Nut              |       |
| 50                           | 1483-2010-01 | 1    | Dust Cover       |       |
| 51                           | 118800154/0  | 2    | Brush            |       |
| 52                           | 9699-0035-02 | 2    | Flat washer      |       |
| 53                           | 1483-2070-01 | 1    | Oil Seal         |       |
| 56                           | 118800053/0  | 2    | Spacer           |       |
| 57                           | 9598-0002-02 | 2    | Spring Pin       |       |
| 58                           | 118800155/0  | 1    | Right Support    |       |
| 58                           | 118800156/0  | 1    | Left Support     |       |
| 59                           | 118800157/0  | 2    | Wheel            |       |
| 60                           | 1483-2195-01 | 2    | Washer           |       |
| 61                           | 118800158/0  | 1    | Chassis          |       |
| 62                           | 1483-2075-01 | 1    | Cap              |       |
| 63                           | 1483-2191-01 | 1    | Nut              |       |




| Front adjustable brush 82 cm - Collector |              |      |             |       |
|------------------------------------------|--------------|------|-------------|-------|
| POS                                      | CODE         | Q.TY | DESCRIPTION | NOTES |
| 1                                        | 118800139/0  | 1    | Blade       |       |
| 2                                        | 118800140/0  | 1    | Support     |       |
| 3                                        | 118800141/0  | 1    | Container   |       |
| 6                                        | 118800142/0  | 1    | Wheel       |       |
| 7                                        | 9747-1031-02 | 4    | Lock nut    |       |
| 8                                        | 9699-0035-02 | 5    | Flat washer |       |
| 9                                        | 9959-0616-16 | 1    | Screw       |       |
| 10                                       | 9747-0631-02 | 1    | Lock nut    |       |
| 11                                       | 1483-2194-01 | 2    | Washer      |       |
| 15                                       | 118800143/0  | 1    | Wheel       |       |
| 16                                       | 118800144/0  | 2    | Support     |       |
| 18                                       | 9699-0105-02 | 1    | Washer      |       |
| 19                                       | 9997-0620-16 | 1    | Screw       |       |





| Ridging plough |              |      |             |       |
|----------------|--------------|------|-------------|-------|
| POS            | CODE         | Q.TY | DESCRIPTION | NOTES |
| 1              | 118800285/0  | 1    | Ridger      |       |
| 2              | 118800286/0  | 1    | Support     |       |
| 3              | 9699-0121-02 | 1    | Washer      |       |
| 4              | 9598-0003-02 | 2    | Spring pin  |       |



| Front mount snow blade 85 cm |              |      |                  |       |
|------------------------------|--------------|------|------------------|-------|
| POS                          | CODE         | Q.TY | DESCRIPTION      | NOTES |
| 1                            | 1483-2079-01 | 1    | Handgrip         |       |
| 2                            | 118800294/0  | 1    | Handle           |       |
| 3                            | 118800298/0  | 1    | Screw            |       |
| 4                            | 118800295/0  | 1    | Spring           |       |
| 5                            | 9699-0121-02 | 1    | Washer           |       |
| 6                            | 9747-1231-02 | 1    | Nut              |       |
| 7                            | 118800299/0  | 1    | Screw            |       |
| 8                            | 9699-0119-02 | 1    | Washer           |       |
| 9                            | 118800293/0  | 1    | Support          |       |
| 10                           | 9501-0500-00 | 1    | Grease Dispenser |       |
| 11                           | 9699-0119-02 | 1    | Washer           |       |
| 12                           | 118800296/0  | 1    | Nut              |       |
| 13                           | 118800291/0  | 1    | Protection       |       |
| 14                           | 118800292/0  | 1    | Spacer           |       |
| 15                           | 1483-2297-01 | 1    | Spacer           |       |
| 16                           | 9598-0003-02 | 1    | Spring pin       |       |
| 17                           | 118800297/0  | 5    | Screw            |       |
| 18                           | 118800284/0  | 5    | Blade            |       |
| 20                           | 9699-0028-02 | 5    | Flat washer      |       |
| 21                           | 9747-0831-02 | 5    | Lock nut         |       |



| Front adjustable brush 105 cm |              |      |                |       |
|-------------------------------|--------------|------|----------------|-------|
| POS                           | CODE         | Q.TY | DESCRIPTION    | NOTES |
| 1                             | 118800145/0  | 1    | Knob           |       |
| 2                             | 118800146/0  | 1    | Handle         |       |
| 3                             | 118800015/0  | 1    | Spring         |       |
| 4                             | 118800147/0  | 1    | Protection     |       |
| 5                             | 9959-0816-16 | 8    | Screw          |       |
| 7                             | 9959-0616-16 | 4    | Screw          |       |
| 8                             | 9799-1231-02 | 1    | Nut            |       |
| 9                             | 9699-0035-02 | 1    | Flat washer    |       |
| 10                            | 1483-2085-01 | 3    | Spacer         |       |
| 11                            | 1483-2082-01 | 1    | Pulley         |       |
| 12                            | 118800023/0  | 1    | Belt           |       |
| 13                            | 9747-1031-02 | 2    | Lock nut       |       |
| 14                            | 118800050/0  | 1    | Bearing        |       |
| 15                            | 1483-2325-01 | 1    | Pulley         |       |
| 16                            | 118800051/0  | 1    | Spacer         |       |
| 17                            | 118800058/0  | 1    | Support        |       |
| 18                            | 1483-2108-01 | 1    | Spacer         |       |
| 22                            | 9747-0831-02 | 1    | Lock nut       |       |
| 24                            | 118800150/0  | 1    | Pin            |       |
| 27                            | 118800024/0  | 1    | Belt           |       |
| 30                            | 1483-2192-01 | 1    | Bearing        |       |
| 32                            | 1483-2068-01 | 1    | Seeger         |       |
| 33                            | 1483-2000-01 | 1    | Spacer         |       |
| 34                            | 1483-2072-01 | 1    | Needle Bearing |       |
| 35                            | 1483-2081-01 | 1    | Screw          |       |
| 36                            | 118800151/0  | 1    | Shaft          |       |
| 37                            | 9847-8016-16 | 2    | Screw          |       |
| 38                            | 118800290/0  | 1    | Cover          |       |
| 39                            | 118800025/0  | 1    | Spring         |       |
| 42                            | 9747-1031-02 | 2    | Lock nut       |       |
| 44                            | 118800282/0  | 1    | Plate          |       |
| 45                            | 118800288/0  | 1    | Protection     |       |
| 45                            | 118800289/0  | 1    | Protection     |       |
| 46                            | 9699-0121-02 | 2    | Washer         |       |
| 47                            | 9747-1231-02 | 2    | Nut            |       |
| 48                            | 112794985/0  | 2    | Screw          |       |
| 49                            | 1483-2190-01 | 1    | Nut            |       |
| 50                            | 1483-2010-01 | 1    | Dust Cover     |       |
| 51                            | 118800283/0  | 2    | Brush          |       |
| 52                            | 9699-0035-02 | 2    | Flat washer    |       |
| 53                            | 1483-2070-01 | 1    | Oil Seal       |       |
| 56                            | 118800053/0  | 2    | Spacer         |       |
| 57                            | 9598-0002-02 | 2    | Spring Pin     |       |
| 58                            | 118800155/0  | 1    | Right Support  |       |
| 58                            | 118800156/0  | 1    | Left Support   |       |
| 59                            | 118800157/0  | 2    | Wheel          |       |
| 60                            | 1483-2195-01 | 2    | Washer         |       |
| 61                            | 118800287/0  | 1    | Chassis        |       |
| 62                            | 1483-2075-01 | 1    | Cap            |       |
| 63                            | 1483-2191-01 | 1    | Nut            |       |