

# Genuine Spare Parts

www.stiga.com


## SBL 620 B Model Year 2010

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.








## SBL 620 B

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	123071006/0	Cylinder	Cylinder Assy	
2	1	123878046/0	Skruv	Screw	
3	1	123073506/0	Insugningsrör	Intake Manifold	
4	1	123208404/0	Fläns	Flange	
4	1	123878035/0	Skruv	Screw	
5	1	123878037/0	Skruv	Screw	
6	1	183740002/0	Ljuddämpare	Muffler	
7	1	123220005/0	Gnistsläckare	Arrester	
8	1	123878038/0	Skruv	Screw	
9	1	183057004/0	Vevhus	Crankcase	
10	1	123280016/0	Packning	Gasket	
11	1	114215213/0	Kullager	Ball Bearing	
12	1	119035158/0	Tätningring	Seal Ring	
13	1	119035156/0	Tätningring	Seal Ring	
14	1	123878045/0	Skruv	Screw	
15	1	112610000/0	Låsring	Ring	
16	1	123590001/0	Kolv	Piston	
17	2	123204001/0	Kolvring	Piston Ring	
18	1	6995129	Kolvbult	Piston Pin	
19	1	6995093	Låsring	Snap Ring	
20	1	6995021	Lager	Needle Bearing	
21	1	6995041	Bricka	Washer	
22	1	123020016/0	Vevaxel	Crankshaft	
23	1	123120003/0	Mutter	Nut	
24	1	6995018	Kil	Flywheel Key	
25	1	123880003/0	Svängjul	Flywheel	
26	1	123044004/0	Elektronikspole	Electronic Coil	
27	1	6995234	Skruv	Screw	
28	1	123053000/0	Tändstiftshatt	Spark Plug Cover	
29	1	123430576/0	Tändstiftshatt	Spark Plug Spring	
30	1	3210024	Tändstift	Spark Plug	
31	1	123109529/0	Tändstiftshatt	Spark Plug Cover	
32	1	183065009/0	Jordkabel	Earth Cable	
33	1	183058013/0	Start kpl	Starter Ass.Y	
34	1	123604004/0	Startskiva	Starter Pulley	
35	1	123878041/0	Skruv	Screw	
36	1	123054018/0	Förgasare	Carburettor	
37	1	183781000/0	Luftfilterhus	Air Filter Holder	
38	1	183090002/0	Luftfilterkåpa	Filter Cover	
39	1	123220006/0	Luftfilter	Air Filter	
40	1	123208403/0	Fläns	Flange	
41	1	123878034/0	Skruv	Screw	
42	1	123654000/0	Skydd	Guard	
43	1	123878036/0	Skruv	Screw	
44	1	123878039/0	Skruv	Screw	
45	1	183303507/0	Packning	Gasket Ass' Y	





## SBL 620 B

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	123690002/0	Luftledare	Air Conveyor	
2	1	123690003/0	Luftledare	Air Conveyor	
3	1	123650003/0	Rörförbindning	Tube Connection	
4	1	112020000/0	O-ring	O Ring	
5	1	123878040/0	Skruv	Screw	
6	1	23120000/0	Mutter	Nut	
7	1	123109530/0	Kåpa	Cover	
8	1	123867007/0	Rör	Tube	
9	1	123876000/0	Fläkt	Fan	
10	1	123106016/0	Cylinderkåpa-gul	Yellow Cylinder Cover	
11	1	123890000/0	Ryggfäste	Knap Sack	
12	1	123669000/0	Baksida	Back	
13	1	112500095/0	Rivet	Rivet	
14	1	123046001/0	Sele	Harness	
15	1	123275016/0	Hylsa	Grommet	
16	1	123275017/0	Hylsa	Grommet	
17	1	183733002/0	Bränsletank kpl	Kit Fuel Tank	
18	1	183790007/0	Tanklock	Cap Ass'Y, Fuel Tank	
19	1	6995069	Bränslefilter	Intake Filter Assy	
20	1	183300013/0	Handtag kpl	Handle Ass.Y	
21	1	183065010/0	Stoppkabel	Stop Wire	
22	1	123315071/0	Gasreglage	Throttle Lever	
23	1	123315072/0	Säkerhetsspärr	Safety Lever	
24	1	123430574/0	Fjäder	Spring	
25	1	123430575/0	Fjäder	Spring	
26	1	123867010/0	Rör	Tube	
27	1	123867008/0	Rör	Tube	
28	1	123867012/0	Rör	Tube	
29	1	123867009/0	Rör	Tube	
30	1	123206850/0	Klämma	Clamp	
31	1	123206851/0	Klämma	Clamp	
32	1	183780000/0	Handtagsstöd	Handgrip Support Ass.Y	