

Genuine Spare Parts

www.stiga.com

SNOW PRISMA BASIC


includes:
18-2815-31 Snow Prisma Basic

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.






Utgåva Issue 2013-11		Bildnr Picture No 2853		SNOW PRISMA STYRE REGLAGE		SNOW PRISMA HANDLE CONTROLS		Sida Page 2	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
10	4				1812-2641-01	Skruv.....	Screw.....		
20	1				1812-2568-01	Styre-undre	Handlebar-lower.....		
30	1				1812-3069-01	Styre-övre	Handlebar-upper.....		
40	1				1812-2909-01	Reglagebygel.....	Engine stop bail.....		
50	1				1812-2653-01	Vagnsbult.....	Carriage bolt.....		
60	2				1812-3039-01	Låsratt	Handle knob		
70	2				1812-2572-01	Snörguide.....	Rope guide		
80	1				9743-3521-32	Mutter	Nut.....		




Utgåva Issue 2013-11		Bildnr Picture No 2763B		SNOW PRISMA RAM		SNOW PRISMA FRAME		Sida Page 4	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
x 10	1				1812-3129-01	Ram kpl	Frame assy		
20	1				1812-2555-01	Transmissionshus.....	Drive housing.....		
30	3				9987-5119-16	Skruv.....	Screw.....		
35	3				1812-2945-01	Bricka	Washer.....		
40	3				9955-3732-12	Skruv.....	Screw.....		
50	1				1812-2578-01	Utkaströr	Chimney.....		
60	5				1812-2765-01	Skruv.....	Screw.....		
70	1				1812-2713-01	Skrapskär	Scraper bar		
75	1				1812-2762-01	Stöd.....	Support.....		
80	4				1812-3010-01	Skruv.....	Screw.....		
110	4				1812-2939-01	Mutter	Nut.....		






Utgåva Issue 2013-11		Bildnr Picture No 2854		SNOW PRISMA MOTOR		SNOW PRISMA ENGINE		Sida Page 6	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
10 10B	1 3				1812-2497-01 699854	Ljuddämparskydd..... Skruv.....	Muffler guard Screw.....		B&S part




Utgåva Issue 2013-11		Bildnr Picture No 2771A		SNOW PRISMA DRIVNING SNÖSKRUV		SNOW PRISMA AUGER DRIVE		Sida Page 8	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
10	1				1812-2602-01	Remskiva-sekundär	Pulley-driven		
20	1				1812-2557-01	Remskiva-primär	Pulley-driver		
30	1				1812-2577-01	Spännarm	Idler drive arm		
40	1				1812-2077-01	Spännrulle	Tension roller		
50	1				1812-2566-01	Drivrem	Drive belt		
60	1				9988-3738-12	Skruv	Screw		
70	1				9743-3721-32	Mutter	Nut		
80	1				1812-2601-01	Distans	Spacer		
90	1				1812-2642-01	Vagnsbult	Carriage bolt		
100	1				1812-2654-01	Bricka	Flat washer		
110	1				9743-3521-32	Mutter	Nut		
120	1				1812-2126-01	Reglagewire	Drive cable		
130	1				1812-2608-01	Fjäderhylsa	Clutch spring boot		
140	1				1812-2615-01	Fjäder	Idler spring		
150	1				1812-2616-01	Fjäder	Extension spring		
160	1				1812-2617-01	Fäste	Cable guide bracket		
170	2				1812-2619-01	Skruv	Screw		
180	1				1812-2625-01	Skruv	Screw		
190	1				1812-2651-01	Mutter	Nut		
200	1				1812-1205-01	Spole	Spool		
210	1				1812-2079-01	Skruv	Screw		
220	1				9683-0035-02	Bricka	Washer		
240	1				1812-2763-01	Låsbricka	Push nut		




Utgåva Issue 2013-11		Bildnr Picture No 2767A		SNOW PRISMA HJUL KÅPOR		SNOW PRISMA WHEELS BODY COVER		Sida Page 10	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
10	1				1812-3058-01	Kåpa-övre, gul	Cover-top , yellow.....		
20	1				1812-2579-01	Kåpa, svart	Drive case cover, bl.....		
30	2				9988-3551-12	Skruv	Screw.....		
40	2				9743-3521-32	Mutter	Nut.....		
50	2				1812-2618-01	Skruv.....	Screw.....		
60	6				1812-2619-01	Skruv.....	Screw.....		
70	2				1812-2994-01	Hjul	Wheel		
80	2				1812-3130-01	Låsring	E-ring		
90	2				1812-2649-01	Planbricka	Flat washer		
100	2				1812-2627-01	Skruv.....	Cap screw		
110	2				1812-2498-01	Snabbmutter.....	Speed nut.....		
120	1				1812-2603-01	Kåpring-utkast	Chute cover		
130	1				1812-3007-01	Skruv.....	Screw.....		
140	2				1812-2750-01	Navkapsel	Hub cap		


x




Utgåva Issue 2013-11		Bildnr Picture No 2765A		SNOW PRISMA SNÖSKRUV		SNOW PRISMA AUGER		Sida Page 12	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
10	1				1812-2635-01	Snöskruv	Auger assy.....		Inkl. pos 10B-10F Inkl. pos 10D
10B	1				1812-2503-01	Gummiskärsats	Auger flight kit		
10D	12				1812-2652-01	Skruv.....	Screw.....		
10E	1				9743-3521-32	Mutter	Nut.....		
10F	1				9988-3538-12	Skruv.....	Screw.....		
20	2				1812-2559-01	Lagerhållare.....	Bearing retainer.....		
30	6				1812-2619-01	Skruv.....	Screw.....		
40	2				1812-2373-01	Kullager	Ball bearing		
50	1				9988-3619-16	Skruv.....	Screw.....		
60	1				1812-2560-01	Lagerlock.....	Bearing cap		
70	1				1812-2660-01	Bricka	Washer.....		



Utgåva Issue 2013-11		Bildnr Picture No 2855		SNOW PRISMA UTKASTROTATION		SNOW PRISMA CHUTE ROTATION		Sida Page 14	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
10	1				1812-2556-01	Ringdrev-utkastrot.....	Chute rotation gear.....		
20	1				1812-2570-01	Platta-utkast	Chute mounting plate.....		
30	1				1812-2571-01	Hållare-ringdrev	Chute gear retainer.....		
40	2				1812-2618-01	Skruv.....	Screw.....		
50	1				1812-2907-01	Block	Block stop		
60	1				1812-2906-01	Fjäder.....	Spring.....		
70	1				1812-2257-01	Skruv.....	Screw.....		
80	1				1812-2619-01	Skruv.....	Screw.....		



Utgåva Issue 2013-11		Bildnr Picture No 2856		SNOW PRISMA UTKAST		SNOW PRISMA CHUTE		Sida Page 16	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
10	1				1812-2923-01	Skruvsats.....	Parts bag.....		Incl. Pos 10A
10A	3				1812-2749-01	Skruv.....	Screw.....		
20	1				1812-2912-01	Utkast kpl.....	Chute assy.....		Incl. 20A-20B
20A	1				1812-2977-01	Ansatsbult.....	Bolt.....		
20B	1				1812-2361-01	Vingmutter.....	Wingnut.....		
30	1				1812-2911-01	Handtag.....	Handle.....		




A




B



C



D



E



F



Utgåva Issue 2013-11		Bildnr Picture No 2857		SNOW PRISMA DEKALER		SNOW PRISMA LABELS		Sida Page 18	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	2815								
1	1				1812-2700-02	Dekalsats.....	Label kit		Incl. A-I