



Genuine Spare Parts






Utgåva Issue 2003- 43		Bildnr Picture No 1484A		ST 210 TRIMMER RIGG SKÄRHUVUD		ST 210 TRIMMER DRIVE SHAFT STRINGHEAD		Sida Page 272	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	1021								
2	1				1911-3761-01	Platta	Fixed plate		Inkl. pos 11, 12
3	4				1911-3762-01	Isolator	Insulator		
5	1				1911-3773-01	Gaswire	Throttle cable		
6	1				1911-3763-01	Lock	Cover		
7	1				1911-3764-01	Jordkabel	Ground wire		
8	1				1911-3765-01	Brytare	Switch		
9	1				1911-3774-01	Hus kpl (vä+hö)	Housing assy (L+R)		
10	1				1911-3766-01	Bränsletank kpl	Fuel tank assy		
11	1				1911-3767-01	• Bränslefilter	• Fuel pick-up		
12	1				1911-3768-01	• Tanklock	• Fuel cap		
13	1				1911-3769-01	Fjäder	Spring		Inkl. pos 21 Inkl. pos 23 - 25 0.45 kg (130 m) 15 m
14	1				1911-3770-01	Gasreglage	Throttle trigger		
15	1				1911-3775-01	Rör bakre m.flexaxel	Rear tube w.flex shaf.		
16	1				1911-3756-01	Handtag kpl	Handle assy		
17	1				1911-3776-01	Axelhylsa	Shaft sleeve		
18	1				1911-3777-01	Rörkoppling kpl	Tube joint		
19	1				1911-3778-01	Rör främre m.flexaxel	Front tube w.flex sh.		
20	1				1911-3771-01	Skydd kpl	Shield assy		
21	1				1911-3772-01	• Kniv	• Line cutter blade		
22	1				1911-3760-01	Skärhuvud kpl	Cutterhead assy		
22A	1				1911-9007-04	Skärtråd (2.0 mm)	Cutting line (2.0 mm)		
22A	1				1911-9007-08	Skärtråd (2.0 mm)	Cutting line (2.0 mm)		
23	2				1911-3759-01	• Trådhylsa	• Grommet		
24	1				1911-3758-01	• Fjäder	• Spring		
25	1				1911-3757-01	• Ratt	• Knob		
26	1				1911-3779-01	Koppling	Clutch		
27	1				1911-3780-01	Kopplingshjul	Clutch drum		



Utgåva Issue		Bildnr Picture No		ST 210- SB 22 MOTOR		ST 210- SB 22 ENGINE		Sida Page
2003- 43		1485A						276
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	1021 6110							
1	1			1911-3781-01	Start kpl.....	Start assy.....		Inkl. pos 2 - 5
2	1			1911-3782-01	• Starthandtag.....	• Starter handle.....		
3	1			1911-3783-01	• Startsnöre.....	• Starter rope.....		
4	1			1911-3784-01	• Fjäder.....	• Spring.....		
5	1			1911-3785-01	• Linhjul.....	• Pulley.....		
6	1			1911-3786-01	Packningssats.....	Gasket set.....		
7	1			1911-3787-01	Förgasarfäste.....	Carburettor base.....		
8	1			1911-3788-01	Förgasare kpl.....	Carburettor assy.....		
9	1			1911-3789-01	• Chokespjäll.....	• Choke valve.....		
10	2			1911-3790-01	• Luftfilter.....	• Air filter.....		
11	1			1911-3791-01	Luftfilter kpl.....	Air filter assy.....		Inkl. pos 9 - 10
12	1			1911-3792-01	Primer.....	Primer.....		
15	1			1911-3855-01	Startspärr kpl.....	Starter pawl assy.....		
16	1			1911-3796-01	Svänghjul.....	Flywheel.....		
17	1			1911-3797-01	• Tätningsring.....	• Seal ring.....		
18	1			1911-3798-01	• Kil.....	• Key.....		
19	1			1911-3799-01	• Tätningsring.....	• Seal ring.....		
20	1			1911-3800-01	Short- block.....	Short- block.....		
21	2			1911-3801-01	• • Låsring.....	• • Lock ring.....		
22	2			1911-3802-01	• • Packning.....	• • Gasket.....		
23	1			1911-3803-01	• • Kolvbult.....	• • Piston pin.....		
23A	2			1911-3816-01	• • Kolvring.....	• • Piston ring.....		
24	1			1911-3804-01	• Kolv kpl.....	• Piston assy.....		Inkl. pos 21 - 23A
25	1			1911-3805-01	Cylinder kpl m.kolv.....	Cylinder assy w.pisto.....		Inkl. pos 24
26	2			1911-3806-01	Skruv.....	Screw.....		
27	1			1911-3807-01	Ljuddämpare.....	Muffler.....		
28	2			1911-3808-01	Skruv.....	Screw.....		
29	1			1911-3809-01	Motorkåpa.....	Engine shield.....		
30	1			9400-0258-00	Tändstift.....	Spark plug.....		Champion CJ7Y
31	1			1911-3810-01	Kablage.....	Wiring harness.....		
32	1			1911-3811-01	Elektronikspole.....	Electronic coil.....		
33	2			1911-3812-01	Distans.....	Spacer.....		
34	2			1911-3813-01	Skruv.....	Screw.....		
35	1			1911-3814-01	Svänghjulslock.....	Flywheel cover.....		
36	1			1911-3815-01	Tändstiftsskydd.....	Spark plug cover.....		

X



Utgåva Issue 2004- 12		Bildnr Picture No 1733		KULTIVATOR ST 210- SB 22 ART.NR 19- 1921- 11		CULTIVATOR ST 210- SB 22 ART.NO 19- 1921- 11		Sida Page 366	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	1921								
1	1				1911-2011-01	Flexaxel.....	Flex shaft.....		Inkl. pos 23
2	1				1911-2030-01	Bricka	Washer.....		
3	1				1911-2014-01	Bussning	Bushing.....		
4	1				1911-2010-01	Rör	Steel tube.....		
5	4				1911-2027-01	Skruv	Screw.....		
6	1				1911-2006-01	Skydd	Guard shield.....		
7	2				1911-2016-01	Bussning	Bushing.....		
8	4				1911-2026-01	Mutter.....	Nut		
9	1				1911-2015-01	Packning.....	Gasket		
10	1				1911-2019-01	Skruv	Screw.....		
11	10				1911-2028-01	Skruv	Screw.....		
12	1				1911-2022-01	Transm.hus- hö.....	Gearbox- RH.....		
13	1				1911-2008-01	Tätningsring	Oil seal		
14	1				1911-2017-01	Bussning	Bushing.....		
15	1				1911-2013-01	Lager	Bearing.....		
16	1				1911-2007-01	Snäckskruv	Worm shaft		
17	1				1911-2018-01	Bussning	Bushing.....		
18	2				1911-2024-01	Rotor	Blade		
19	4				1911-2020-01	Sprint.....	Pin		
20	4				1911-2021-01	Låssprint	Pin lock		
21	2				1911-2025-01	Rotor	Blade		
22	1				1911-2012-01	Axel m drev	Spiral gear assy		
24	1				1911-2023-01	Transm.hus- vä.....	Gearbox- LH.....		
25	2				1911-2001-01	O- ring	O- ring		
26	2				1911-2000-01	Bricka	Washer.....		
27	2				1911-2009-01	Filtring	Dust ring		
28	1				1911-2004-01	Bricka	Washer.....		
29	2				1911-2003-01	Bricka	Washer.....		
30	4				1911-2031-01	Bricka	Washer.....		
31	1				1911-2002-01	O- ring	O- ring		
32	2				1911-2005-01	Bricka	Washer.....		
33	2				1911-2029-01	Skruv	Screw.....		
34	1				1911-2032-01	Fjäderbricka	Spring washer		
35	1				1911-2033-01	Skyddshatt.....	Sleeve		