



Genuine Spare Parts






Utgåva Issue 2004- 12		Bildnr Picture No 1616A		SB 22 RÖJARE RIGG SKÄRHUVUD		SB 22 BRUSH CUTTER DRIVE SHAFT STRINGHEAD		Sida Page 254	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	6110								
2	1				1911-3761-01	Platta	Fixed plate		Inkl. pos 11, 12, 34
3	4				1911-3762-01	Isolator	Insulator		
5	1				1911-3911-01	Gaswire	Throttle cable		
6	1				1911-3763-01	Lock.....	Cover		
7	1				1911-3764-01	Jordkabel.....	Ground wire		
8	1				1911-3918-01	Strömbrytare	Switch		
9	1				1911-3919-01	Kåpa kpl- gul.....	Housing assy- yellow		
10	1				1911-3766-01	Bränsletank kpl	Fuel tank assy		
11	1				1911-3767-01	• Bränslefilter	• Fuel pick- up		
12	1				1911-3912-01	• Tanklock	• Fuel tank cap		
13	1				1911-3913-01	Fjäder.....	Spring		Inkl. pos 17
14	1				1911-3914-01	Gasreglage.....	Throttle trigger		
14A	1				1911-3915-01	Säkerhetsspärr	Safety lever		
15	1				1911-3916-01	Rör nedre m.drivaxel	Lower tube w.shaft.....		
15A	1				1911-3917-01	Rör övre m.drivaxel	Upper tube w.shaft.....		
16	1				1911-3896-01	Stenskydd kpl	Stone guard assy		
17	1				1911-3772-01	• Kniv	• Line cutter blade		
18	1				1911-3897-01	Handtag främre kpl	Front handle assy		
19	1				1911-3895-01	Skärhuvud kpl.....	Cutting head assy.....		
19A	1				1911-9007-04	Skärtråd (2.0 mm)	Cutting line (2.0 mm)		
19A	1				1911-9007-08	Skärtråd (2.0 mm)	Cutting line (2.0 mm)		Inkl. pos 20 - 22 0.45 kg (130 m) 15 m
20	1				1911-3898-01	• Fjäder.....	• Spring		
21	2				1911-3899-01	• Trådhylsa	• Line inlet		
22	1				1911-3757-01	• Ratt (vå- gänga)	• Knob (LH- thread)		
23	1				1911-3900-01	Snäckväxel kpl	Gear case assy		
23A	1				1911-3901-01	Hylsa	Collar		
23B	1				1911-3902-01	Övre ringmutter	Upper ring nut.....		
23C	1				1911-3903-01	Nedre ringmutter	Lower ring nut		
23D	1				1911-3904-01	Bricka	Washer		
23E	1				1911-3905-01	Mutter.....	Nut		
24	1				1911-3906-01	Stabiliseringsskål.....	Stabilizer bowl.....		3T
25	1				1911-3920-01	Röjklinga	Clearing blade		
26	1				1911-3907-01	Nyckel- skärhuvud	Key- cutting head		
27	1				1911-3908-01	Sele	Harness.....		
28	1				1911-3909-01	Fäste f.sele.....	Harness support		
29	1				1911-3910-01	Dekal- säkerhet	Label- safety		
30	1				1911-3780-01	Kopplingshjul.....	Clutch drum		
31	1				1911-3779-01	Koppling	Clutch.....		
32	1				1911-3777-01	Rörkoppling kpl.....	Tube joint		
33	1				1911-3776-01	Axelhylsa	Shaft sleeve.....		
34	1				1911-3929-01	• Gummiringstättning.....	• Grommet.....		



Utgåva Issue 2004- 12		Bildnr Picture No 1485B		ST 210- SB 22 MOTOR		ST 210- SB 22 ENGINE		Sida Page 256	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	1021 6110								
1	1				1911-3781-01	Start kpl.....	Start assy		Inkl. pos 2 - 5
2	1				1911-3782-01	• Starthandtag	• Starter handle.....		
3	1				1911-3783-01	• Startsnöre.....	• Starter rope		
4	1				1911-3784-01	• Fjäder.....	• Spring		
5	1				1911-3785-01	• Linhjul.....	• Pulley		
6	1				1911-3786-01	Packningssats	Gasket set		Inkl. pos 9 - 10
7	1				1911-3787-01	Förgasarfäste.....	Carburettor base		
8	1				1911-3788-01	Förgasare kpl.....	Carburettor assy		
9	1				1911-3789-01	• Chokespjäll	• Choke valve		
10	2				1911-3790-01	• Luftfilter.....	• Air filter		
11	1				1911-3791-01	Luftfilter kpl	Air filter assy		
12	1				1911-3792-01	Primer	Primer		
15	1				1911-3855-01	Startspärr kpl.....	Starter pawl assy		
16	1				1911-3796-01	Svånghjul.....	Flywheel		
17	1				1911-3797-01	• Tätningsring	• Seal ring.....		
18	1				1911-3798-01	• Kil	• Key		
19	1				1911-3799-01	• Tätningsring	• Seal ring.....		
20	1				1911-3800-01	Short- block.....	Short- block		
21	2				1911-3801-01	• Låsring.....	• Lock ring		
22	2				1911-3802-01	• Packning.....	• Gasket		
23	1				1911-3803-01	• Kolvbult	• Piston pin		
23A	2				1911-3816-01	• Kolvring	• Piston ring.....		
24	1				1911-3804-01	• Kolv kpl.....	• Piston assy.....		
25	1				1911-3805-01	Cylinder kpl m.kolv	Cylinder assy w.pisto	Inkl. pos 21 - 23A	
26	2				1911-3806-01	Skruv	Screw	Inkl. pos 24	
27	1				1911-3807-01	Ljuddämpare	Muffler		
28	2				1911-3808-01	Skruv	Screw		
29	1				1911-3809-01	Motorkåpa	Engine shield.....		
30	1				9400-0258-00	Tändstift	Spark plug.....	Champion CJ7Y	
31	1				1911-3810-01	Kablage.....	Wiring harness.....		
32	1				1911-3811-01	Elektronikspole	Electronic coil		
33	2				1911-3812-01	Distans	Spacer.....		
34	2				1911-3813-01	Skruv	Screw		
35	1				1911-3814-01	Svånghjulslock	Flywheel cover		
36	1				1911-3815-01	Tändstiftsskydd	Spark plug cover.....		



Utgåva Issue 2004- 12		Bildnr Picture No 1733		KULTIVATOR ST 210- SB 22 ART.NR 19- 1921- 11		CULTIVATOR ST 210- SB 22 ART.NO 19- 1921- 11		Sida Page 366	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	1921								
1	1				1911-2011-01	Flexaxel.....	Flex shaft.....		Inkl. pos 23
2	1				1911-2030-01	Bricka	Washer.....		
3	1				1911-2014-01	Bussning	Bushing.....		
4	1				1911-2010-01	Rör	Steel tube.....		
5	4				1911-2027-01	Skruv	Screw.....		
6	1				1911-2006-01	Skydd	Guard shield.....		
7	2				1911-2016-01	Bussning	Bushing.....		
8	4				1911-2026-01	Mutter.....	Nut.....		
9	1				1911-2015-01	Packning.....	Gasket.....		
10	1				1911-2019-01	Skruv	Screw.....		
11	10				1911-2028-01	Skruv	Screw.....		
12	1				1911-2022-01	Transm.hus- hö.....	Gearbox- RH.....		
13	1				1911-2008-01	Tätningsring	Oil seal		
14	1				1911-2017-01	Bussning	Bushing.....		
15	1				1911-2013-01	Lager	Bearing.....		
16	1				1911-2007-01	Snäckskruv	Worm shaft		
17	1				1911-2018-01	Bussning	Bushing.....		
18	2				1911-2024-01	Rotor	Blade		
19	4				1911-2020-01	Sprint.....	Pin		
20	4				1911-2021-01	Låssprint	Pin lock		
21	2				1911-2025-01	Rotor	Blade		
22	1				1911-2012-01	Axel m drev	Spiral gear assy		
24	1				1911-2023-01	Transm.hus- vä.....	Gearbox- LH.....		
25	2				1911-2001-01	O- ring	O- ring		
26	2				1911-2000-01	Bricka	Washer.....		
27	2				1911-2009-01	Filtring	Dust ring		
28	1				1911-2004-01	Bricka	Washer.....		
29	2				1911-2003-01	Bricka	Washer.....		
30	4				1911-2031-01	Bricka	Washer.....		
31	1				1911-2002-01	O- ring	O- ring		
32	2				1911-2005-01	Bricka	Washer.....		
33	2				1911-2029-01	Skruv	Screw.....		
34	1				1911-2032-01	Fjäderbricka	Spring washer		
35	1				1911-2033-01	Skyddshatt.....	Sleeve		