



Genuine Spare Parts





Utgåva Issue 2004- 12		Bildnr Picture No 1752		SB 435 RÖJARE RIGG		SB 435 BRUSH CUTTER DRIVE SHAFT		Sida Page 282	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4401								
1	4				1911-3001-01	Skruv	Screw		
2	1				1911-4006-01	Stöd- fram	Housing support-front		
3	1				1911-4004-01	Vibrationsdämpare- fra	Shock absorber- front		
4	1				1911-4009-01	Handtag- fram	Handle- front		
5	2				1911-3216-01	Bricka	Washer		
6	2				1911-3251-01	Skruv	Screw		
7	1				1911-4007-01	Distans	Step- down spacer		
8	1				1911-4008-01	Transmissionshus	Transmission housing		
9	1				1911-4010-01	Handtagshus	Handgrip housing		
10	1				1911-4003-01	Säkerhetsspärr	Safety lever		
11	1				1911-4001-01	Fjäder	Spring		
12	1				1911-4002-01	Gasreglage	Throttle lever		
13	1				1911-3699-01	Stoppknapp	Stop knob		
14	1				1911-3681-01	Stopplatta	Stop plate		
15	1				1911-3656-01	Skruv	Screw		
16	1				1911-3999-01	Kabelhölje	Wire sheath		
17	1				1911-3995-01	Gaswire	Throttle wire		
18	1				1911-3992-01	Jordkabel- svart	Earth cable- black		
19	1				1911-3991-01	Kabel- röd	Cable- red		
20	1				1911-4005-01	Vibrationsdämpare- bak	Shock absorber- rear		
21	1				1911-3011-01	Skruv	Screw		
22	1				1911-3021-01	Mutter	Nut		
23	4				1911-3012-01	Skruv	Screw		
24	1				1911-3658-01	• Skruv	• Screw		
25	1				1911-3035-01	• Kullager	• Ball bearing		
26	1				1911-3066-01	• Låsring	• Lock ring		
27	1				1911-3188-01	Transmissionsnav kpl	Transmission hub assy		Inkl. pos 24 - 26
28	1				1911-3134-01	• Kopplingstrumma	• Clutch		
29	1				1911-3083-01	• Lagernav	• Bearing hub		
30	1				1911-3140-01	Drivaxel kpl	Transm. shaft assy		Inkl. pos 28 - 29
31	1				1911-3139-01	Drivaxelrör	Transmission pipe		
32	2				1911-3216-01	Bricka	Washer		
33	2				1911-3009-01	Skruv	Screw		
34	1				1911-3006-01	• Skruv	• Screw		
35	1				1911-3077-01	• Kniv	• Line cutter		
36	1				1911-3022-01	• Mutter	• Nut		
37	1				1911-3216-01	• Bricka	• Washer		
38	1				1911-3201-01	Säkerhetsskydd kpl	Safety cover assy		Inkl. pos 34 - 37
39	1				1911-3724-01	Sele	Harness		
42	1				1911-3261-01	Skruv	Screw		
43	1				1911-3998-01	Wirejustering	Throttle cable adjust		
44	2				1911-4000-01	Mutter	Nut		
46	1				1911-3166-01	Stenskydd (sågklinga)	Stone shield (saw)		
99	1				1911-3212-01	Skyddsglasögon	Protective goggles		Ej ill(not ill.



Utgåva Issue 2004- 12		Bildnr Picture No 1285B		SB 435- SB 436 RÖJARE SNÄCKVÄXEL		SB 435- SB 436 BRUSH CUTTER GEAR CASE		Sida Page 286	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	4401 4402								
1	1				1911-3137- 01	Snäckväxel kpl.....	Gear case assy		Inkl. pos 2 - 21
1 A	1				1911-3161- 01	Snäckväxelhus.....	Gear case		
2	1				1911-3067- 01	• Låsring	• Lock ring		
3	1				1911-3065- 01	• Låsring	• Lock ring		
4	1				1911-3037- 01	• Kullager	• Ball bearing		
5	1				1911-3036- 01	• Kullager	• Ball bearing		
6	1				1911-3182- 01	• Snäckdrev.....	• Worm gear		
7	2				1911-3008- 01	• Skruv	• Screw		
8	1				1911-3025- 01	• Skruv	• Screw		
9	1				1911-3029- 01	• Skruv	• Screw		
10	1				1911-3038- 01	• Kullager	• Ball bearing		
12	1				1911-3049- 01	• Kil	• Key		
13	1				1911-3034- 01	• Kullager	• Ball bearing		
14	1				1911-3066- 01	• Låsring	• Lock ring		
15	1				1911-3045- 01	• Tättningsring	• Oil seal		
16	1				1911-3082- 01	• Hylsa.....	• Collar.....		
17	1				1911-3081- 01	• Ringmutter- övre.....	• Ring nut- upper		
18	1				1911-3070- 01	• Ringmutter- nedre.....	• Ring nut- lower.....		
19	1				1911-3163- 01	• Skål kpl (fast)	• Bowl assy (fixed).....	Inkl. pos 20 - 21	
20	1				1911-3018- 01	•• Bricka.....	•• Washer		
21	1				1911-3026- 01	•• Skruv (vå- gängad)	•• Screw (LH- thread)		
22	1				1911-3179- 01	Röjklinga	Clearing blade		4T - Ø 255 mm
22 A	1				1911-3850- 01	Klingskydd.....	Blade guard.....		Ej ill/not ill.
24	1				1911-3921- 01	Sågklinga.....	Saw blade		24T - Ø 255 mm
30	1				1911-3877- 01	Skärhuvud kpl.....	Cutterhead assy		Inkl. pos 31 - 32
31	2				1911-3875- 01	• Trådhylsa	• Line inlet		
32	1				1911-3876- 01	• Fjäder.....	• Spring		
33	1				1911-9008- 04	Skärtråd (2.4 mm).....	Cutting line (2.4 mm).....		0.45 kg (90 m)
33	1				1911-9008- 08	Skärtråd (2.4 mm).....	Cutting line (2.4 mm).....	15 m	
99	1				1911-3853- 01	Fettub	Grease tube.....	Ej ill/not ill.	

X