


Genuine Spare Parts





Utgåva Issue 2004- 12		Bildnr Picture No 1615A		ST 600 ELTRIMMER		ST 600 EL. TRIMMER		Sida Page 246	
Pos. Fig.	Antal/Quantity				Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes
	1160								
1	1				1911-3894-01	Hus kpl- gul	Housing assy- yellow		
2	1				1911-3879-01	Drivaxelförbindning	Drive shaft connector		
3	1				1911-3880-01	Anslutning	Connector		
4	1				1911-3881-01	Motor.....	Motor		
5	1				1911-3882-01	Fläkt.....	Fan		
6	1				1911-3883-01	Lock.....	Cover		
7	1				1911-3884-01	Tryckknapp	Button		
8	1				1911-3885-01	Fjäder.....	Spring		
9	1				1911-3886-01	Kondensator	Condensor		
10	1				1911-3887-01	Strömbrytare	Switch.....		
11	1				1911-3888-01	Anslutningssladd	Connecting cable.....		
12	1				1911-3889-01	Avtryckare	Trigger.....		
13	1				1911-3756-01	Handtag kpl	Handle assy.....		
14	1				1911-3890-01	Rör	Tube		
15	1				1911-3891-01	Flexaxel.....	Flexible shaft		
16	1				1911-3892-01	Stenskydd kpl.....	Stone guard assy		Inkl. pos 17
17	1				1911-3893-01	• Kniv	• Blade		
18	1				1911-3927-01	• Ratt (hö- gänga).....	• Knob (RH- thread)		
19	1				1911-3758-01	• Fjäder.....	• Spring		
20	2				1911-3759-01	• Trådhylsa	• Grommet.....		
21	1				1911-3760-01	Skärhuvud kpl.....	Cutterhead assy		Inkl. pos 18 - 20
21A	1				1911-9007- 04	Skärtråd (2.0 mm)	Cutting line (2.0 mm).....		0.45 kg (130 m)
21A	1				1911-9007- 08	Skärtråd (2.0 mm)	Cutting line (2.0 mm).....		15 m
22	1				1911-3928-01	Skydd f. skärhuvud	Cutterhead guard		