




Genuine Spare Parts





Utgåva Issue 2006-12		Bildnr Picture No 1971		SB 425 RÖJARE RIGG			SB 425 BRUSH CUTTER DRIVE SHAFT		Sida Page 308
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4403 -11								
1	1			1911-4206-01	Kopplingstrumma.....	Clutch drum			
2	1			1911-4189-01	Transmissionsstöd	Transmission support			
3	1			1911-4154-01	Gaffel	Fork.....			
4	1			1911-3002-01	Skruv	Screw.....			
5	1			1911-4155-01	Hylsa	Grommet.....			
6	1			1911-4188-01	Stöd	Support.....			
7	1			1911-4245-01	Bussning	Bushing.....			
8	1			1911-3267-01	Bricka	Washer.....			
9	1			1911-3007-01	Skruv	Screw.....			
10	1			1911-4236-01	Reducering	Reduction.....			
11	4			1911-3011-01	Skruv	Screw.....			
12	1			1911-3002-01	Skruv	Screw.....			
13	1			1911-4176-01	Lagernav	Bearing hub.....			
14	1			1911-4134-01	Gaswire	Throttle wire.....			
15	1			1911-4127-01	Kabel	Cable.....			
16	1			1911-4130-01	Jordkabel	Ground cable.....			
17	1			1911-4164-01	Kabelhölje	Wire sheath.....			
18	1			1911-3002-01	Skruv	Screw.....			
21	1			1911-4184-01	Handtag- hö	Handgrip- RH			
22	1			1911-4185-01	Handtag- vä	Handgrip- LH.....			
23	1			1911-3053-01	Stoppkontakt	Stop switch			
24	1			1911-4170-01	Säkerhetsspärr	Safety lever			
25	1			1911-4169-01	Gasreglage	Throttle lever			
26	1			1911-4173-01	Fjäder	Spring			
27	4			1911-3001-01	Skruv	Screw.....			
28	1			1911-4152-01	Värmeisolering	Heat insulator.....			
30	1			1911-3007-01	Skruv	Screw.....			
31	1			1911-4187-01	Fäste- sele	Harness support			
32	1			1911-3278-01	Mutter	Nut			
33	2			1911-3008-01	Skruv	Screw.....			
34	2			1911-3015-01	Bricka	Washer.....			
35	2			1911-3023-01	Mutter	Nut			
36	1			1911-4166-01	Handtag- främre	Handle- front			
41	1			1911-4253-01	Transmissionsrör	Transmission tube.....			
42	1			1911-4258-01	Transmissionsaxel	Transmission shaft			
43	1			1911-3998-01	Wirejustering	Throttle cable adjust			
44	2			1911-4000-01	Mutter	Nut			
46	1			1911-3261-01	Skruv	Screw.....			
47	1			1911-3724-01	Sele	Harness			
51	1			1911-3201-01	Säkerhetsskydd kpl	Safety cover assy	Inkl. pos 52 - 55		
52	1			1911-3022-01	• Mutter	• Nut			
53	1			1911-3216-01	• Bricka	• Washer			
54	1			1911-3077-01	• Kniv	• Line cutter			
55	1			1911-3006-01	• Skruv	• Screw			
56	2			1911-3009-01	Skruv	Screw			
57	2			1911-3216-01	Bricka	Washer			
99	1			1911-3212-01	Skyddsglasögon	Protective goggles	Tillbehör/accessory		



Utgåva Issue 2006-12		Bildnr Picture No 1973A		SB 425- SB 426 RÖJARE SNÄCKVÄXEL			SB 425- SB 426 BRUSH CUTTER GEAR CASE		Sida Page 312
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4403	4404	-11						
X	61	1		1911-4222-01	Snäckväxel kpl.....	Gear case assy		Inkl. pos 62 - 79	
X	62	1		1911-4124-01	• Snäckväxelhus.....	• Gear case			
X	63	1		1911-3678-01	• Låsring	• Lock ring			
X	64	1		1911-3662-01	• Kullager	• Ball bearing			
X	65	1		1911-3038-01	• Kullager	• Ball bearing			
X	66	1		1911-3677-01	• Låsring	• Lock ring			
X	67	1		1911-4234-01	• Snäckdrev.....	• Pinion.....			
X	68	1		1911-3029-01	• Skruv	• Screw			
X	69	1		1911-3663-01	• Kullager	• Ball bearing			
X	70	1		1911-4457-01	• Drev	• Ring gear			
X	72	1		1911-4441-01	• Axel.....	• Shaft			
X	73	1		1911-3039-01	• Kullager	• Ball bearing			
X	74	1		1911-3679-01	• Låsring	• Lock ring			
X	75	1		1911-3664-01	• Tätningsring	• Seal ring			
X	76	2		1911-3008-01	• Skruv	• Screw			
X	77	1		1911-3025-01	• Skruv	• Screw			
X	78	1		1911-3690-01	• Hylsa.....	• Collar			
X	79	1		1911-3683-01	• Ringmutter- övre.....	• Ring nut- upper			
X	80	1		1911-3680-01	Ringmutter- nedre	Ring nut- lower			
X	81	1		1911-4242-01	Stabilisator	Stabilizer			
X	82	1		1911-4228-01	Bricka	Washer.....			
X	83	1		1911-4232-01	Mutter	Nut			
X	84A	1		1911-4530-01	Röjklinga	Clearing blade	3T - Ø 255 mm		
X	84B	1		1911-3179-01	Röjklinga	Clearing blade	4T - Ø 255 mm		
X	85	1		1911-4148-01	Skärhuvud kpl.....	Nylon head assy.....	Inkl. pos 86 - 87		
X	85A	1		1911-9008-04	Skärtråd (2.4 mm).....	Cutting line (2.4 mm).....	0.45 kg (90 m)		
X	85A	1		1911-9008-08	Skärtråd (2.4 mm).....	Cutting line (2.4 mm).....	15 m		
X	86	2		1911-3875-01	• Trådhylsa	• Line inlet			
X	87	1		1911-3876-01	• Fjäder	• Spring	Ej ill/not ill.		
X	98	1		1911-3853-01	Fettub	Grease tube	Ej ill/not ill.		
X	99	1		1911-3850-01	Klingskydd.....	Blade guard			