





Genuine Spare Parts





Utgåva Issue 2006-12		Bildnr Picture No 1972		SB 426 RÖJARE RIGG			SB 426 BRUSH CUTTER DRIVE SHAFT		Sida Page 310
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4404 - 11								
1	1			1911-4206-01	Kopplingstrumma.....	Clutch drum			
2	1			1911-4189-01	Transmissionsstöd	Transmission support.....			
3	1			1911-4154-01	Gaffel	Fork.....			
4	1			1911-3002-01	Skruv	Screw.....			
5	1			1911-4155-01	Hylsa	Grommet.....			
6	1			1911-4188-01	Stöd	Support.....			
7	1			1911-4245-01	Bussning	Bushing.....			
8	1			1911-3267-01	Bricka	Washer.....			
9	1			1911-3007-01	Skruv	Screw.....			
10	1			1911-4236-01	Reducering	Reduction.....			
11	4			1911-3011-01	Skruv	Screw.....			
12	1			1911-3002-01	Skruv	Screw			
13	1			1911-4176-01	Lagernav.....	Bearing hub.....			
14	1			1911-4135-01	Gaswire	Throttle wire.....			
15	1			1911-4128-01	Kabel	Coil- switch cable			
16	1			1911-4129-01	Jordkabel.....	Ground cable.....			
17	1			1911-3704-01	Wirehölje	Wire sheath.....			
18	1			1911-3007-01	Skruv	Screw.....			
19	1			1911-4187-01	Fäste- sele.....	Harness support			
20	1			1911-3278-01	Mutter	Nut			
21	1			1911-3203-01	Handtag kpl	Handle assy.....		Inkl. pos 22 - 29	
22	1			1911-3001-01	• Skruv	• Screw			
23	1			1911-3089-01	• Fjäder	• Spring			
24	1			1911-3108-01	• Gasreglage	• Throttle lever			
25	1			1911-3109-01	• Säkerhetsspärr	• Safety lever			
26	1			1911-3090-01	• Fjäder	• Spring			
27	1			1911-3053-01	• Stoppkontakt	• Stop switch			
28	1			9747-0531-02	• Mutter	• Nut			
29	1			1911-3008-01	• Skruv	• Screw			
30	1			1911-4181-01	Reduktion	Reduction.....			
31	1			1911-4253-01	Transmissionsrör.....	Transmission tube.....			
32	1			1911-4258-01	Transmissionsaxel	Transmission shaft.....			
33	4			1911-3009-01	Skruv	Screw			
34	1			1911-4203-01	Styrfäste- övre	Handle support- upper		Inkl. pos 36	
35	1			1911-4214-01	Styre kpl	Handle assy			
36	1			1911-4172-01	• Handtag- vä.....	• Grip- LH			
37	1			1911-4202-01	Styrfäste- mitten	Handle support- middle			
38	1			1911-4257-01	Styrfäste- undre	Handle support- lower			
39	2			1911-3008-01	Skruv	Screw			
43	1			1911-3998-01	Wirejustering	Throttle cable adjust			
44	2			1911-4000-01	Mutter	Nut			
46	1			1911-3261-01	Skruv	Screw			
47	1			1911-3724-01	Sele	Harness			
51	1			1911-3201-01	Säkerhetsskydd kpl.....	Safety cover assy		Inkl. pos 52 - 55	
52	1			1911-3022-01	• Mutter	• Nut			
53	1			1911-3216-01	• Bricka	• Washer			
54	1			1911-3077-01	• Kniv	• Line cutter			
55	1			1911-3006-01	• Skruv	• Screw			
56	2			1911-3009-01	Skruv	Screw			
57	2			1911-3216-01	Bricka	Washer			
99	1			1911-3212-01	Skyddsglasögon	Protective goggles	Tillbehör/accessory		



Utgåva Issue 2006-12		Bildnr Picture No 1973A		SB 425- SB 426 RÖJARE SNÄCKVÄXEL			SB 425- SB 426 BRUSH CUTTER GEAR CASE		Sida Page 312
Pos. Fig.	Antal/Quantity			Art nr Part No	Benämning	Description	Sats Kit	Anmärkning Notes	
	4403	4404	-11						
X	61	1		1911-4222-01	Snäckväxel kpl.....	Gear case assy		Inkl. pos 62 - 79	
X	62	1		1911-4124-01	• Snäckväxelhus.....	• Gear case			
X	63	1		1911-3678-01	• Låsring	• Lock ring			
X	64	1		1911-3662-01	• Kullager	• Ball bearing			
X	65	1		1911-3038-01	• Kullager	• Ball bearing			
X	66	1		1911-3677-01	• Låsring	• Lock ring			
X	67	1		1911-4234-01	• Snäckdrev.....	• Pinion.....			
X	68	1		1911-3029-01	• Skruv	• Screw			
X	69	1		1911-3663-01	• Kullager	• Ball bearing			
X	70	1		1911-4457-01	• Drev	• Ring gear			
X	72	1		1911-4441-01	• Axel.....	• Shaft			
X	73	1		1911-3039-01	• Kullager	• Ball bearing			
X	74	1		1911-3679-01	• Låsring	• Lock ring			
X	75	1		1911-3664-01	• Tätningsring	• Seal ring			
X	76	2		1911-3008-01	• Skruv	• Screw			
X	77	1		1911-3025-01	• Skruv	• Screw			
X	78	1		1911-3690-01	• Hylsa.....	• Collar			
X	79	1		1911-3683-01	• Ringmutter- övre.....	• Ring nut- upper			
X	80	1		1911-3680-01	Ringmutter- nedre	Ring nut- lower			
X	81	1		1911-4242-01	Stabilisator	Stabilizer			
X	82	1		1911-4228-01	Bricka	Washer.....			
X	83	1		1911-4232-01	Mutter	Nut			
X	84A	1		1911-4530-01	Röjklinga	Clearing blade	3T - Ø 255 mm		
X	84B	1		1911-3179-01	Röjklinga	Clearing blade	4T - Ø 255 mm		
X	85	1		1911-4148-01	Skärhuvud kpl.....	Nylon head assy.....	Inkl. pos 86 - 87		
X	85A	1		1911-9008-04	Skärtråd (2.4 mm).....	Cutting line (2.4 mm).....	0.45 kg (90 m)		
X	85A	1		1911-9008-08	Skärtråd (2.4 mm).....	Cutting line (2.4 mm).....	15 m		
X	86	2		1911-3875-01	• Trädhylsa	• Line inlet			
X	87	1		1911-3876-01	• Fjäder	• Spring	Ej ill/not ill.		
X	98	1		1911-3853-01	Fettub	Grease tube	Ej ill/not ill.		
X	99	1		1911-3850-01	Klingskydd.....	Blade guard			