



# Genuine Spare Parts

---







| Utgåva<br>Issue |                | Bildnr<br>Picture No       |  | SB 43P- SB 44P<br>SB 52P PRO<br>RÖJARE<br>MOTOR |                                | SB 43P- SB 44P<br>SB 52P PRO<br>BRUSH CUTTER<br>ENGINE |             | Sida<br>Page        |
|-----------------|----------------|----------------------------|--|-------------------------------------------------|--------------------------------|--------------------------------------------------------|-------------|---------------------|
| 2006- 12        |                | 1288B                      |  |                                                 |                                |                                                        |             | 302                 |
| Pos.<br>Fig.    | Antal/Quantity |                            |  | Art nr<br>Part No                               | Benämning                      | Description                                            | Sats<br>Kit | Anmärkning<br>Notes |
|                 | 4630<br>-14    | 6113<br>-12<br>6115<br>-12 |  |                                                 |                                |                                                        |             |                     |
| 1               | 10             | 10                         |  | 1911-3007-01                                    | Skruv .....                    | Screw .....                                            |             |                     |
| 2               | 1              | 1                          |  | 1911-3732-01                                    | Transm.stödhus .....           | Transm.support case .....                              |             |                     |
| 3               | 4              | 4                          |  | 1911-3023-01                                    | Mutter .....                   | Nut .....                                              |             |                     |
| 4               | 1              | 1                          |  | 1911-3005-01                                    | Skruv .....                    | Screw .....                                            |             |                     |
| 5               | 1              | 1                          |  | 1911-3016-01                                    | Bricka .....                   | Washer .....                                           |             |                     |
| 5A              | 1              | 1                          |  | 1911-3874-01                                    | Flatstiftskontakt .....        | Connector .....                                        |             |                     |
| 6               | 2              | 2                          |  | 1911-3019-01                                    | Bricka .....                   | Washer .....                                           |             |                     |
| 7               | 2              | 2                          |  | 1911-3028-01                                    | • Skruv .....                  | • Screw .....                                          |             |                     |
| 8               |                | 1                          |  | 1911-3086-01                                    | • Fjäder .....                 | • Spring .....                                         |             |                     |
| 8               | 1              |                            |  | 1911-3088-01                                    | • Fjäder .....                 | • Spring .....                                         |             |                     |
| 9               |                | 2                          |  | 1911-3094-01                                    | • Koppling .....               | • Clutch unit .....                                    |             |                     |
| 9               | 2              |                            |  | 1911-3095-01                                    | • Koppling .....               | • Clutch unit .....                                    |             |                     |
| 10A             | 1              | 1                          |  | 1911-3078-01                                    | • Kopplingsplatta- yttre ..... | • Clutch guide plate- ou .....                         |             |                     |
| 10B             | 1              | 1                          |  | 1911-3079-01                                    | • Kopplingsplatta- inre .....  | • Clutch guide plate- in .....                         |             |                     |
| 11              | 2              | 2                          |  | 1911-3009-01                                    | Skruv .....                    | Screw .....                                            |             |                     |
| 12              | 2              | 2                          |  | 1911-3017-01                                    | Bricka .....                   | Washer .....                                           |             |                     |
| 13              | 1              | 1                          |  | 1911-4443-01                                    | Elektronikspole .....          | Electronic coil .....                                  |             |                     |
| 14              | 1              | 1                          |  | 1911-3055-01                                    | Tändstiftskabel .....          | Spark plug cable .....                                 |             |                     |
| 15              | 1              | 1                          |  | 1911-4248-01                                    | Kabelhölje .....               | Wire sheath .....                                      |             |                     |
| 16              | 1              | 1                          |  | 1911-3092-01                                    | Klämma .....                   | Clamp .....                                            |             |                     |
| 17              | 1              | 1                          |  | 1911-3673-01                                    | Jordkabel .....                | Earth cable .....                                      |             |                     |
| 18              | 1              |                            |  | 1911-3186-01                                    | Svänghjul kpl .....            | Flywheel assy .....                                    |             | Inkl. pos 7 - 10    |
| 18              |                | 1                          |  | 1911-3821-01                                    | Svänghjul kpl .....            | Flywheel assy .....                                    |             | Inkl. pos 7 - 10    |
| 19              | 2              | 2                          |  | 1911-3020-01                                    | Mutter .....                   | Nut .....                                              |             |                     |
| 20              | 4              | 4                          |  | 1911-3010-01                                    | Skruv .....                    | Screw .....                                            |             |                     |
| 23              | 2              | 2                          |  | 1911-3044-01                                    | Tätningssring .....            | Seal ring .....                                        |             |                     |
| 24              | 1              | 1                          |  | 1911-3116-01                                    | Gummihylsa .....               | Grommet .....                                          |             |                     |
| 25              | 1              | 1                          |  | 1911-3823-01                                    | Vevhus kpl .....               | Crankcase assy .....                                   |             |                     |
| 26              | 1              | 1                          |  | 1911-3049-01                                    | Kil .....                      | Key .....                                              |             |                     |
| 27              | 1              | 1                          |  | 1911-3041-01                                    | • Nållager .....               | • Needle bearing .....                                 |             |                     |
| 28              | 1              | 1                          |  | 1911-3185-01                                    | Vevaxel kpl .....              | Crankshaft assy .....                                  |             | Inkl. pos 27        |
| 29              | 2              | 2                          |  | 1911-3033-01                                    | Kullager .....                 | Ball bearing .....                                     |             |                     |
| 30              | 1              | 1                          |  | 1911-3098-01                                    | • Packning .....               | • Gasket .....                                         |             |                     |
| 31              | 5              | 5                          |  | 1911-3022-01                                    | Mutter .....                   | Nut .....                                              |             |                     |
| 32              | 2              | 2                          |  | 1911-3002-01                                    | • Skruv .....                  | • Screw .....                                          |             |                     |
| 33              | 2              | 2                          |  | 1911-3087-01                                    | • Fjäder .....                 | • Spring .....                                         |             |                     |
| 34              | 2              | 2                          |  | 1911-3118-01                                    | • Startspärr .....             | • Starter hook .....                                   |             |                     |
| 35              | 1              | 1                          |  | 1911-3824-01                                    | Startkopp kpl .....            | Starter cup assy .....                                 |             | Inkl. pos 32 - 34   |
| 37              | 1              | 1                          |  | 1911-3006-01                                    | Skruv .....                    | Screw .....                                            |             |                     |
| 38              | 1              | 1                          |  | 1911-3174-01                                    | Cylinderkåpa .....             | Cylinder cover .....                                   |             |                     |
| 39              | 1              | 1                          |  | 1911-3136-01                                    | Ljuddämpare .....              | Muffler .....                                          |             |                     |
| 40              | 1              | 1                          |  | 1911-3105-01                                    | • Packning .....               | • Gasket .....                                         |             |                     |
| 41              | 1              | 1                          |  | 1911-3113-01                                    | Tändstiftshylsa .....          | Spark plug cover .....                                 |             |                     |
| 42              | 1              | 1                          |  | 1911-3093-01                                    | Tändstiftsfjäder .....         | Spark plug spring .....                                |             |                     |
| 43              | 1              | 1                          |  | 9400-0258-00                                    | Tändstift .....                | Spark plug .....                                       |             | Champion CJ7Y       |
| 44              | 4              | 4                          |  | 1911-3009-01                                    | Skruv .....                    | Screw .....                                            |             |                     |
| 45              | 1              | 1                          |  | 1911-3099-01                                    | • Cylinderpackning .....       | • Cylinder gasket .....                                |             |                     |
| 46              | 1              |                            |  | 1911-3046-01                                    | • Kolvring .....               | • Piston ring .....                                    |             |                     |
| 46              |                | 1                          |  | 1911-3303-01                                    | • Kolvring .....               | • Piston ring .....                                    |             |                     |
| 47              | 1              |                            |  | 1911-3050-01                                    | • Kolvbult .....               | • Piston pin .....                                     |             |                     |
| 47              |                | 1                          |  | 1911-3305-01                                    | • Kolvbult .....               | • Piston pin .....                                     |             |                     |
| 48              | 2              | 2                          |  | 1911-3068-01                                    | • Låsring .....                | • Lock ring .....                                      |             |                     |
| 49              | 1              |                            |  | 1911-3195-01                                    | • Kolv kpl .....               | • Piston assy .....                                    |             | Inkl. pos 46 - 48   |
| 49              |                | 1                          |  | 1911-3595-01                                    | • Kolv kpl .....               | • Piston assy .....                                    |             | Inkl. pos 46 - 48   |
| 50              | 1              |                            |  | 1911-3196-01                                    | Cylinder kpl m.kolv .....      | Cylinder assy w.pist. ....                             |             | Inkl. pos 49        |
| 50              |                | 1                          |  | 1911-3596-01                                    | Cylinder kpl m.kolv .....      | Cylinder assy w.pist. ....                             |             | Inkl. pos 49        |
| 51              | 2              | 2                          |  | 1911-3007-01                                    | Skruv .....                    | Screw .....                                            |             |                     |
| 52              | 1              | 1                          |  | 1911-3150-01                                    | • Bränslefilter .....          | • Intake filter .....                                  |             |                     |
| 53              | 1              | 1                          |  | 1911-3209-01                                    | • Slangtätning kpl .....       | • Grommet assy .....                                   |             |                     |
| 54              | 1              | 1                          |  | 1911-3207-01                                    | • Tanklock .....               | • Fuel cap .....                                       |             |                     |
| 55              | 1              | 1                          |  | 1911-3147-01                                    | Bränsletank kpl .....          | Fuel tank assy .....                                   |             | Inkl. pos 52 - 54   |
| 56              | 1              | 1                          |  | 1911-3740-01                                    | Fläns .....                    | Flange .....                                           |             |                     |
| 57              | 4              | 4                          |  | 1911-3006-01                                    | Skruv .....                    | Screw .....                                            |             | Plast/plastic       |




|                                 |                |                                   |  |                                                 |                   |                                                        |                   |                         |                      |
|---------------------------------|----------------|-----------------------------------|--|-------------------------------------------------|-------------------|--------------------------------------------------------|-------------------|-------------------------|----------------------|
| Utgåva<br>Issue<br><br>2006- 12 |                | Bildnr<br>Picture No<br><br>1288B |  | SB 43P- SB 44P<br>SB 52P PRO<br>RÖJARE<br>MOTOR |                   | SB 43P- SB 44P<br>SB 52P PRO<br>BRUSH CUTTER<br>ENGINE |                   | Sida<br>Page<br><br>304 |                      |
| Pos.<br>Fig.                    | Antal/Quantity |                                   |  |                                                 | Art nr<br>Part No | Benämning                                              | Description       | Sats<br>Kit             | Anmärkning<br>Notes  |
|                                 |                | 6113<br>-12                       |  |                                                 |                   |                                                        |                   |                         |                      |
|                                 | 4630<br>-14    | 6115<br>-12                       |  |                                                 |                   |                                                        |                   |                         |                      |
| 57                              | 4              | 4                                 |  |                                                 | 1911-3007-01      | Skruv .....                                            | Screw .....       |                         | Stål/steel           |
| 58                              | 4              | 4                                 |  |                                                 | 1911-3017-01      | Bricka .....                                           | Washer .....      |                         |                      |
| 59                              | 4              | 4                                 |  |                                                 | 1911-3023-01      | Mutter .....                                           | Nut .....         |                         | Inkl. pos 30, 40, 45 |
| 64                              | 1              | 1                                 |  |                                                 | 1911-3206-01      | Packningssats .....                                    | Gasket set .....  |                         |                      |
| 67                              | 1              | 1                                 |  |                                                 | 1911-3013-01      | Skruv .....                                            | Screw .....       |                         |                      |
| 68                              | 1              | 1                                 |  |                                                 | 1911-3701-01      | Distans .....                                          | Spacer .....      |                         |                      |
| 69                              | 1              | 1                                 |  |                                                 | 1911-3723-01      | Påse m.verktyg .....                                   | Bag w.tools ..... |                         |                      |



[illegible]



| Utgåva<br>Issue<br><br>2006- 12 |                | Bildnr<br>Picture No<br><br>1284 |  | SB 40- SB 44P<br>SB 52P PRO<br>RÖJARE<br>RIGG |                   | SB 40- SB 44P<br>SB 52P PRO<br>BRUSH CUTTER<br>DRIVE SHAFT |                             | Sida<br>Page<br><br>294                                          |                     |
|---------------------------------|----------------|----------------------------------|--|-----------------------------------------------|-------------------|------------------------------------------------------------|-----------------------------|------------------------------------------------------------------|---------------------|
| Pos.<br>Fig.                    | Antal/Quantity |                                  |  |                                               | Art nr<br>Part No | Benämning                                                  | Description                 | Sats<br>Kit                                                      | Anmärkning<br>Notes |
|                                 | 4629<br>-13    | 6115<br>-12<br>4630<br>-14       |  |                                               |                   |                                                            |                             |                                                                  |                     |
| 1                               | 1              | 1                                |  |                                               | 1911-3203-01      | Handtag kpl .....                                          | Handle assy.....            |                                                                  | Inkl. pos 2 - 9     |
| 2                               | 1              | 1                                |  |                                               | 1911-3001-01      | • Skruv .....                                              | • Screw .....               |                                                                  |                     |
| 3                               | 1              | 1                                |  |                                               | 1911-3008-01      | • Skruv .....                                              | • Screw .....               |                                                                  |                     |
| 4                               | 1              | 1                                |  |                                               | 9747-0531-02      | • Mutter.....                                              | • Nut .....                 |                                                                  |                     |
| 5                               | 1              | 1                                |  |                                               | 1911-3053-01      | • Stoppkontakt .....                                       | • Stop switch .....         |                                                                  |                     |
| 6                               | 1              | 1                                |  |                                               | 1911-3108-01      | • Gasreglage.....                                          | • Throttle lever .....      |                                                                  |                     |
| 7                               | 1              | 1                                |  |                                               | 1911-3109-01      | • Säkerhetsspärr .....                                     | • Safety lever .....        |                                                                  |                     |
| 8                               | 1              | 1                                |  |                                               | 1911-3089-01      | • Fjäder.....                                              | • Spring .....              |                                                                  |                     |
| 9                               | 1              | 1                                |  |                                               | 1911-3090-01      | • Fjäder.....                                              | • Spring .....              |                                                                  |                     |
| 10                              | 1              |                                  |  |                                               | 1911-3146-01      | Gaswire .....                                              | Throttle wire.....          |                                                                  |                     |
| 10                              |                | 1                                |  |                                               | 1911-4453-01      | Gaswire .....                                              | Throttle cable .....        |                                                                  |                     |
| 11                              | 1              | 1                                |  |                                               | 1911-3133-01      | Kabelskydd .....                                           | Wire sheath.....            |                                                                  |                     |
| 12                              | 1              | 1                                |  |                                               | 1911-3061-01      | Kabel- röd .....                                           | Cable- red.....             |                                                                  |                     |
| 13                              | 1              | 1                                |  |                                               | 1911-3062-01      | Jordkabel- svart.....                                      | Earth cable- black .....    |                                                                  |                     |
| 14                              | 1              | 1                                |  |                                               | 1911-3722-01      | Styre.....                                                 | Handle.....                 |                                                                  |                     |
| 15                              | 1              | 1                                |  |                                               | 1911-3114-01      | Handtag- vä .....                                          | Knob- left .....            |                                                                  |                     |
| 16                              | 1              | 1                                |  |                                               | 1911-3000-01      | Skruv .....                                                | Screw .....                 |                                                                  |                     |
| 17                              | 1              | 1                                |  |                                               | 1911-3123-01      | Vingmutter.....                                            | Wing nut .....              |                                                                  |                     |
| 18                              | 1              | 1                                |  |                                               | 1911-3192-01      | Styrinfästning kpl .....                                   | Handle support assy .....   |                                                                  |                     |
| 19                              | 1              | 1                                |  |                                               | 1911-3658-01      | • Skruv .....                                              | • Screw .....               |                                                                  |                     |
| 20                              | 1              | 1                                |  |                                               | 1911-3091-01      | Fjäder.....                                                | Spring .....                |                                                                  |                     |
| 21                              | 1              | 1                                |  |                                               | 1911-3066-01      | • Låsring .....                                            | • Lock ring .....           |                                                                  |                     |
| 22                              | 1              | 1                                |  |                                               | 1911-3035-01      | • Kullager .....                                           | • Ball bearing .....        |                                                                  |                     |
| 23                              | 1              |                                  |  |                                               | 1911-3188-01      | Transmissionsnav kpl .....                                 | Transmission hub assy ..... | Inkl. pos 19, 21 - 22<br>Inkl. pos 19, 21 - 22                   |                     |
| 23                              |                | 1                                |  |                                               | 1911-3189-01      | Transmissionsnav kpl .....                                 | Transmission hub assy ..... |                                                                  |                     |
| 24                              | 1              | 1                                |  |                                               | 1911-3011-01      | Skruv .....                                                | Screw .....                 |                                                                  |                     |
| 25                              | 1              | 1                                |  |                                               | 1911-3021-01      | Mutter.....                                                | Nut .....                   |                                                                  |                     |
| 26                              | 4              | 4                                |  |                                               | 1911-3012-01      | Skruv .....                                                | Screw .....                 |                                                                  |                     |
| 27                              | 1              | 1                                |  |                                               | 1911-3111-01      | Vibrationsdämpare- bak.....                                | Shock absorber- rear.....   |                                                                  |                     |
| 28                              | 1              | 1                                |  |                                               | 1911-3171-01      | Transmissionshus .....                                     | Transmission housing.....   |                                                                  |                     |
| 29                              | 3              | 3                                |  |                                               | 1911-3110-01      | Vibrationsdämpare- fra .....                               | Shock absorber- front ..... |                                                                  |                     |
| 30                              | 1              | 1                                |  |                                               | 1911-3080-01      | Handtagsfästmutter .....                                   | Handle fixing plate .....   |                                                                  |                     |
| 31                              | 1              |                                  |  |                                               | 1911-3172-01      | Stöd- främre .....                                         | Housing support- front..... |                                                                  |                     |
| 31                              |                | 1                                |  |                                               | 1911-3173-01      | Stöd- främre .....                                         | Housing support- front..... |                                                                  |                     |
| 32                              | 2              | 2                                |  |                                               | 1911-3009-01      | Skruv .....                                                | Screw .....                 |                                                                  |                     |
| 33                              | 2              | 2                                |  |                                               | 9747-0531-02      | Mutter.....                                                | Nut .....                   |                                                                  |                     |
| 34                              | 1              | 1                                |  |                                               | 1911-3134-01      | • Kopplingstrumma .....                                    | • Clutch.....               |                                                                  |                     |
| 35                              | 1              | 1                                |  |                                               | 1911-3083-01      | • Lagernav .....                                           | • Bearing hub.....          |                                                                  |                     |
| 36                              | 1              | 1                                |  |                                               | 1911-3140-01      | Drivaxel kpl.....                                          | Transm. shaft assy .....    | Inkl. pos 34 - 35<br>D = 26 mm<br>D = 28 mm<br>Inkl. pos 39 - 42 |                     |
| 37                              | 1              |                                  |  |                                               | 1911-3139-01      | Drivaxelrör .....                                          | Transmission pipe .....     |                                                                  |                     |
| 37                              |                | 1                                |  |                                               | 1911-3142-01      | Drivaxelrör .....                                          | Transmission pipe .....     |                                                                  |                     |
| 38                              | 1              | 1                                |  |                                               | 1911-3201-01      | Säkerhetsskydd kpl.....                                    | Safety cover assy .....     | Tillbehör/accessory                                              |                     |
| 39                              | 1              | 1                                |  |                                               | 1911-3006-01      | • Skruv .....                                              | • Screw .....               |                                                                  |                     |
| 40                              | 1              | 1                                |  |                                               | 1911-3216-01      | • Bricka .....                                             | • Washer .....              |                                                                  |                     |
| 41                              | 1              | 1                                |  |                                               | 1911-3022-01      | • Mutter .....                                             | • Nut .....                 |                                                                  |                     |
| 42                              | 1              | 1                                |  |                                               | 1911-3077-01      | • Kniv .....                                               | • Line cutter .....         |                                                                  |                     |
| 43                              | 2              | 2                                |  |                                               | 1911-3216-01      | Bricka .....                                               | Washer .....                |                                                                  |                     |
| 44                              | 2              | 2                                |  |                                               | 1911-3009-01      | Skruv .....                                                | Screw .....                 |                                                                  |                     |
| 45                              | 1              | 1                                |  |                                               | 1911-3152-01      | Sele .....                                                 | Harness.....                |                                                                  |                     |
| 46                              | 1              | 1                                |  |                                               | 1911-3166-01      | Stenskydd (sågklinga) .....                                | Stone shield (saw) .....    |                                                                  |                     |
| 99                              | 1              | 1                                |  |                                               | 1911-3212-01      | Skyddsglasögon .....                                       | Protective goggles .....    |                                                                  |                     |



| Utgåva<br>Issue<br><br>2006- 12 |                            | Bildnr<br>Picture No<br><br>1285D |                            | SB 39- SB 40- SB 43P<br>SB 44P- SB 52P PRO<br>RÖJARE<br>SNÄCKVÄXEL |                   | SB 39- SB 40- SB 43P<br>SB 44P- SB 52P PRO<br>BRUSH CUTTER<br>GEAR CASE |                              | Sida<br>Page<br><br>296 |                                      |
|---------------------------------|----------------------------|-----------------------------------|----------------------------|--------------------------------------------------------------------|-------------------|-------------------------------------------------------------------------|------------------------------|-------------------------|--------------------------------------|
| Pos.<br>Fig.                    | Antal/Quantity             |                                   |                            |                                                                    | Art nr<br>Part No | Benämning                                                               | Description                  | Sats<br>Kit             | Anmärkning<br>Notes                  |
|                                 | 6118<br>-11<br>4629<br>-13 | 6113<br>-12                       | 6115<br>-12<br>4630<br>-14 |                                                                    |                   |                                                                         |                              |                         |                                      |
| 1                               | 1                          | 1                                 |                            |                                                                    | 1911-3137-01      | Snäckväxel kpl.....                                                     | Gear case assy .....         |                         | Inkl. pos 2 - 21<br>Inkl. pos 2 - 21 |
| 1                               |                            |                                   | 1                          |                                                                    | 1911-3138-01      | Snäckväxel kpl.....                                                     | Gear case assy .....         |                         |                                      |
| 1A                              | 1                          | 1                                 |                            |                                                                    | 1911-3161-01      | Snäckväxelhus.....                                                      | Gear case .....              |                         |                                      |
| 1A                              |                            |                                   | 1                          |                                                                    | 1911-3162-01      | Snäckväxelhus.....                                                      | Gear case .....              |                         |                                      |
| 2                               | 1                          | 1                                 | 1                          |                                                                    | 1911-3067-01      | • Låsring .....                                                         | • Lock ring .....            |                         |                                      |
| 3                               | 1                          | 1                                 | 1                          |                                                                    | 1911-3065-01      | • Låsring .....                                                         | • Lock ring .....            |                         |                                      |
| 4                               | 1                          | 1                                 | 1                          |                                                                    | 1911-3037-01      | • Kullager .....                                                        | • Ball bearing .....         |                         |                                      |
| 5                               | 1                          | 1                                 | 1                          |                                                                    | 1911-3036-01      | • Kullager .....                                                        | • Ball bearing .....         |                         |                                      |
| 6                               | 1                          | 1                                 |                            |                                                                    | 1911-3182-01      | • Snäckdrev.....                                                        | • Worm gear .....            |                         |                                      |
| 6                               |                            |                                   | 1                          |                                                                    | 1911-3183-01      | • Snäckdrev.....                                                        | • Worm gear .....            |                         |                                      |
| 7                               | 2                          | 2                                 | 2                          |                                                                    | 1911-3008-01      | • Skruv .....                                                           | • Screw .....                |                         |                                      |
| 8                               | 1                          | 1                                 | 1                          |                                                                    | 1911-3025-01      | • Skruv .....                                                           | • Screw .....                |                         |                                      |
| 9                               | 1                          | 1                                 | 1                          |                                                                    | 1911-3029-01      | • Skruv .....                                                           | • Screw .....                |                         |                                      |
| 10                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3038-01      | • Kullager .....                                                        | • Ball bearing .....         |                         |                                      |
| 13                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3034-01      | • Kullager .....                                                        | • Ball bearing .....         |                         |                                      |
| 14                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3066-01      | • Låsring .....                                                         | • Lock ring .....            |                         |                                      |
| 15                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3045-01      | • Tätningsring .....                                                    | • Oil seal .....             |                         |                                      |
| 16                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3082-01      | • Hylsa.....                                                            | • Collar.....                |                         |                                      |
| 17                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3081-01      | • Ringmutter- övre.....                                                 | • Ring nut- upper .....      |                         |                                      |
| 18                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3070-01      | • Ringmutter- nedre.....                                                | • Ring nut- lower.....       |                         |                                      |
| 19                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3163-01      | • Skål kpl (fast) .....                                                 | • Bowl assy (fixed) .....    |                         | Inkl. pos 20 - 21                    |
| 20                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3018-01      | • • Bricka.....                                                         | • • Washer.....              |                         |                                      |
| 21                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3026-01      | • • Skruv (vä- gängad) .....                                            | • • Screw (LH- thread) ..... |                         |                                      |
| 22                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3179-01      | Röjklinga .....                                                         | Clearing blade .....         |                         | 4T - Ø 255 mm                        |
| 22A                             | 1                          | 1                                 | 1                          |                                                                    | 1911-3850-01      | Klingskydd.....                                                         | Blade guard.....             |                         | Ej ill/not ill.                      |
| 24                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3921-01      | Sågklinga.....                                                          | Saw blade .....              |                         | 24T - Ø 255 mm                       |
| 31                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3877-01      | Skärhuvud kpl.....                                                      | Cutterhead assy .....        |                         | Inkl. pos 32 - 33                    |
| 31A                             | 1                          | 1                                 | 1                          |                                                                    | 1911-9008-04      | Skärtråd (2.4 mm).....                                                  | Cutting line (2.4 mm).....   |                         | 0.45 kg (90 m)                       |
| 31A                             | 1                          | 1                                 | 1                          |                                                                    | 1911-9008-08      | Skärtråd (2.4 mm).....                                                  | Cutting line (2.4 mm).....   |                         | 15 m                                 |
| 32                              | 2                          | 2                                 | 2                          |                                                                    | 1911-3875-01      | • Trådhylsa .....                                                       | • Line inlet .....           |                         |                                      |
| 33                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3876-01      | • Fjäder.....                                                           | • Spring .....               |                         |                                      |
| 41                              |                            | 1                                 | 1                          |                                                                    | 1911-3154-01      | Skärhuvud kpl (Profi) .....                                             | Nylon head (Profi).....      |                         | Inkl. pos 42 - 44<br>0.45 kg (90 m)  |
| 41A                             |                            | 1                                 | 1                          |                                                                    | 1911-9008-04      | Skärtråd (2.4 mm).....                                                  | Cutting line (2.4 mm).....   |                         |                                      |
| 41A                             |                            | 1                                 | 1                          |                                                                    | 1911-9008-08      | Skärtråd (2.4 mm).....                                                  | Cutting line (2.4 mm).....   |                         | 15 m                                 |
| 42                              |                            | 2                                 | 2                          |                                                                    | 1911-3085-01      | • Bussning.....                                                         | • Bushing .....              |                         |                                      |
| 43                              |                            | 1                                 | 1                          |                                                                    | 1911-3213-01      | • Fjäder.....                                                           | • Spring .....               |                         |                                      |
| 44                              |                            | 1                                 | 1                          |                                                                    | 1911-3215-01      | • Lock.....                                                             | • Cover.....                 |                         |                                      |
| 45                              |                            | 1                                 | 1                          |                                                                    | 1911-3076-01      | Kopp .....                                                              | Cup .....                    |                         |                                      |
| 99                              | 1                          | 1                                 | 1                          |                                                                    | 1911-3853-01      | Fettub .....                                                            | Grease tube.....             |                         | Ej ill/not ill.                      |