


Genuine Spare Parts

SB 27 J








SB 27 J - Model Year 2008

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	23051000/0	Tändstift	Spark Plug	
5	1	123878049/0	Skruv	Screw	
6	1	123878050/0	Skruv	Screw	
7	1	183740005/0	Ljuddämpare	Muffler	
8	1	123280025/0	Packning	Gasket	
10	1	183070003/0	Cylinder	Cylinder - Piston Ass'Y	
13	1	123280026/0	Cylinderkåpa	Cylinder Gasket	
14	2	123204004/0	Kolring	Piston Ring	
15	1	183590003/0	Kolv kpl	Piston Ass' Y	
19	1	123072001/0	Nållager	Needle Bearing	
20	1	123072000/0	Kil	Flywheel Key	
21	1	123020019/0	Vevaxel	Flywheel Key	
22	1	123044007/0	Elektronikspole	Electr. Coil	
23	1	123878051/0	Skruv	Screw	
24	1	123065033/0	Tändstiftskabel	Spark Plug Cable	
25	1	183037001/0	Start kpl-gul	Starter Assy Yellow	
26	1	123082001/0	Startkopp	Starter Cup	
27	1	123593505/0	Låsratt	Knob	
28	1	183090003/0	Luftfilterkåpa-gul	Filter Cover, Yellow	
28	1	183090004/0	Luftfilterkåpa	Filter Cover, Red	
29	1	123220008/0	Luftfilter	Air Filter	
30	1	123878052/0	Skruv	Screw	
31	1	383781001/0	Luftfilterhus	Air Filter Holder	
32	1	123315077/0	Chokearm	Choke Lever	
33	1	123054021/0	Förgasare kpl	Carburettor	
34	1	383073501/0	Insugningsrör	Intake Manifold Assy	
35	1	183303511/0	Packning	Gasket Ass' Y	
40	1	119035154/0	Tätningssring	Seal Ring	
41	1	183275301/0	Shortblock	Engine Short Block	
43	1	123280027/0	Packning	Crankcase Gasket	
45	1	112020001/0	Tätningssring	Seal Ring	
46	1	183880004/0	Svånghjul	Flywheel Ass.Y	
47	1	183733004/0	Bränsletank kpl	Kit Fuel Tank	
48	1	123790016/0	Tanklock	Fuel Cap Assy	
49	1	123120004/0	Mutter	Nut	
50	1	383240001/0	Tankgenomföring	Grommet Assy	
51	1	183215003/0	Koppling	Clutch Ass.Y	
52	1	183520001/0	Bränslefilter	Intake Filter	
54	1	383785001/0	Transmissionsstöd	Support Trasm.Assy, Yellow	
59	1	6980624	Skruv	Screw	
60	1	123275020/0	Hylsa	Grommet	





SB 27 J - Model Year 2008

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	383869060/0	Transm.rör	Transmission Pipe Ass.Y	
2	1	123020018/0	Drivaxel	Transm.Shaft Ass.Y	
3	1	383300018/0	Handtag	Front Handle	
4	1	383260001/0	Förbindning	Joint Chair Ass'Y	
5	1	383300017/0	Handtag kpl	Handle Ass.Y	
6	1	183065012/0	Kablage	Cables Ass.Y + Sheath	
7	1	123700054/0	Handtag-hö	Right Handgrip	
8	1	123700055/0	Handtag-vä	Left Handgrip	
9	1	123430578/0	Fjäder	Spring	
10	1	123315076/0	Gasreglage	Throttle Lever	
11	1	6980206	Brytare	Stop Switch	
12	1	383780001/0	Fäste	Harness Support Ass.Y	
13	1	123046004/0	Sele	Harness	
14	1	383869062/0	Transm.rör	Transmission Pipe Ass.Y	
15	1	123020020/0	Drivaxel	Transm.Shaft Ass.Y	
16	1	383820505/0	Snäckväxel kpl	Gear Case Assy	
21	1	383465005/0	Skyddskåpa	Safety Cover Ass.Y	
25	1	383820504/0	Skärhuvud kpl	Cutting Line Assy	
26	1	123070009/0	Nyckel	Nylon Head Key	
27	1	123155005/0	Röjklinga	3 Teeth Disc	
28	1	383303512/0	Mont.detaljer	Parts Bag	
29	1	6980307	Hylsa	Collar	
30	1	6980308	Övre ringmutter	Upper Ring Nut	
31	1	6980312	Stabiliseringsklå	Stabilizer	