

Genuine Spare Parts

www.stiga.com


SB40 Model Year 2011

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS


All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.








Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	12	2135040	Skruv	Screw	
2	1	4540800	Trasm. Support Case	Trasm. Support Case	
4	1	2132500	Skruv	Screw	
5	1	2312120	Bricka	Washer	
6	4	3745530	Hylsa	Serb.Grommet	
7	2	2653210	Skruv	Screw	
8	1	3654040	Fjäder	Spring Mod.Piston Ass.Y Ø 42	
9	2	3660430/1	Koppling	Clutch Unit Mod.Piston Ass.Y Ø 42	
10	2	2321230	Bricka	Washer	
11	2	2135060	Skruv	Screw	
12	2	2321150	Bricka	Washer	
13	1	3211015	Elektronikspole	Electronic Coil	
14	1	3211080	Spark Plug Cable	Spark Plug Cable	
15	1	3782040	Kabelhölje	Wire Jacket	
16	1	3211415	Jordkabel	Earth Cable	
17	1	4251480/1	Svängjul kpl	Flywheel Ass.Y (Incl. 7,9,10)	
18	2	2670120	Svärdmutter	Nut	
19	3	2135050	Skruv	Screw	
20	2	3121070	Tätningssring	Seal Ring	
21	1	3745130	Hylsa	Grommet	
22	1	8521010	Vevhus	Crankcase Ass.Y	
23	1	3151010	Kil	Flywheel Key	
25	1	3116100	Nållager	Needle Bearing 8X12X10	
27	1	8250840	Vevaxel (Inkl. 25)	Crankshaft (Incl. 25)	
28	2	3112240	Kullager	Bearing	
29	1	3750280	Massathread Guide	Massathread Guide	
30	1	3724050	Packning	Gasket	
31	5	2432040	Mutter	Nut	
32	3	2123100	Skruv	Screw	
33	2	3654050	Fjäder	Spring	
34	2	3749570	Startspärr	Starter Hook	
35	1	8540810	Startkopp (Inkl.32-36)	Starter Cup Ass.Y (Incl.32-36)	
36	1	2135180	Skruv	Screw	
37	1	4563660	Cylinderkåpa	Cylinder Cover Ass.Y Yellow	
38	1	4122120	Luftfilter	Muffler	
41	1	3724340	Packning	Muffler Gasket	
42	1	3744850	Tändstiftshatt	Spark Plug Cover	
43	1	3657530	Tändstiftsfjäder	Spark Plug Spring	
44	1	3210024	Tändstift	Spark Plug	
45	2	2135150	Skruv	Screw	
46	1	3724260	Cylinderkåpa	Cylinder Gasket	
47	1	3123150	Kolvring	Piston Ring X Mod. Ø 38	
48	1	3158260	Kolvbult 8X29	Piston Pin 8X29	
49	2	3356050	Låsring	Circlip	
50	1	8541120	Kolv kpl	Piston Ass.Y Ø 38 (Incl.26,47-49)	
51	1	8541110	Cylinder-kolv kpl Ø 38	Cylinder-Piston Ass.Y Ø 38 (Incl.50)	
52	1	4253290	Bränslefilter	Intake Filter	
53	1	8745541	Gummihylsa	Grommet Ass.Y	
54	1	8741370	Tanklock	Fuel Cap Ass.Y	
55	1	4252470	Bränsletank	Fuel Tank Ass.Y (Incl.52-54)	
61	2	2112310	Skruv	Screw	
62	1	8724340	Packning	Gasket Set (Incl.30,41,46)	
63	1	4612587	Fläns	Flange	










Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	3724360	Packning	Intake Manif-Gasket	
2	1	3750410	Insugningsrör	Intake Manifold	
3	2	2670280	Mutter	Nut	
4	2	2135050	Skruv	Screw	
5	2	3724400	Packning	Intake-Carb Gasket	
6	1	3785070	Värmedistans	Heat Block	
7	1	4353270/1	Förgasare	Carburettor	
8	1	8750390	Luftfilterhus	Air Filter Holder	
9	3	2312090	Bricka	Washer	
10	2	2135250	Skruv	Screw	
11	1	3781600	Luftfilter	Air Filter	
12	1	4563670	Luftfilterkåpa	Filter Cover Yellow	
13	3	2123100	Skruv	Screw	
14	1	3613420	Bricka	Washer	
15	1	4562220	Linhjul	Starter Pulley	
16	1	3723640	Skiva	Disc	
17	1	4611480	Startfjäder	Starter Spring	
18	1	8563650	Starter Recoil Case	Starter Recoil Case	
19	12	2135040	Skruv	Screw	
20	1	3784030	Startsnöre	Starter Cord	
21	1	3750067	Starthandtag	Starter Handle	
22	4	3745530	Hylsa	Serb.Grommet	
23	1	4252680	Start kpl (Inkl.13-22)	Starter Ass.Y (Incl. 13-22)	
24	1	3744870	Primer	Primer Pump	
25	1	4353150	Packning	Gasket-Diaph. Set	
30	2	2461030	Mutter	Nut	






Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	8563830	Handtag	Handle Ass.Y (Incl.2-9)	
2	1	2123030	Skruv	Screw	
3	1	2135050	Skruv	Screw	
4	1	12154330/0	Mutter	Nut	
5	1	3210970	Brytare	Stop Switch	
6	1	3743431/1	Fjäder Arm Gaswire	Spring	
7	1	3743441	Säkerhetsspärr	Safety Lever	
8	1	3654270/1	Fjäder Arm Gaswire	Spring	
9	1	3654280/1	Fjäder	Spring	
10	1	4252570	Gaswire	Wire Ass.Y	
11	1	3786220	Kabelhölje	Wire Sheath	
12	1	3211590	Kabel	Coil-Switch Cable (Red)	
13	1	3211600/1	Jordkabel	Earth Cable (Black)	
14	1	4252840/1	Styre	Handle	
15	1	3744860/1	Handtagsgrepp	Left Knob	
16	1	2112580	Skruv	Screw	
17	1	3750480	Vingmutter	Wing Nut	
18	1	8521070	Styrinfästning kpl	Handgrip Support Ass.Y	
19	1	2126050	Skruv	Screw	
20	1	3654530	Fjäder	Spring	
21	1	3353080	Låsring	Ring	
22	1	3112170	Kullager	Bearing	
23	1	3L8520990/3	Transm.nav	Transmission Hub Ass.Y Ø 26	
24	1	2135150	Skruv	Screw	
25	1	2432030	Mutterschraube (Flex)	Nut (Flex)	
26	4	2135160	Skruv	Screw	
27	1	3744330	Vibrationsdämpare-bak	Rear Shock Absorber	
28	1	4563850/2	Transmissionshus	Transmission Housing	
29	3	3744320	Vibrationsdämpare-fra	Front Shock Absorber	
30	1	3615190	Plåt	Handle Fixing Plate	
31	1	4563860	Stöd-främre	Front Housing Support Ø 26	
32	2	2135060	Skruv	Screw	
33	2	12154330/0	Mutter	Nut	
34	1	4121861/1	Kopplingshjul	Clutch	
35	1	3642191	Lagernav	Bearing Hub	
36	1	4251400	Transmissionsaxel	Trans.Shaft Assy	
37	1	4251204	Drivaxelrör	Transmission Pipe Ass.Y	
38	1	3L8563570/1	Skyddskåpa	Safety Cover Ass.Y (Incl.43-46)	
39	1	2135030	Skruv	Screw	
40	1	2312150	Bricka	Washer	
41	1	2432040	Mutter	Nut	
42	1	3615000	Kniv	Line Cutter	
43	2	2312150	Bricka	Washer	
44	2	2135060	Skruv	Screw	
45	1	4253440	Sele	Harness	
46	1	123046000/0	Sele	Harness	





SB40


Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	4252780/1	Snäckväxel kpl	Gear Case Assy [Ø26]	
1	1	4252780/1	Snäckväxel kpl	Gear Case Assy [Ø26]	
7	2	2135050	Skruv	Screw	
8	1	2653090	Skruv	Screw	
9	1	2653460	Skruv	Screw	
15	1	3121170	Tätningssring	Oil Seal	
16	1	3641700/1	Krage	Collar	
17	1	3641640	Ringmutter-övre	Upper Ring Nut	
18	1	3612640	Ringmutter-nedre	Lower Ring Nut	
19	1	4560610	Stabilisator kpl	Stabilizer	
20	1	2321230	Bricka	Washer	
21	1	2653170	Skruv	Screw	
22	1	4611880	Röjklina	4 Teeth 25 Cm	
31	1	4353240/1	Skärhuvud kpl	2 Hedges Nylon Head	





SB40

Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	6910500	Transmissionsaxel Ø24	Transmission Case Ass.Y Ø24	
2	1	6910502	Kedjestopp	Chain Housing	
3	1	6910503	Tank	Oil Tank	
4	1	6910504	Lock	Cover Ø24	
5	1	6910506	Fläns	Flange	
6	1	6910507	Skruv	Screw	
7	1	6910508	Oljepump	Oil Pump Ass.Y	
8	1	4112610	Svärd	"Guide Bar 10""	
9	1	4113551	Kedja	"Chain 10""	



Pos. Fig.	Antal Quantity	Art No Part No	Benämning	Description	Anmärkning Notes
1	1	6910520	Kniv kpl	Blade Ass.Y	
2	1	6910521	Transmissionsaxel	Transmission Shaft Ass.Y	
3	1	6910524	Snäckväxel kpl	Gear Case Ass.Y	
4	1	6910523	Gasarm	Lever+Regulation Rod	
5	1	4252640	Axelhylsa	Coupling	
6	1	2382430	Distans	Spacer	