

Genuine Spare Parts

www.stiga.com

SBK 53 D


- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

© Copyright 2013 Global Garden Products


All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.

THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.







POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	118801960/0	1	Cylinder	
2	118801779/0	1	Cylinder Gasket	
3	118801818/0	1	Plate	
4	118801979/0	1	Plate	
5	118801823/0	1	Crankcase	
6	118801984/0	1	Crankcase	
7	118801915/0	1	Washer, Piston Pin	
9	118801919/0	2	Bearing	
10	118801923/0	1	Seal Ring	
11	118801995/0	1	Seal Ring	
12	118801940/0	4	Screw	
13	118801946/0	4	Screw	
14	2135120	4	Screw	
15	118801794/0	1	Piston	
16	118801799/0	1	Piston Pin	
17	118801804/0	1	Piston Ring	
18	118801808/0	1	Bearing	
19	118801888/0	1	Crankshaft	
20	118801910/0	2	Spacer	
21	118801916/0	2	Washer, Piston Pin	
22	118802007/0	1	Cylinder Cover Yellow	
23	118801992/0	1	Cylinder Plate	
24	118801898/0	1	Housing	
26	123878020/0	2	Screw	
27	2135040	4	Screw	
28	2135180	2	Screw	
29	118801831/0	2	Insulator	
30	118801840/0	1	Flywheel	
31	123120005/0	1	Nut	
32	118801852/0	1	Earth Cable	
33	118801987/0	1	Coil-Switch Cable	
34	118801948/0	1	Clamp	
35	3210024	1	Spark Plug	
36	3657050	1	Terminal	
37	118801844/0	1	Spark Plug Cover	
38	118801849/0	1	Electronic Coil	
39	3151050	1	Flywheel Key	
40	118801927/0	1	Grommet	
41	2132510	2	Screw	
42	118801780/0	1	Muffler Gasket	
43	118801874/0	1	Muffler	
45	2135010	1	Screw	
46	2135040	2	Screw	
47	118801871/0	1	Starter Pulley	
48	118801912/0	2	Snap Ring	
49	118801977/0	1	Clutch Ass.Y	
50	118801813/0	1	Plate	
51	118801978/0	1	Plate	
52	118801918/0	2	Pin	
53	118801933/0	1	Spring	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	118801858/0	1	Tank Support	
2	118801893/0	1	Tank	
3	118801894/0	1	Oil Cap	
4	2135030	4	Screw	
5	118801925/0	1	Grommet	
6	118801949/0	1	Fuel Line	
7	118802000/0	1	Tube	
8	183520004/0	1	Intake	
11	118801790/0	1	Breather Valve Ass.Y	
12	118801781/0	1	Cylinder Gasket	
13	118801972/0	1	Carburetor Gasket	
14	2135060	4	Screw	
15	118801828/0	1	Carburettor	
17	118801770/0	1	Air Cleaner Base	
18	118801963/0	1	Air Filter	
19	118801786/0	1	Yellow Filter Cover	
20	118801941/0	1	Screw	
21	118801835/0	1	Deflector	
22	118801924/0	1	Or Ring	
23	2135250	2	Screw	
24	112727810/0	1	Screw	
26	118801879/0	1	Starter Assy Black	
27	118801947/0	1	Screw	
28	118801866/0	1	Cam	
29	118801997/0	1	Spring	
30	118801903/0	1	Starter Pulley	
31	118801938/0	1	Starter Spring	
32	2132180	4	Screw	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	4251400	1	Transmission Shaft Assy	
2	3L4121861/1	1	Clutch Drum Assy	
3	3642191	1	Bearing Hub	
4	4630091	1	Trasmission Shaft	
5	323869053/1	1	Trasmission Pipe	
6	3353080	1	Ring	
7	3112170	1	Ball Bearing	
8	2126050	1	Screw	
9	3L8521000/1	1	Transm. Hub Ass.Y Ø28	
10	123066021/0	1	Wire Ass.Y	
11	3786220	1	Wire Sheath	
12	123065031/0	1	Coil-Switch Cable	
13	123065032/0	1	Earth Cable	
14	2135150	1	Screw	
15	2432030	1	Nut	
16	2135160	4	Screw	
17	3L3744330/1	1	Rear Shock Absorber	
18	3L4563850/2	1	Transmission Housing	
19	2112580	1	Screw	
20	3750480	1	Wing Nut	
21	118801367/0	1	Left Handgrip	
22	118801368/0	1	Handle	
23	4541460	1	Bracket	
24	4541450	1	Bracket	
25	118801332/0	1	Left Handgrip,Black	
26	118801333/0	1	Spring	
27	118801335/0	1	Safety Lever	
28	118801337/0	2	Clamp	
29	118801366/0	2	Grommet	
30	118801364/0	1	Cap	
31	118801365/0	1	Grommet	
32	2135180	2	Screw	
33	118801336/0	1	Throttle Lever	
34	118801334/0	1	Spring	
35	118801338/0	1	Spring	
36	118801329/0	1	Stop Knob	
37	118801330/0	1	Stop Plate	
38	112735105/0	4	Screw	
39	118801331/0	1	Right Handgrip,Black	
40	123046002/0	1	Harness	
41	3654530	1	Spring	
42	3744320	3	Front Shock Absorber	
43	3615190	1	Handle Fixing Plate	
44	4563861	1	Front Housing Support Ø 26	
45	2135060	2	Screw	
46	112154330/0	2	Nut	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	3L4252790/1	1	Gear Case Assy	
2	2135050	2	Screw	
3	2653090	4	Screw	
4	1L3641700/1	1	Collar	
5	3641640	1	Upper Ring Nut	
6	3612640	1	Lower Ring Nut	
7	6810050	1	Screw	
8	2321060	1	Washer	
9	3615300	1	Stabilizer	
10	4611880	1	4 Teeth Disc	
11	383820508/0	1	2 Hedges Nylon Head	
12	3614950	2	Plate	
13	6031080	1	F8 Spool	
14	3L8563570/1	1	Safety Cover Ass.Y	
15	2312150	3	Washer	
16	2432040	1	Nut	
17	3615000	1	Line Cutter Blade	
18	2135030	1	Screw	
19	2135060	2	Screw	
20	3L4563577/1	1	Safety Cover	
21	3L4563580/1	1	Splash Guard Lower Protection	